




## STD 22 Compact GYRO COMPASS and STD 22 GYRO COMPASS

**Type 110-233**

**Installation and Service manual**



Weitergabe sowie Vervielfältigung dieser Unterlage, Verwertung und Mitteilung ihres Inhaltes nicht gestattet, soweit nicht ausdrücklich zugestanden. Zuwiderhandlungen verpflichten zu Schadenersatz.

*Toute communication ou reproduction de ce document, toute exploitation ou communication de son contenu sont interdites, sauf autorisation expresse. Tout manquement à cette règle est illicite et expose son auteur au versement de dommages et intérêts.*


*Copying of this document, and giving it to others and the use or communication of the contents thereof, are forbidden without express authority. Offenders are liable to the payment of damages.*

*Sin nuestra expresa autorización, queda terminantemente prohibida la reproducción total o parcial de este documento, así como su uso indebido y/o su exhibición o comunicación a terceros. De los infractores se exigirá el correspondiente resarcimiento de daños y perjuicios.*

# Installation and Service manual

## Compass STD 22

### Compass STD 22 Compact



Compass  
STD 22

## **CONTENTS**

## **Page**

### **Declaration of Conformity**

<b>Safety notes .....</b>	<b>1</b>
---------------------------	----------

<b>1</b>	<b>General information .....</b>	<b>3</b>
1.1	CAN bus (CAN = Controller Area Network) .....	13
<b>2</b>	<b>Preparing to install the STD 22 Compact Gyro Compass ....</b>	<b>15</b>
2.1	STD 22 Compact Compass – Scope of Supply .....	15
2.2	General information concerning installation of the STD 22 Compact Compass .....	16
2.3	Creating cable connections .....	17
2.3.1	General information concerning on-board wiring .....	17
2.3.1.1	General information about creating an earth connection .....	20
2.4	Installing the compass and putting it into operation .....	21
2.4.1	Remove the transportation support with outer sphere, supporting liquid and distilled water. ....	21
2.4.1.1	Assembling the compass enclosure .....	22
2.4.1.2	Installation of the gyrosphere .....	25
2.4.1.3	Filling with distilled water and supporting liquid .....	27
2.4.1.4	Inserting the outer sphere in the compass enclosure .....	29
2.5	Creating cable connections and plug connections .....	31
2.5.1	Overview of plug connections and fuses on PCB's .....	31
2.5.1.1	Connecting the course receiver in the STD 22 Compact Gyro Compass .....	33
2.5.1.2	Connecting status and control signal outputs in the STD 22 Compact Gyro Compass .....	35
2.5.1.3	Connecting signal inputs for QS and SEC in the STD 22 Compact Gyro compass .....	37
2.5.1.4	Connecting the power supply cable .....	39
2.5.1.5	Connecting the compass to earth .....	40
2.6	Installation and commissioning of optional features .....	41
2.6.1	Installation and commissioning of the Additional Output Box 143-103 .....	41
2.6.2	Installation and commissioning of the AC/DC Converter 121-062 .....	43
2.6.3	Installation and commissioning of the Operator Unit Quick Settling (QS) 130-606 .....	46
2.6.3.1	Installing the Operator Unit Quick Settling .....	47
2.6.4	Switching on, settling and adjustment .....	49
2.6.4.1	Switching on the compass .....	49
2.6.4.2	Checks on the compass .....	49
2.6.4.3	Setting the STD 22 Compact Compass into operation .....	51
2.6.4.4	Setting the compass zero (reference course) .....	53
2.6.4.5	Reading the alignment error .....	55
2.6.4.6	Setting Channel 1 and Channel 2 .....	56
2.6.4.7	Setting the information source for Speed Error Correction .....	59
2.6.4.8	Adjustment of essential operating modes .....	63
2.6.4.9	Function check on externally connected course receivers .....	70

# Installation and Service manual

## Compass STD 22

### Compass STD 22 Compact

---

<b>3</b>	<b>Preparing to install the STD 22 Gyro Compass .....</b>	<b>73</b>
3.1	STD 22 Compass – Scope of Supply .....	73
3.1.1	General information concerning installation of the STD 22 Compass .....	74
3.2	Creating cable connections .....	75
3.2.1	General information concerning on-board wiring .....	75
3.2.1.1	General information about creating an earth connection .....	78
3.3	Installing the compass and putting it into operation .....	79
3.3.1	Remove the transportation support with outer sphere, supporting liquid and distilled water .....	79
3.3.1.1	Assembling the compass enclosure .....	80
3.3.1.2	Installation of the gyrosphere .....	83
3.3.1.3	Filling with distilled water and supporting liquid .....	85
3.3.1.4	Inserting the outer sphere in the compass enclosure .....	87
3.4	Creating cable connections and plug connections .....	89
3.4.1	Overview of plug connections and fuses on PCB's .....	89
3.4.2	Creating a cable connection from STD 22 Compass → Distribution Unit .....	91
3.4.2.1	Connecting to the power supply (Distribution Unit) .....	92
3.4.2.2	Connecting the CAN bus plug .....	93
3.4.2.3	Setting the jumpers for the CAN bus .....	94
3.4.2.4	Switching the termination resistors for the CAN bus (E10 only) ..	95
3.4.2.5	Connecting the compass to earth .....	96
3.4.3	Switching on, settling and adjustment .....	97
3.4.3.1	Checks on the compass .....	97
3.4.3.2	Switching on the compass .....	99
3.4.3.3	Setting the compass zero (reference course) .....	101
3.4.3.4	Reading the alignment error .....	103
3.4.3.5	Setting the CAN bus address .....	104
3.4.3.6	Adjustments of essential operating modes .....	105
3.4.3.7	Function check on externally connected course receivers, Function check of RoT .....	112
<b>4</b>	<b>Fuses, jumper, LED's, buttons and plugs .....</b>	<b>115</b>
<b>5</b>	<b>DIP SWITCH settings .....</b>	<b>117</b>
5.1	Overview of functions of all DIP switch settings .....	118
5.1.1	Adjustments of parameters (in ascending order of function) .....	122
5.1.2	Adjustments of parameters (in ascending order of their appearance) .....	124
5.1.3	7 segment displays and their meaning .....	126
5.1.4	Functional description of DIP switch settings (for general use) ...	127
5.1.5	Functional description of DIP switch settings (SEC) .....	163
<b>6</b>	<b>Tasks to be performed regularly .....</b>	<b>183</b>
6.1	Changing the supporting liquid and distilled water .....	183
6.1.1	Removing the outer sphere from the compass enclosure .....	183
6.1.1.1	Draining the supporting liquid and distilled water .....	185



# Installation and Service manual

## Compass STD 22

### Compass STD 22 Compact



Compass  
STD 22

<b>7</b>	<b>Error messages and warnings .....</b>	<b>188</b>
7.1	Error messages .....	188
7.2	Warnings .....	191
7.2.1	Warning 1 "Fan failure" .....	192
7.2.2	Warning 2 "Heater failure" .....	193
7.2.3	Warning 3 "Supporting liquid > 60°C" .....	193
7.2.4	Warning 4 "Supporting liquid level too low" .....	194
7.2.5	Warning 5 "Voltage cut-off" .....	194
<b>8</b>	<b>NMEA-Formats .....</b>	<b>195</b>

ET-Catalogue (Pages 1 to 4)

Annex 1-8 (PCB with component view and designations)

Drawings:

Gyro Compass Dimensional Drawing 110 D 233 HP005

Gyro Compass STD 22 Cable and Connection Diagram 110-233 HP009

Sheets 1 to 3

Gyro Compass STD 22, Cable and Connection Diagram (E10)

110-233.HP029

Sheets 1 to 3

Gyro Compass STD 22 Compact

Cable and Connection Diagram 110-233 HP010

Additional Output Box

Dimensional Drawing 146-103.HP005

Additional Output Box

Wiring Diagram 146-103.HP007

AC/DC Converter

Dimensional Drawing 121-062.HP005

Operator Unit Quick Settling

Dimensional Drawing 130 E 606 HP005

Gyro Compass STD 22, Wiring Diagram 110-233.HP008

Sheets 1+2


Terminal Strip PCB, Circuit Diagram 110-233. HP016

**Installation and Service manual**  
**Compass STD 22**  
**Compass STD 22 Compact**

---

intentionally left blank

**Installation and Service manual  
Compass STD 22  
Compass STD 22 Compact**



Compass  
STD 22

**Raytheon**

**Raytheon Marine GmbH**  
High Seas Products  
Postfach 11 66  
D - 24100 Kiel  
Germany  
Tel +49-431-30 19-0  
Fax +49-431-30 19-291  
Email [info@raykiel.com](mailto:info@raykiel.com)  
[www.raytheon-marine.de](http://www.raytheon-marine.de)

**Konformitätserklärung des Herstellers**

Artikel Nr. 10 der Richtlinie 96/98/EG

**Manufacturer's Declaration of Conformity**

Article 10 – EC-Directive 96/98/EC

Hiermit wird bestätigt, daß das nachfolgend aufgeführte Produkt dem baumustergeprüften Produkt entspricht und gemäß Qualitätssicherungs-Modul D erfolgreich getestet wurde.

This is to certify that the product identified below has been manufactured in accordance with type approved units and has been successfully tested according to the Quality Assurance Module D.

Produktbezeichnung/  
Product Designation:

**Gyrocompass System /  
Gyrocompass System for High Speed Craft**

Typ / Type:

**Anschütz Gyro Compass Standard 22**  
(Systemkomponenten siehe Anlage/  
system components see attached)

Baumusterprüfung durch/  
Type Examination by:

GL Luxembourg  
26, place de la Gare  
L-1616 Luxembourg

Benannte Stelle Nr. 0801/  
Notified Body No. 0801

Baumusterprüfbescheinigungen Nr./ 47778 - 03 Lux, 47779 - 03 Lux  
Type Examination Certificates No.:

Angewendete Normen  
und Richtlinien/-  
Applied Standards and  
Directives:

Directive 96/98EC / Additional Directive 2001/53/EC  
Additional Directive 2002/75/EC  
EN 61162-1, EN 60945, IEC 60945, IEC 61162-1  
EN ISO 8728, ISO 16328  
IMO Resolutions A.424 (XI), A.694 (17), A.813 (19)  
A.821(19), MSC.64 (67) Annex 4, MSC.97(73)

Diese Erklärung wird verantwortlich für den Hersteller abgegeben durch/  
This declaration has been made in the name of the manufacturer by:

Kiel, den 18.03.2005

Raytheon Marine GmbH  
Head of Quality Management

Raytheon Marine GmbH  
Head of Qualification / Certification

  
Martin Wloka

  
Günther Krappe

EG-BPB/GL-47778-03Lux/47779-03Lux

KE0029DE\_050318.doc

Seite 1 von 2

# Installation and Service manual

## Compass STD 22

### Compass STD 22 Compact



#### Raytheon Marine GmbH

High Seas Products  
Postfach 11 66  
D - 24100 Kiel  
Germany  
Tel +49-4 31-30 19-0  
Fax +49-431-30 19-291  
Email: info@raykiel.com  
www.raytheon-marine.de

#### Konformitätserklärung des Herstellers

Artikel Nr. 10 der Richtlinie 96/98/EG

#### Manufacturer's Declaration of Conformity

Article 10 – EC-Directive 96/98/EC

#### Anschütz Gyro Compass Standard 22

Auflistung der Systemkomponenten / Listing of the system components:

Gyro Compass	110-233	
Gyrosphere	111-006	
Operator unit	130-613	
Distribution unit	138-118	
Repeater Compass	133 - 560	
Additional output box	146-103 NG001	1
AC DC Converter	121-062	1
Multi Display	AN 300	1
Change-over box	138 – 119	2
Change-over switch	124 – 187	2


<sup>1</sup> Optional

<sup>2</sup> Optional ( For the redundant STD 22 compass system with automatic change-over function)

Additional configurations:

The master compass STANDARD 22 type 110-233 with Gyrosphere type 111-006.E001 may be also used with the system configurations and equipment listed in EC-type approval certificate No. 6297/0032/00 (STANDARD 20) from Bundesamt für Seeschifffahrt und Hydrographie (BSH) Germany, and listed in EC-type approval certificate No. 17063-00 GL Lux (GYROSTAR II) from GL Luxembourg.

**Installation and Service manual  
Compass STD 22  
Compass STD 22 Compact**



Compass  
STD 22

**Raytheon**

Raytheon Anschütz GmbH  
Postfach 11 66  
D - 24106 Kiel  
Germany  
Tel +49-431-30 10-0  
Fax +49-431-30 10-291  
Email: info@rayr.com  
www.raytheon-marine.de

**Manufacturer's Declaration of Conformity**

Article 10 – EC-Directive 96/98/EC.

As amended by Directive 2001/53/EC , 2002/75/EC.

This is to certify that the product identified below has been manufactured in accordance with type approved units and has been successfully tested according to the Quality Assurance Module D.

Product Designation: **Gyrocompass System /  
Gyrocompass System for High Speed Craft /  
Gyrocompass System as Rate- of-turn Indicator**

Type: **Anschütz Gyro Compass Standard 22**  
system components see attached)

Type Examination by: GL Luxembourg  
26, place de la Gare  
L-1616 Luxembourg  
Notified Body No. 0801

Type Examination Certificates No.: 47778 - 03 Lux, 47779 - 03 Lux

Applied Standards and Directives: Directive 96/98EC / Additional Directive 2001/53/EC  
Additional Directive 2002/75/EC  
EN 61162-1, EN 60945, IEC 60945, IEC 61162-1  
EN ISO 8728, ISO 16328  
IMO Resolutions A.424 (XI), A.694 (17), A.813 (19)  
A.821(19), MSC.64 (67) Annex 4, MSC.97(73)  
A. 526 (13) (Rate-of-turn indicator see remark page 2)

This declaration has been made in the name of the manufacturer by:

Kiel, den 15.02.2006

Raytheon Marine GmbH  
Head of Quality Management

  
Martin Wloka

Raytheon Marine GmbH  
Quality Mangement

  
Günther Krapp

# Installation and Service manual

## Compass STD 22

### Compass STD 22 Compact



Raytheon Anschütz GmbH  
Postfach 11 00  
D - 24193 Kiel  
Germany  
Tel +49-431-92 19 0  
Fax +49-431-35 19-291  
Email: info@ra-kis.com  
www.raytheon-marine.de

#### Manufacturer's Declaration of Conformity

Article 10 – EC-Directive 96/98/EC.

As amended by Directive 2001/53/EC , 2002/75/EC.

#### Anschütz Gyro Compass Standard 22

Auflistung der Systemkomponenten / Listing of the system components:

Gyro Compass	110-233	
Gyrosphere	111-006	
Operator unit	130-613	
Distribution unit	138-118	
Additional output box	146-103 NG001	<sup>1</sup>
AC DC Converter	121-062	<sup>1</sup>

<sup>1</sup> Optional

Additional configurations:

The master compass STANDARD 22 type 110-233 with Gyrosphere type 111-006.E001 may be also used with the system configurations and equipment listed in EC-type approval certificate No. 6297/0032/00 (STANDARD 20) from Bundesamt für Seeschifffahrt und Hydrographie (BSH) Germany, and listed in EC-type approval certificate No. 17063-00 GL Lux (GYROSTAR II) from GL Luxembourg.

#### Remark

The Raytheon Anschütz Gyro Compass Standard 22 system fulfils the accuracy requirements for a rate –of-turn Indicator according to IMO Resolution A.526 (13)- Rate- of- turn Indicator.

The system consists of.

- Gyro Compass Standard 22 (drawing No.110 - 223)
- Distribution Unit (drawing No.138 - 118)
- Operator Unit (drawing No.130 - 613)

The rate- of- turn output has to be taken from the Distribution Unit (drawing No. 138-118) to comply with IMO Resolution A.526(13)- Rate- of- turn Indicator.

---

## Safety notes

### Caution:



- Maintenance and repair work should be carried out only by trained and qualified staff who are well versed in national safety regulations.
- After the gyro compass has been switched off it is necessary to wait at least 15 minutes before accessing the interior of the gyro compass. Otherwise the sphere could be damaged!
- Never switch off the compass at sea, the sphere could be damaged.



- It is advisable to leave the gyro compass switched on when lying in port for periods of up to one week.
- If warnings occur, the operation of the gyro equipment is not restricted. If the cause of the problem is rectified quickly, it is possible to prevent the equipment from breaking down. Please inform the authorised service staff (via the hotline). Refer to the service manual as appropriate.
- When error messages appear, the heading is no longer displayed on the compass; the heading is not followed up on a connected course receiver. The compass must be repaired by well trained staff.



Please note that all ship's of 500 gross tonnage and upwards according to SOLAS regulations must be equipped with a gyro compass.

The gyro compass must be operational. For this reason it is not allowed to have a switched-off gyro during voyages.

A switched-off gyro compass during voyages could cause damage to the gyrosphere.

# Installation and Service manual

## Compass STD 22

### Compass STD 22 Compact

---



Caused by technical progress the PC-Boards of the Gyro Compass are changed.  
Due to that some pictures and/or procedures have been changed.  
Respective changes are marked with "E10".



The AC supply voltage (ships mains) may drop out.  
This leads to a restart of the gyrocompass and a new settling stage.  
The heading information during this settling stage has a reduced accuracy.  
Therefore a continuously supply with 24VDC should be guaranteed.





---

**1**

**General information**

The STD 22 Compact Compass and the STD 22 Compass are identical gyro compasses.


The difference between the two gyro compasses is that the STD 22 Gyro Compass can be operated via a CAN bus system with an Operator Unit and a Distribution Unit. In the case of the STD 22 Compact Gyro Compass, the CAN bus is not enabled.

The following diagrams provide an overview of the possible applications of the STD 22 Compact and STD 22 Gyro Compasses.

# Installation and Service manual

## Compass STD 22

### Compass STD 22 Compact



## STD 22 Compact Gyro Compass


# Installation and Service manual

## Compass STD 22

### Compass STD 22 Compact




Compass  
STD 22



# Installation and Service manual

## Compass STD 22

### Compass STD 22 Compact




# Installation and Service manual

## Compass STD 22

### Compass STD 22 Compact



Compass  
STD 22




## STD 22 GGM Gyro Compass System\*

\*(GGM = Gyro/Gyro/Magnet)

# Installation and Service manual

## Compass STD 22

### Compass STD 22 Compact




# Installation and Service manual

## Compass STD 22

### Compass STD 22 Compact




Compass  
STD 22



# Installation and Service manual

## Compass STD 22

### Compass STD 22 Compact






# Installation and Service manual

## Compass STD 22

### Compass STD 22 Compact




Compass  
STD 22



# Installation and Service manual

## Compass STD 22

### Compass STD 22 Compact



## 1.1 CAN bus (CAN = Controller Area Network)

(CAN = Controller Area Network)




Figure1 : Principle of CAN bus

**Installation and Service manual**  
**Compass STD 22**  
**Compass STD 22 Compact**

---

intentionally left blank



---

## 2 Preparing to install the STD 22 Compact Gyro Compass

To ensure that the STD 22 Compact Gyro Compass is installed and put into operation correctly, these instructions must be followed in the order in which they appear. It must not be installed or put into operation whilst at sea.

### 2.1 STD 22 Compact Compass – Scope of Supply

The scope of supply consists of:

- Compass (110-233)
  - Outer sphere
  - Distilled water
  - Supporting liquid
  - Gyrosphere (111-006)
- User manual for the STD 22 Compass
- Installation and service manual for the STD 22 Compass
- Tools and spare parts pack
  - Sealing rings
  - Suction cup
  - Filling device
  - Injector

Optional:

- AC/DC converter (121-062)
- Quick Settling Operator Unit (130-606)
  
- Additional Output Box (146-103)  
(Interface extension STEP/SSC)

## Installation and Service manual Compass STD 22 Compact

---

### 2.2 General information concerning installation of the STD 22 Compact Compass

When fitting components, observe the following spacing:

Fit the compass enclosure so that the display can be viewed from above and the cover of the enclosure can be removed (see also Dimensional Drawing 110-233.HP005).

To ensure fault-free operation of the STD 22Compact Compass, it is essential to follow these directions, safety notes and installation instructions.

Instructions relating to cable cross-sections and earth connections must be adhered to.

The tools which are specified for installing the compass must be used.


Only original parts or parts approved by the manufacturer may be used in connection with the STD 22 Compact Compass.

See also Cable Connection Diagram 110-233 HP010 for the STD 22 Compact Compass.

Gyro Compass should not be installed in oil-containing ambient air, not in surrounding vibration and should installed on a vibration-free platform.

Gyro compass should be installed on the ships' line (vertical and horizontal).

The installation of the power supply (AC/DC-Converter) should only be performed by an experienced electrician.



The 24 VDC supply voltage should be engineered as a low-security-voltage according to SELV.

## 2.3 Creating cable connections

### 2.3.1 General information concerning on-board wiring

The cables which are to be connected to the STD 22 Compact Gyro Compass are led through one of the cable entries at the top of the compass enclosure and fixed in the cable entry with a cable clip suitable for the size of the cable.

The cable entries are supplied with the compass.



**Caution:**

Ensure that cables are not live before creating cable connections.

It is vitally important to ensure that all cables are free of voltage; where appropriate, carry out voltage measurements beforehand and/or disconnect the relevant distributor from the power supply.

To ensure that the compass functions correctly, it is essential to adhere to the following sequence when creating cable connections.

- Strip the cable over a length of approximately 180 mm (depending on the distance of the cable entry from the terminal). Be careful not to damage the screening.
- Trim the screening so as to leave approximately 15 mm on the cable.




Figure 2: Requirements for stripping the connecting cable

## Installation and Service manual Compass STD 22 Compact

---

- Push the components of the screw fastening over the cable.  
It is essential to follow the sequence (as shown in Figure 3).
- Check the cone and the mating piece of the earthing insert for corrosion and if necessary remove corrosion with an emery cloth.
- Push the mating piece of the earthing insert to the end of the cable sheath.
- Push the cone inside the screening and against the mating piece. Ensure that the screening is evenly distributed over the cone (see Figure 3).





Figure 3: Creating the cable connection



Supply voltage    Coursebus    CAN bus    Function "Quick Settling"



Note: The connection cables should be shortened in that way, that they could be led to the terminal boards without mechanical stress.  
Too long connection cables will lead to EMC problems.  
For the cable-type see respective drawing at the appendix.

Figure 4: Example of a proper cable connection

- Place the earthing insert, strain relief and washer in the cable entry; fit and tighten the counter nut.
- Strip the cable conductors to a length of about 1.5 cm, lightly twist them and fit cable end sleeves. Connect the cable conductors according to respective drawings and tables. Tighten the terminal screws – check the connection is secure by pulling gently.

## Installation and Service manual

### Compass STD 22 Compact

---

#### 2.3.1.1 General information about creating an earth connection

The following instructions relating to the creation of cable connections must be adhered to in order to comply with the stringent EMC requirements.  
The specified cable types must be used.



It is vital to ensure that these connections have **a common** reference to ship's earth.  
Additional components (optional features) must likewise be connected to the common earth.




Figure 5: Creating an earth connection

Each earth connection must be made as shown in Figure 5.

The earth cable, to which a cable lug is attached, must have a cross-section of at least 1.5 mm<sup>2</sup>.

The cable lug is mounted between a pair of toothed washers.

Earth connections must be free of all corrosion; they must be screwed tight.

## 2.4 Installing the compass and putting it into operation

### 2.4.1 Remove the transportation support with outer sphere, supporting liquid and distilled water.

- Undo the 4 screws (Figure 6 /1) at the top and bottom of the enclosure door, lift out the door and detach the earthing strip (Figure 6/2) on the inside of the door.
- Carefully remove the transport packaging with the outer sphere and the two bottles containing supporting liquid and distilled water from the compass enclosure.
- Take the outer sphere out of the transport packaging and place it on the base plate; the outer sphere must be secured to prevent it from tilting





Figure 6: Principle of dismantling the enclosure door

## Installation and Service manual Compass STD 22 Compact

### 2.4.1.1 Assembling the compass enclosure

**Note:** It is not necessary to install the compass enclosure with reference to the ship (e.g. in the ship's forward direction). It can be installed in whatever position is most convenient for servicing and operation.

The installation described below is to be regarded as the maker's recommendation.




Figure 7: Installation of the compass enclosure



The compass enclosure must be installed in such a way that the following requirements are met:

- The 8 supports must all stand on a flat, firm surface.  
If necessary, the user should himself create an intermediate plate (marine quality hardwood or metal) suited to the local conditions.
- The compass enclosure must be screwed to the intermediate plate in a sea-resistant fashion.
- The intermediate plate must also be screwed to the ship's body in a sea-resistant fashion; this fastening is the responsibility of the user of the STD 22 Compact himself.
- The compass enclosure must be mounted so that the digital display can be seen easily after installation, the door of the compass enclosure can be opened and closed easily and the cover of the compass enclosure can be detached.
- The fastenings of the compass enclosure are indicated in the dimensional drawing "Gyro Compass" (110 D 233 HP005) in the appendix to this manual.

The compass enclosure is fastened to the intermediate plate with 6 screws

- for woodscrews  $\varnothing 11$  x length depending on the thickness of the intermediate plate
- for metal screws M10 x length depending on the thickness of the intermediate plate.

The compass enclosure can also be mounted directly on a flat metal surface; in this case, suitable stud bolts (M10) must be welded on; alternatively the compass housing can be fastened on the underlying surface with threaded holes and screws M10-A4.

## Installation and Service manual Compass STD 22 Compact




Figure 8: Horizontal alignment for installation of the compass enclosure

### 2.4.1.2 Installation of the gyrosphere

Special tool required:  
Suction cup

Installation procedure:

- Undo the six screws (Figure 9/1) fastening the upper and lower halves of the outer sphere (Figure 9/2 and 3).
- Remove plug B3 (Figure 9/4) from the plug plate.




Figure 9: Outer sphere

- Remove the upper half of the outer sphere (Figure 9/2).  
Take the gyrosphere (Figure 10/2) out of the transportation box and carefully insert it using the suction cup (Figure 10/3) in the lower outer sphere (see Figure 10).

## Installation and Service manual Compass STD 22 Compact




Figure 10: Principle of separating the upper and lower halves of the outer sphere  
– inserting the gyrosphere

- Replace the upper half of the outer sphere on the lower half.



Check that there is a proper seal between the two halves of the outer sphere (see Figure 10/1)!

- Retighten the six screws (see Figure 9/1).
- Insert plug B3 (Figure 9/4) again.



### 2.4.1.3

#### Filling with distilled water and supporting liquid.

(see Figure 11)

- Undo the three plastic screws (Figure 11/1-3) on the upper outer sphere




Figure 11: Filling with liquids

- Fit the supplied filling device on the distilled water bottle.
- Pour in all the distilled water (230 cm<sup>3</sup>) (look for the identifying label on the outer sphere).
- Re-close the distilled water filling opening with the screw, check that it is properly sealed.
- Remove the filling device from the distilled water bottle and attach it to the supporting liquid bottle.



## Installation and Service manual Compass STD 22 Compact

---

- Pour approximately 840 cm<sup>3</sup> of supporting liquid in the appropriate filling opening (look for the identifying label).

The supporting liquid must be at room temperature (over 25° C) and the measuring cone should fill half the measuring range (diameter).

The following photograph shows the measuring cone for the liquid level.



This picture only shows the situation at the start of operation (after filling for the first time or after changing the supporting liquid -> cold supporting liquid); during operation, the dark circle in the measuring cone is smaller.

Figure 12: Measuring cone for supporting liquid level

- Discard any unused supporting liquid; no special measures are needed for disposal.
- Re-close the filling opening for supporting liquid, check that it is properly sealed.
- Re-insert the ventilation screw, check that it is properly sealed.

#### 2.4.1.4

#### Inserting the outer sphere in the compass enclosure

(see Figure 13)

- Carefully insert the gyrosphere in the compass enclosure:



Pay attention to the two locking pins on the closure.

- Using both hands, hold the outer sphere and guide it under the snap closures (Figure 13/1) on the pendulum joint (Figure 13/2).




Figure 13: Principle of inserting the outer sphere in the compass enclosure

## **Installation and Service manual Compass STD 22 Compact**

---


- Using the thumbs, press down and engage two snap closures (Figure 13/1).
- Turn the outer sphere through 90° and repeat the process with the two other snap closures. The outer sphere is now fastened to the pendulum joint
- Guide the cable around the outer sphere and attach the plugs to the small PCB of the outer sphere, tighten the fastening screws

## 2.5 Creating cable connections and plug connections

### 2.5.1 Overview of plug connections and fuses on PCB's

(see also section 4 for more information about LED's, plugs, push buttons and jumper)

Power Supply PCB 110-233.102      Connection PCB NB05-356      Sensor PCB 110-233.X08



Power Supply PCB 110-233.X12      Connection PCB 110-233.X13      Sensor PCB 110-233.X11

E10




Figure 14: Arrangement of PCB's in the STD 22 Compact Compass (cover removed)

## Installation and Service manual Compass STD 22 Compact




Figure 15: Arrangement of plugs, terminal boards and fuses

1	Terminal L1	Power supply (24VDC)	
2	Fuse E1 (T10A)	Power supply (24VDC)	
3	Plug B2	Output Channel1 Course Bus/NMEA	
4	Fuse E2 (T1A)	Channel1 +24V	
5	Plug B3	Output Channel2 Course Bus/NMEA	
6	Fuse E3 (T1A)	Channel2 +24V	
7	Plug B4	Output Course Bus	
8	Fuse E4 (T1A)	Course Bus +24V	
9	Plug B5	Input (+24V/Set QS/ Pulse Log/Pulse Log Dir./NMEA Log/GPS-receiver)	
10	Plug B6	Output (QS/SEC/System/Available)	
11	Plug B7	CAN1 bus	
12	Plug B8	CAN2 bus	
	Switch B32	for CAN1 bus terminating resistor	E10
13	Terminal Board L2	24V connection to Power Supply PCB	
	Plug B8	CAN2 bus	E10
14	Jumper B31	for the CAN2 bus terminating resistor	
	Switch B31	for the CAN2 bus terminating resistor	E10
15	Jumper B32	for the CAN1 bus terminating resistor	
	Terminal Board L2	24V connection to Power Supply PCB	E10

### 2.5.1.1 Connecting the course receiver in the STD 22 Compact Gyro Compass

(see also Cable and Connection Diagram 110-233.HP010)

Three outputs are provided on the Connection PCB of the gyro compass for course data:

Output 1 (also Channel 1) for NMEA or Course bus (RS 422)

Output 2 (also Channel 2) for NMEA or Course bus (RS 422)

Output 3 for Course bus only (RS 422)

The setting of output data for Output 1 and Output 2 is described in section 2.6.4.6




Figure 16: Course receiver connections

## Installation and Service manual

### Compass STD 22 Compact

---

Course receivers should be connected with a screened cable having up to 6 poles (appr. 0.5mm<sup>2</sup> per conductor).

Output 1 (Channel 1)	Plug B2	Connection 3 Connection 4 Connection 5 Connection 1 Connection 2 Connection 6	Tx+ Tx- Tx GND 24VDC 0V ⏚
Output 2 (Channel 2)	Plug B3	Connection 3 Connection 4 Connection 5 Connection 1 Connection 2 Connection 6	Tx+ Tx- Tx GND 24VDC 0V ⏚
Output 3	Plug B4	Connection 3 Connection 4 Connection 5 Connection 1 Connection 2 Connection 6	Tx+ Tx- Tx GND 24VDC 0V ⏚



### 2.5.1.2 Connecting status and control signal outputs in the STD 22 Compact Gyro Compass

The following status signals and signals for external signalling can be tapped from the Connection PCB of the Gyro compass.

AVAILABLE	compass data available
SYSTEM	general alarm, system error
QS	Quick Settling status information
SEC	Speed Error Correction status information

A LED is assigned to each of these connections on the Connection PCB.

AVAILABLE	LED lights up green when the gyro compass is ready for use (4 hours after the power supply is switched on QS activated –after appr. 1 h)
SYSTEM	LED lights up red if a fault occurs in the gyro compass
QS	LED flashes green if Quick Settling is possible. LED lights up green during Quick Settling. LED goes off when Quick Settling is completed.
SEC	LED goes off if Speed Error Correction is faulty or is impossible because Pulse Log/GPS-receiver information is unavailable LED lights up green if Speed Error Correction is OK.




Figure 17: Connection for status and control signals

## Installation and Service manual

### Compass STD 22 Compact

---

AVAILABLE	Plug B6	Connection 7 Connection 8	
SYSTEM	Plug B6	Connection 5 Connection 6	
SEC	Plug B6	Connection 1 Connection 2	
QS	Plug B6	Connection 3 Connection 4	see also section 2.6.3.1



### **2.5.1.3 Connecting signal inputs for QS and SEC in the STD 22 Compact gyro compass**

Signal inputs for enabling the Quick Settling function and Pulse Log/GPS-receiver information for Speed Error Correction (SEC) can be connected on the Connection PCB.

The following inputs are available:

SET QS INPUT	for enabling the QS function (via the Quick Settling operator unit)
PULSLOG INPUT	for entering speed information from Pulse Log for the SEC
PULSLOG DIR.INPUT	for entering the direction (forwards/reverse) of the speed information from a Pulse Log for SEC
GPS INPUT	for entering position information and where appropriate the speed input from GPS-receiver for the SEC
NMEA LOG INPUT	for entering speed information from a Log with NMEA format for the SEC

To operate the Speed Error Correction it is necessary to connect a Pulse Log or a GPS-receiver.

Setting the source of the speed sensor for Speed Error Correction is explained in section 2.6.4.7 .

The connecting cable cross section should not be less than 0.5mm<sup>2</sup>  
(see also drawings: Cable and Connection Diagram 110-233.HP009 ,HP010or HP029).

## Installation and Service manual Compass STD 22 Compact

---




Figure 18: Connection of signal inputs for QS and SEC

SET QS INPUT  see also section 2.6.3.1	Plug B5	Terminal 2 Terminal 3	
PULSLOG INPUT	Plug B5	Terminal 4 Terminal 5	
PULSLOG DIR. INPUT	Plug B5	Terminal 6 Terminal 7	
GPS-receiver INPUT	Plug B5	Terminal 12 Terminal 11	Rx+ Rx-
NMEA LOG INPUT	Plug B5	Terminal 10 Terminal 9	Rx+ Rx-

## 2.5.1.4 Connecting the power supply cable

The STD 22 Compact Compass operates at 24VDC.

This voltage can be generated directly using an AC/DC converter (see section 2.6.2) or fed directly from the 24VDC ship's mains to the compass.




Figure 19: Connection of the +24VDC power supply

The 3-core cable that is used should have a conductor cross-section of  $\geq 2.5\text{mm}^2$

At terminal L1 (see Figure 19) connect a power supply of  
with +24VDC at terminal 1  
0V at terminal 2

## Installation and Service manual

### Compass STD 22 Compact

---

#### 2.5.1.5 Connecting the compass to earth




Figure 20: Connection of compass to earth

An earth connection (ship's earth) must be made using the earthing shown in Figure 20. The earth connection must have a common reference to the other components!

## 2.6 Installation and commissioning of optional features

### 2.6.1 Installation and commissioning of the Additional Output Box 143-103




Figure 21: Additional Output Box 146-103 (device open)

Install the Additional Output Box as shown in dimensional drawing 146-103HP005. Ensure that it is properly connected to the ship's earth.

#### Connecting the power supply:

24VDC at terminal L1, terminals 3 (+) and 4(-) of the mains filter.

The power supply can be taken directly from the ship's supply (24VDC) or from terminals 6, 7, 8 or 9 (+) and 11, 12, 13 or 14 (-) of the AC/DC-Converters (if supplied) (see also section 2.6.2).

## Installation and Service manual Compass STD 22 Compact

---

### Making a signal connection:

(see also Cable and Connection Diagram 110-233.HP010  
and wiring diagram 146-103.HP007)

A 2-core, screened cable with conductor cross-section  $\geq 1\text{mm}^2$  is used to create a connection between:

Plug B4 on Connection PCB of the STD 22 Compact Gyro Compass

Terminal 3 (TX+) und 4 (TX-)

and

terminal board L4, terminals 1 (Rx-) und 2 (RX+) of the Step/SSC Modules in the Additional Output Box (siehe Figure 21).




Figure 22: Connection of Course Bus in the STD 22 Compact Gyro Compass

The signal outputs from the Additional Output Box are created as shown in the drawings

- Cable and Connection Diagram 110-233.HP010


and

- Wiring diagram 146-103.HP007.



## 2.6.2

### Installation and commissioning of the AC/DC Converters 121-062




One cable inlet has to be left blank between AC In and DC out!!

Figure 23: AC/DC Converter

**NOTE:** Detailed dimensions can be found in drawing 121 D 062.HP005.  
For connecting the AC/DC Converter, see also Cable and Connection Diagram STD 22 Compact 11-233.HP010.  
and connection diagram on the cover.

Fasten the AC/DC Converter on a firm surface with 4 screws.

The installation of the power supply (AC/DC-Converter) should only be performed by an experienced electrician.



The 24 VDC supply voltage should be engineered as a low-security-voltage according to SELV.

## Installation and Service manual Compass STD 22 Compact

---



**Caution:**

Before connecting the cable, the AC/DC Converter must be disconnected from the power supply and safeguarded against reconnecting until it is set into operation.

Take care to ensure that a common earth is used for all components of the STD 22or STD 22 Compact Gyro Compass.

To connect the AC/DC Converter to the ship's mains, use a cable which meets following minimum requirements:

2 x 1,5mm<sup>2</sup> (with screen, single-side connected to the housing)




Figure 24: AC/DC Converter (Terminal board)



To connect the cables to the terminal board, the plastic cover has to be pulled off from the terminal board.

Cables should not be lengthened too long, to prevent a short circuit to a neighbour terminal by an inadvertently loosening.

Additionally the cable should be fixed (as shown in Figure 24) with tie wraps and self adhesive tie mounts. After that the plastic cover has to be pulled on the terminal board.

The ship's electrical supply (  $AC_{IN} = 115...230V, 50/60Hz$  ) must be connected to the terminal board at terminals **17** and **19** or **18** und **20** see Figure 24.

To connect the AC/DC Converter with a 24VDC load, use cables which meet the following minimum requirements:

- 2 x 2,5mm<sup>2</sup> (with screen) gyro compass
- 2 x 0,5mm<sup>2</sup> (with screen) Additional Output Box

The output voltage (24VDC supply) is taken from the terminals:

**6**(24VDC) and **11**(0V) or

**7**(24VDC) and **12**(0V) or

**8**(24VDC) and **13**(0V) or

**9**(24VDC) and **14**(0V) .

Before connecting the 24VDC load to the AC/DC Converter, the output voltage must be measured. It must be within the tolerance range of 18 VDC to 36 VDC.

After the ship's mains is switched on, the AC/DC Converter is supplied at 24VDC.

The AC/DC Converter does not need to be switched on separately.

## Installation and Service manual Compass STD 22 Compact

---

### 2.6.3 Installation and commissioning of the Operator Unit Quick Settling (QS) 130-606




Figure 25: Operator Unit Quick-Settling (front view)

## 2.6.3.1 Installing the Operator Unit Quick-Settling

NOTE: Detailed dimensions can be found in drawing 130 E 606.HP005.  
For connecting the Operator Unit Quick Settling, see also Cable and Connection diagram STD 22 Compact 110-233.HP010.

The Operator Unit Quick Settling is designed for desk mounting.

When installing ensure there is sufficient clearance underneath the operator unit (minimum 32mm, see drilling scheme)

The Operator Unit Quick Settling can be fixed in a panel up to 17 mm thick.




Figure 26: Operator Unit Quick Settling (rear view)

The Operator Unit Quick Settling should be connected to the compass by a cable which meets the following minimum requirements (see also Figure 27).

- 4 x 0,5<sup>2</sup>mm with screen
- 1 x 0,5<sup>2</sup>mm (for jumper to be installed)

The screening of the cable is connected to earth in the Operator Unit Quick Settling (Figure 26/2).

The cable is fastened with the strain relief (cable grip) (Figure 26/1) in the Operator Unit Quick-Settling.

## Installation and Service manual Compass STD 22 Compact

---




Figure 27: Connecting the Operator Unit Quick Settling in the STD22 Compact Gyro Compass

Operator Unit Quick-Settling	STD 22 Compact Gyro Compass
Terminal L1, connection 1	Plug B5, connection 3
Terminal L1, connection 2	Plug B5, connection 2
Terminal L1, connection 3	Plug B6, connection 2
STD 22 Compact Gyro Compass: jumper from plug B6, Pin 1 to plug B5, Pin 1 (24VDC)	

## 2.6.4 Switching on, settling and adjustment

### 2.6.4.1 Switching on the compass

The compass unit switches on when the power supply is activated on the main control panel.

### 2.6.4.2 Checks on the compass

Measuring the compass power supply voltage (on the compass).

This voltage must be within the tolerance range (18 VDC to 36 VDC).

Terminal board L1  
Power supply connection




Figure 28: Measuring the compass power supply voltage

Terminal board L1    terminal 1 +24VDC

Terminal board L1    terminal 2 0V

**NOTE:**    The absolute lower limit for the power supply voltage is 18VDC, the absolute upper limit is 36VDC!  
When connecting cables, ensure that these values are adhered to.

# Installation and Service manual

## Compass STD 22 Compact

Checking the DIP switch settings on the compass (see Figure 29):





Figure 29: Checks on the compass before setting into operation

All DIP switches in the “ON” position.





## 2.6.4.3

### Setting the STD 22 Compact Compass into operation

The compass goes into heating stage for the first 30 minutes (this period will vary depending on the temperature of the supporting liquid), during which time the course output of the compass should not be used, and the letter “h” is displayed as the leading sign on the digital display (see Figure 30).

During the settling in stage (for 4 hours after switching on), the course output of the compass may be used; **however, the deviation from the actual course may still be considerable (as well as it is at all connected course receivers).**

During this period, an additional dit appears in the digital display of the compass (see Figure 31).

(The “Quick Settling” option reduces the settling in stage to appr. 1 hour).

After 4 hours from switching on, the compass course may be used.

4 hours after switching on, the compass has a accuracy of  $<2^\circ$ .

After appr. 5 hours (after switching on), the compass has an accuracy of  $0,1^\circ \times 1/\cos$  latitude.

### on the compass




Figure 30: Indications on the compass during the heating stage

## Installation and Service manual Compass STD 22 Compact

---




Figure 31: Indications on the compass during the settling stage

## 2.6.4.4 Setting the compass zero (reference course)

Once the compass has been installed, it must be aligned according to its installation location. The compass zero is set using DIP switch B 37 and buttons B 38 and B 39.

**The compass must have been in operation for at least 5 hours before the compass zero is set.**




Figure 32: DIP switch B37 and buttons B38/B39

The reference course to be set is determined from the ship's fore-and-aft line (e.g. take a bearing or obtain the pier course from the sea chart).

This reference course is entered according to the following procedure.

- Set DIP switch B37 "1" to the "OFF" position.  
The digital indicator is now indicating "ALeR" = Alignment Error
- Press button B38 or button B39 until the heading you require is displayed (B38 changes the value downwards and B39 changes it upwards).
- If you hold down the button the speed at which it changes will increase.  
Set DIP switch B37 "1" to the "ON" position. This saves the set value in the compass.
- After the reference course has been set, read the alignment error (see next section). (See also Figure 33)

# Installation and Service manual Compass STD 22 Compact





Figure 33: Procedure for setting the compass zero

## 2.6.4.5 Reading the alignment error

The alignment error must be entered in the table provided for that purpose on the inside of the cover.

Alignment Error	
123.4	

Figure 34: Table at compass cover (inner side)



DIP-switch "8" in "OFF" position.

**NOTE:** It is essential to enter this value, because the alignment error will be needed if the sensor electronics are replaced, in order to determine the reference course for the new PCB.

DIP switch "8" in "ON" position.

The STD 22 Compass is ready for use.

Replace the cover of the compass and screw it tight.

## Installation and Service manual Compass STD 22 Compact

### 2.6.4.6 Setting Channel 1 and Channel 2

Unscrew and remove the cover of the compass housing.








Figure 35: DIP switch B37 and buttons B38/B39






Initial status:





Indications	Comments, Information
Setting the interface for Channel 1 and Channel 2.  HSEr = Heading serial (Course Bus) nMEA = NMEA 0183  The “flashing” setting is accepted.	
Switch B37 (DIP switch)    Chan 1	    Continued on next page

# Installation and Service manual Compass STD 22 Compact

Indications	Comments, Information
from last page	<div> <div> <div>B38</div> <div>  <div>3X</div> </div> </div> <div> <div>⇒</div> <div> <div>Chn2</div> </div> </div> </div> <div> <div> <div>B38</div> <div>  <div>4X</div> </div> </div> <div> <div>⇒</div> <div> <div>HSEr</div> <div>↓</div> <div> <div>↗</div> <div> <div> <div>↖</div> <div>HSEr</div> <div>↗</div> </div> </div> <div>↘</div> </div> </div> </div> <div> <div> <div>B39</div> <div>  </div> </div> <div> <div>↔</div> <div> <div> <div>↖</div> <div>HSEr</div> <div>↗</div> </div> </div> </div> </div> <div> <div> <div>B38</div> <div>  <div>5X</div> </div> </div> <div> <div>⇒</div> <div> <div>nNEA</div> <div>↓</div> <div> <div>↗</div> <div> <div> <div>↖</div> <div>nNEA</div> <div>↗</div> </div> </div> <div>↘</div> </div> </div> </div> <div> <div> <div>B39</div> <div>  </div> </div> <div> <div>↔</div> <div> <div> <div>↖</div> <div>nNEA</div> <div>↗</div> </div> </div> </div> </div> </div></div>
<div> <div>OPEN</div> <div> <div> <div> <div>1</div><div>2</div><div>3</div><div>4</div><div>5</div><div>6</div><div>7</div><div>8</div> </div> <div> <div> <div>OFF</div> <div>ON</div> </div> </div> </div> <div>⇒</div> <div> <div> <div>130.1</div> </div> <div>Display</div> </div> </div> </div>	



## 2.6.4.7

### Setting the information source for Speed Error Correction

Unscrew and remove the cover of the compass housing.



















Figure 36: DIP switch B37 and buttons B38/B39

Initial status:



## Installation and Service manual Compass STD 22 Compact

Indications	Comments, Information
<p>PLoG = Pulse-Log            PLd- = Puls-Log (polarity of the input interface inverted)            PLd = Puls-Log (polarity of the input interface <u>not</u> inverted)            uhu. = NMEA-Log (means water speed in general)            ubu.u. = means NMEA Log specified with speed through the water            ubu.G = means NMEA Log specified with speed over ground            GLoG = GPS-receiver-Speed</p> <p>The indications in the flashing display are selected.</p> <p>If the setting does not correspond to the connected device, the course correction relay responds and gives an appropriate warning only to devices which are connected to this alarm output.</p>	
<p>Switch B37 (DIP switch)</p>  <p>1 2 3 4 5 6 7 8</p> <p>↓</p> 	<div style="border-bottom: 1px dashed black; padding-bottom: 10px;"> <p>B38</p>  →  <p>↓</p> <p>B39</p>  →  </div> <div style="border-bottom: 1px dashed black; padding: 10px 0 10px 10px;"> <p>B38</p>  →  <p>↓</p> <p>B39</p>  →  </div> <div style="padding: 10px 0 10px 10px;"> <p>B38</p>  →  <p>↓</p> <p>B39</p>  →  </div>
continued on next page	



Indications	Comments, Information
	<div><div><div><div>B38</div><div>4X</div><div></div></div><div><div>B39</div><div>1X</div><div></div></div></div><div><div>→</div><div></div></div><div><div>↓</div></div><div><div>→</div><div></div></div></div> <div><div><div>B38</div><div>5X</div><div></div></div><div><div>B39</div><div>1X</div><div></div></div></div> <div><div>→</div><div></div></div> <div><div>↓</div></div> <div><div>→</div><div></div></div>

B38

6X

B39

1X




→

↓

→

continued on next page

Installation and Service manual  
Compass STD 22 Compact

Indications	Comments, Information
	
<p>OPEN</p> 	 <p>Display</p>

## 2.6.4.8 Adjustment of essential operating modes

Unscrew and remove the cover of the compass housing.





Figure 37: DIP switch B37 and buttons B38/B39

Initial status:



## Installation and Service manual Compass STD 22 Compact

Note: The procedure to adjust essential operating modes  
is described on the next four pages.

Set the repetition rate of the NMEA heading data output, the output with or without ROT (Rate of Turn), with or without oil residual error for the speed error correction and the setting of a connected Data Distribution Unit (**Data Distribution Unit is not for STD 22 Compact Gyro Compass**).

1 heading data transmission 1 telegram per second.

10 heading data transmission 10 telegrams per second.

HE.ro heading with ROT.

HE.-- heading only

SECY heading data incorporating Speed Error Correction

SECN heading data without Speed Error Correction

oELY Speed Error Correction with oil residual error (**recommended setting → SEC**)

oELN Speed Error Correction without oil residual error

ddUY with connected Data Distribution Unit (**only for STD 22**)

ddUn without Data Distribution Unit (**for STD 22 Compact absolute necessary**)



nMSY NMEA output with SEC

nMSn NMEA output without SEC

The indications in the flashing display are selected.

Switch B37 (DIP switch)

OPEN




continued on next page


# Installation and Service manual Compass STD 22 Compact




Compass  
STD 22




## Installation and Service manual Compass STD 22 Compact








## Installation and Service manual Compass STD 22 Compact



# Installation and Service manual Compass STD 22 Compact



Compass  
STD 22



## Installation and Service manual Compass STD 22 Compact

### 2.6.4.9 Function check on externally connected course receivers

Unscrew and remove the cover of the compass housing.






Figure 38: DIP switch B37 and button B38/B39

Initial status:




## Checking connected course receivers (course data)

Switch B 37 (DIP switch)



B 39




Outer sphere turns cw

130.0  
129.9  
129.8  
129.7  
129.6



B38





Outer sphere turns ccw

130.5  
130.4  
130.3  
130.2  
130.1



Start with push button B39 first.

OPEN



Display

## **Installation and Service manual Compass STD 22 Compact**

---

intentionally left blank



## 3 Preparing to install the STD 22 Gyro Compass

To ensure that the STD 22 Gyro Compass is installed and put into operation correctly, these instructions must be followed in the order in which they appear.  
It must not be installed or put into operation whilst at sea.

### 3.1 STD 22 Compass – Scope of Supply

The scope of supply consists of:

- Compass (110-233)
  - Outer sphere
  - Distilled water
  - Supporting liquid
  - Gyrosphere (111-006)
- User manual for the STD 22 Compass
- Installation and service manual for the STD 22 Compass
- Tools and spare parts pack
  - Sealing rings
  - Suction cup
  - Filling device
  - Injector

The STD 22 Gyro Compass is used in conjunction with at least the following items of equipment:

- Distribution Unit 138-118 (separate manual)
- Operator Unit 130-613 (separate manual)

## Installation and Service manual

### Compass STD 22

---

#### 3.1.1 General information concerning installation of the STD 22 Compass

When fitting components, observe the following spacing:

Fit the compass enclosure so that the display can be viewed from above and the cover of the enclosure can be removed (see also Dimensional Drawing 110-133.HP005).

To ensure fault-free operation of the STD 22 Compass, it is essential to follow these directions, safety notes and installation instructions.

Instructions relating to cable cross-sections and earth connections must be adhered to.

The tools which are specified for installing the compass must be used.

Only original parts or parts approved by the manufacturer may be used in connection with the STD 22 Compass.

See also Cable Connection Diagram 110-233 HP009 or HP0029 for the STD 22 Compass.

Gyro Compass should not be installed in oil-containing ambient air, within surrounding in vibration and should be installed on a vibration-free platform.

Gyro compass should be installed on the ship's line (vertical and horizontal).

The installation of the power supply (AC/DC-Converter) should only be performed by an experienced electrician.



The 24VDC supply voltage should be engineered as a low-security-voltage according to SELV.



In some system configurations it is necessary to take off heading information from the compass direct – additional to the heading information on the CAN bus. This heading information is uncorrected (without SEC)!

Corrected heading information (with SEC) can be taken off in these system configurations from the distribution unit only.



## 3.2 Creating cable connections

### 3.2.1 General information concerning on-board wiring

The cables which are to be connected to the STD 22 Gyro Compass are led through one of the cable entries at the top of the compass enclosure and fixed in the cable entry with a cable clip suitable for the size of the cable.

The cable entries are supplied with the compass.



**Caution:**

Ensure that cables are not live before creating cable connections.

It is vitally important to ensure that all cables are free of voltage; where appropriate, carry out voltage measurements beforehand and/or disconnect the relevant distributor from the power supply.

To ensure that the compass functions correctly, it is essential to adhere to the following sequence when creating cable connections.

- Strip the cable over a length of approximately 180 mm (depending on the distance of the cable entry from the terminal). Be careful not to damage the screening.
- Trim the screening so as to leave approximately 15 mm on the cable.




Figure 37: Requirements for stripping the connecting cable

## Installation and Service manual Compass STD 22

---

- Push the components of the screw fastening over the cable.  
It is essential to follow the sequence (as shown in Figure 38).
- Check the cone and the mating piece of the earthing insert for corrosion and if necessary remove corrosion with an emery cloth.
- Push the mating piece of the earthing insert to the end of the cable sheath.
- Push the cone inside the screening and against the mating piece. Ensure that the screening is evenly distributed over the cone (see Figure 38).





Figure 38: Creating the cable connection

Supply voltage    Coursebus    CAN bus    Function "Quick Settling"



Note: The connection cables should be shortened in that way, that they could be led to the terminal boards without mechanical stress.  
Too long connection cables will lead to EMC problems.  
For the cable-type see respective drawing at the appendix.

Figure 39: Example of a proper cable connection

- Place the earthing insert, strain relief and washer in the cable entry; fit and tighten the counter nut.
  - Strip the cable conductors to a length of about 1.5 cm, lightly twist them and fit cable end sleeves.
- Tighten the terminal screws – check the connection is secure by pulling gently.

## Installation and Service manual

### Compass STD 22

---

#### 3.2.1.1 General information about creating an earth connection

The following instructions relating to the creation of cable connections must be adhered to in order to comply with the stringent EMC requirements.  
The specified cable types must be used.



It is vital to ensure that these connections have **a common** reference to ship's earth.  
Additional components (optional features) must likewise be connected to the common earth.




Figure 40: Creating an earth connection

Each earth connection must be made as shown in Figure 40.  
The earth cable, to which a cable lug is attached, must have a cross-section of at least 1.5 mm<sup>2</sup>.  
The cable lug is mounted between a pair of toothed washers.  
Earth connections must be free of all corrosion; they must be screwed tight.

## 3.3 Installing the compass and putting it into operation

### 3.3.1 Remove the transportation support with outer sphere, supporting liquid and distilled water.

- Undo the 4 screws (Figure 41 /1) at the top and bottom of the enclosure door, lift out the door and detach the earthing strip (Figure 41/2) on the inside of the door.
- Carefully remove the transport packaging with the outer sphere and the two bottles containing supporting liquid and distilled water from the compass enclosure.
- Take the outer sphere out of the transport packaging and place it on the base plate; the outer sphere must be secured to prevent it from tilting





Figure 41: Principle of dismantling the enclosure door

## Installation and Service manual

### Compass STD 22

#### 3.3.1.1 Assembling the compass enclosure

**Note:** It is not necessary to install the compass enclosure with reference to the ship (e.g. in the ship's forward direction). It can be installed in whatever position is most convenient for servicing and operation (compass enclosure removable and it must be possible to open the compass door - observe the size of tools).  
The installation described below is to be regarded as the manufacturer's recommendation.




Figure 42: Installation of the compass enclosure



The compass enclosure must be installed in such a way that the following requirements are met:

- The 8 supports must all stand on a flat, firm surface.  
If necessary, the user should himself create an intermediate plate (marine quality hardwood or metal) suited to the local conditions.
- The compass enclosure must be screwed to the intermediate plate in a sea-resistant fashion.
- The intermediate plate must also be screwed to the ship's body in a sea-resistant fashion; this fastening is the responsibility of the user of the STD 22 himself.
- The compass enclosure must be mounted so that the digital display can be seen easily after installation, the door of the compass enclosure can be opened and closed easily and the cover of the compass enclosure can be detached.
- The fastenings of the compass enclosure are indicated in the dimensional drawing "Gyro Compass" (110 D 233 HP005) in the appendix to this manual.

The compass enclosure is fastened to the intermediate plate with 6 screws

- for woodscrews  $\varnothing 11$  x length depending on the thickness of the intermediate plate
- for metal screws M10 x length depending on the thickness of the intermediate plate.

The compass enclosure can also be mounted directly on a flat metal surface; in this case, suitable stud bolts (M10) must be welded on; alternatively the compass housing can be fastened on the underlying surface with threaded holes and screws M10-A4.

## Installation and Service manual Compass STD 22




Figure 43: Horizontal alignment for installation of the compass enclosure



## 3.3.1.2 Installation of the gyrosphere

Special tool required:  
Suction cup

Installation procedure:

- Undo the six screws (Figure 44/1) fastening the upper and lower halves of the outer sphere (Figure 44/2 and 3).
- Remove plug B3 (Figure 44/4) from the plug plate.




Figure 44: Outer sphere

- Remove the upper half of the outer sphere (Figure 44/2). Take the gyrosphere (Figure 45/2) out of the transportation box and carefully insert it using the suction cup (Figure 45/3) in the lower outer sphere (see Figure 45).

## Installation and Service manual Compass STD 22





Figure 45: Principle of separating the upper and lower halves of the outer sphere  
– inserting the gyrosphere

- Replace the upper half of the outer sphere on the lower half.



Check that there is a proper seal between the two halves of the outer sphere (see Figure 45/1).

- Retighten the six screws (see Figure 44/1).
- Insert plug B3 (Figure 44/4) again.

### 3.3.1.3

#### Filling with distilled water and supporting liquid.

(see Figure 46)

- Undo the three plastic screws (Figure 46/1-3) on the upper outer sphere




Figure 46: Filling with liquids

- Fit the supplied filling device on the distilled water bottle.
- Pour in all the distilled water (230 cm<sup>3</sup>) (look for the identifying label on the outer sphere).
- Re-close the distilled water filling opening with the screw, check that it is properly sealed.
- Remove the filling device from the distilled water bottle and attach it to the supporting liquid bottle.



## Installation and Service manual Compass STD 22

---

- Pour approximately 840 cm<sup>3</sup> of supporting liquid in the appropriate filling opening (look for the identifying label).

The supporting liquid must be at room temperature (over 25° C) and the measuring cone should fill half the measuring range (diameter).

The following photograph shows the measuring cone for the liquid level.



This picture only shows the situation at the start of operation (after filling for the first time or after changing the supporting liquid -> cold supporting liquid); during operation, the dark circle in the measuring cone is smaller.

Figure 47: Measuring cone for supporting liquid level

- Discard any unused supporting liquid; no special measures are needed for disposal.
- Re-close the filling opening for supporting liquid, check that it is properly sealed.
- Re-insert the ventilation screw, check that it is properly sealed.

#### 3.3.1.4

#### Inserting the outer sphere in the compass enclosure

(see Figure 48)

- Carefully insert the gyrosphere in the compass enclosure:



Pay attention to the two locking pins on the closure.

- Using both hands, hold the outer sphere and guide it under the snap closures (Figure 48/1) on the pendulum joint (Figure 48/2).




Figure 48: Principle of inserting the outer sphere in the compass enclosure

## **Installation and Service manual Compass STD 22**


---

- Using the thumbs, press down and engage two snap closures (Figure 48/1).
- Turn the outer sphere through 90° and repeat the process with the two other snap closures. The outer sphere is now fastened to the pendulum joint.
- Guide the cable around the outer sphere and attach the plugs to the small PCB of the outer sphere, tighten the fastening screws.

## 3.4 Creating cable connections and plug connections

### 3.4.1 Overview of plug connections and fuses on PCB's

Power Supply PCB 110-233.102      Connection PCB NB05-356      Sensor PCB 110-233.X08



Power Supply PCB 110-233.X12      Connection PCB 110-233.X13      Sensor PCB 110-233.X11

E10




Figure 49: Arrangement of PCB's in the STD 22 Compass (cover removed)

## Installation and Service manual Compass STD 22




Figure 50: Arrangement of plugs, terminal boards and fuses on the Connection PCB.

1	Terminal L1	Power supply (24VDC)	
2	Fuse E1 (T10A)	Power supply (24VDC)	
3	Plug B2	Output Channel1 Course Bus/NMEA	
4	Fuse E2 (T1A)	Channel1 +24V	
5	Plug B3	Output Channel2 Course Bus/NMEA	
6	Fuse E3 (T1A)	Channel2 +24V	
7	Plug B4	Output Course Bus	
8	Fuse E4 (T1A)	Course Bus +24V	
9	Plug B5	Input (+24V/Set QS/ Pulse Log/Pulse Log Dir./NMEA Log/GPS-receiver)	
10	Plug B6	Output (QS/SEC/System/Available)	
11	Plug B7	CAN1 bus	
12	Plus B8	CAN2 bus	
	Switch B32	for CAN1 bus terminating resistor	E10
13	Terminal Board L2	24V connection to Power Supply PCB	
	Plus B8	CAN2 bus	E10
14	Jumper B31	for the CAN2 bus terminating resistor	
	Switch B31	for the CAN2 bus terminating resistor	E10
15	Jumper B32	for the CAN1 bus terminating resistor	
	Terminal Board L2	24V connection to Power Supply PCB	E10



### 3.4.2 Creating a cable connection from STD 22 Compass → Distribution Unit

NOTE: The installation and commissioning of the Distribution Unit are described in the Distribution Unit manual.

To create cable connections to the Distribution Unit, see also Cable and Connection Diagram 110-233. HP009 or HP029.

This connection is made using cables with CAN bus plugs at both ends (see also section 3.4.2.2 – Connecting the CAN bus plug).

For each CAN bus, a screened 2-core twisted cable with a conductor cross-section of  $\geq 0.5\text{mm}^2$  must be used.

There is a redundant CAN bus:

- CAN1 bus
- CAN2 bus

Each CAN bus must be connected.

Missing or disconnected plug connections will cause an error message to be sent to the Operator Unit (see manual 3648, Operator Unit 130-613).

The plugs must be inserted on the Connection PCB as shown in Figure 50.

If several STD 22 gyro compasses are combined with one another, they are connected to each other from compass to compass via the CAN bus.

For this purpose, each device is equipped with 2 sockets (CAN1 = B7 and CAN2 = B8) (e.g. CAN1 and CAN 1 OUT), whereby CAN OUT does not have to be connected if the compass in question is installed virtually as a terminal device.

The compass or compasses can also be connected via any other CAN bus user.



When inserting plugs, be sure not to get the plugs mixed up.  
The CAN1 bus must always be connected to the CAN1 bus of the subsequent device.



If a compass is operated within a CAN bus configuration as a terminal device on the CAN bus, terminating resistors must be activated for each CAN bus (see section 3.4.2.3).



The total length of the CAN bus cable must not exceed a length of 300 m.

## Installation and Service manual

### Compass STD 22

---

#### 3.4.2.1 Connecting to the power supply (Distribution Unit)

The STD 22 Compact Compass operates at 24VDC.

This voltage is generated via the Distribution Unit or fed directly to the compass.




Figure 51: Connection of the +24VDC power supply

The 2-core cable that is used should have a conductor cross-section of  $\geq 2.5\text{mm}^2$ .

At terminal L1 (see Figure 51), connect a power supply  
of +24VDC at terminal 1  
0V at terminal 2.

## 3.4.2.2 Connecting the CAN bus plug

For each CAN bus, a screened 3-core twisted cable with a conductor cross-section of  $\geq 0.5\text{mm}^2$  must be used.

All the CAN bus connections to be used are identical.




Figure 52: CAN bus plug

The screening of the cable is connected to the enclosure earth.




Figure 53: CAN1 and CAN2 connections in the STD 22 Gyro Compass

## Installation and Service manual

### Compass STD 22

---

#### 3.4.2.3 Setting the jumpers for the CAN bus




Figure 54: Jumpers B32 and B31 for CAN1 and CAN2 in the STD 22 Gyro Compass

If a compass is to be used as a terminal device in a CAN bus application, both jumpers (B32 and B31) must be inserted. These jumpers activate the terminating resistor at the end of each CAN bus.

Each end of the CAN busses must be terminated with a terminating resistor.

Failure to insert jumpers (open bus) will cause sporadic error messages from the bus concerned (see also manual 3648, Operator Unit 130-613).

## 3.4.2.4 Switching the termination resistors for the CAN bus (E10 only)




Figure 55: Switches B32 and B31 for CAN1 and CAN2 termination resistors

If a compass is to be used as a terminal device in a CAN bus application, both switches (B32 and B31) must be set to the closed position. This position activates the terminating resistors at the end of each CAN bus.

Each end of the CAN busses must be terminated with a terminating resistor.

Failure not to set termination resistors (open bus) will cause sporadic error messages from the bus concerned (see also manual 3648, Operator Unit 130-613).

## Installation and Service manual

### Compass STD 22

---

#### 3.4.2.5 Connecting the compass to earth




Figure 56: Connection of compass to earth

An earth connection (ship's earth) must be made using the earthing screw shown in Figure 56.

The earth connection must have a common reference to the other components (Operator Unit, Distribution Unit and repeater compasses).

### 3.4.3 Switching on, settling and adjustment

The STD 22 Compass switches on when the power supply is activated on the main control panel for the Distribution Unit (once the Distribution Unit has been connected to the STD 22 Compass).

#### 3.4.3.1 Checks on the compass

Measuring the compass power supply voltage (on the compass).

This voltage must fall within the tolerance range (18 VDC to 36 VDC).

Terminal board L1  
Power supply connection




Figure 57: Measuring the compass power supply voltage

Terminal board L1	terminal 1	+24VDC
Terminal board L1	terminal 2	0V

Note: The absolute lower limit for the power supply voltage is 18VDC, the absolute upper limit is 36VDC!

When connecting cables, ensure that these values are adhered to.

# Installation and Service manual

## Compass STD 22

Checking the DIP switch settings on the compass (see Figure 58):





Figure 58: Checks on the compass before putting into operation

All DIP switches in the “ON” position





## 3.4.3.2 Switching on the compass

The compass goes into the heating stage for the first 30 minutes (this period will vary depending on the temperature of the supporting liquid), during which time the course output of the compass is unavailable and the letter “h” is displayed as the leading sign on the digital display (see Figure 59).

During the settling in stage (for 4 hours after switching on), the course output of the compass may be used; **however, the deviation from the actual course may still be considerable (as well as the connected course receiver).**

During this period, an additional dot appears in the digital display of the compass (see Figure 60).

(The “Quick Settling” option reduces the settling in stage to approximately 1 hour).

After 4 hours from switching on, the compass course may be used.

4 hours after switching on, the compass has an accuracy of  $<2^\circ$ .

After appr. 5 hours (after switching on), the compass has an accuracy of von  $0,1^\circ \times 1/\cos$  latitude.

### ON THE COMPASS




Figure 59: Indications on the compass during the heating stage

## Installation and Service manual Compass STD 22




Figure 60: Indications on the compass during the settling in stage

### 3.4.3.3 Setting the compass zero (reference course)

Once the compass has been installed, it must be aligned according to its installation location. The compass zero is set using DIP switch B 37 and buttons B 38 and B 39.

**The compass must have been in operation for at least 5 hours before the compass zero is set.**




Figure 61: DIP switch B37 and buttons B38/B39

The reference course to be set is determined from the ship's fore-and-aft line (e.g. take a bearing or obtain the pier course from the sea chart).

This reference course is entered according to the following procedure.

- Set DIP switch B37 "1" to the "OFF" position.  
The digital indicator is now indicating "ALeR" = Alignment Error
- Press button B38 or button B39 until the heading you require is displayed (B38 changes the value downwards and B39 changes it upwards).
- If you hold down the button the speed at which it changes will increase.  
Set DIP switch B37 "1" to the "ON" position. This saves the set value in the compass.
- After the reference course has been set, read the alignment error (see next section) (See also Figure 62)

# Installation and Service manual Compass STD 22





Figure 62: Procedure for setting the compass zero

## 3.4.3.4 Reading the alignment error

The alignment error must be entered in the table provided for that purpose on the inside of the cover.

Alignment Error	
123.4	

Figure 63: Table at the cover (inner side)



DIP switch "8" in "OFF" position.

### NOTE:

It is essential to enter this value, because the alignment error will be needed if the sensor electronics are replaced, in order to determine the reference course for the new PCB.

DIP switch "8" in "ON" position.

The STD 22 Compass is ready for use.

Replace the cover of the compass and screw it tight.

## Installation and Service manual Compass STD 22

### 3.4.3.5 Setting the CAN bus address





Every CAN bus user must be reachable via an address.

This address may be assigned in the CAN bus system only once.

In the gyro compass, this address is set with the DIP switch.

The CAN bus address for compasses can be set within a range from  $10_{(10)}$  to  $19_{(10)}$ .

The address  $00_{(10)}$  may not be used.

Indications	Comments, Information
<p>Switch B 37 (DIP switch)</p>  <p style="text-align: center;">↓</p> 	<div style="display: flex; flex-direction: column; align-items: center;"> <div style="display: flex; align-items: center; margin-bottom: 20px;"> <div style="text-align: center;"> <p>B38</p>  </div> <div style="margin: 0 10px;">→</div> <div style="border: 1px solid black; padding: 5px; text-align: center;">13</div> </div> <div style="margin-bottom: 10px;">↓</div> <div style="border: 1px solid black; padding: 5px; text-align: center;">12</div> <div style="margin-top: 20px;">each time pressed changes downwards</div> </div> <hr style="border-top: 1px dashed black;"/> <div style="display: flex; flex-direction: column; align-items: center;"> <div style="display: flex; align-items: center; margin-bottom: 20px;"> <div style="text-align: center;"> <p>B39</p>  </div> <div style="margin: 0 10px;">→</div> <div style="border: 1px solid black; padding: 5px; text-align: center;">12</div> </div> <div style="margin-bottom: 10px;">↓</div> <div style="border: 1px solid black; padding: 5px; text-align: center;">13</div> <div style="margin-top: 20px;">each time pressed changes upwards</div> </div>

Below mentioned table shows the agreement for the CAN bus addresses within a compass system.

Device(s)	CAN-Bus-Address
Operator Units	01 to 09
Sensors (GPS-compass)	10 to 13
Sensors (Gyro Compass)	14 to 19
Distribution Units	20 to 29

## 3.4.3.6 Adjustment of essential operating modes

Unscrew and remove the cover of the compass enclosure.





Figure 64: DIP switch B37 and button B38/B39

Initial status:




## Installation and Service manual Compass STD 22


Note: The procedure to adjust essential operating modes is described on the next four pages.

Set the repetition rate of the NMEA heading data output, the output with or without ROT (Rate of Turn), with or without oil residual error for the speed error correction and the setting of a connected Data Distribution Unit (not for STD 22 Compact Gyro Compass).












1 heading data transmission 1 telegram per second  
10 heading data transmission 10 telegrams per second  
HE.ro heading with ROT.  
HE.-- heading only  
SECY heading data incorporating Speed Error Correction  
SECN heading data without Speed Error Correction  
oELY Speed Error Correction with oil residual error (**recommended setting**)  
oELn Speed Error Correction without oil residual error  
ddUY with connected Data Distribution Unit  
ddUn without Data Distribution Unit (**setting for STD 22 Compact Gyro Compass absolute necessary**)  
nMSY NMEA output with SEC  
nMSn NMEA output without SEC  
The indications in the flashing display are selected.









## Installation and Service manual Compass STD 22

<p>Switch B37 (DIP switch) OPEN</p>  <p>1 2 3 4 5 6 7 8</p> <p>↓</p> 	<div><p>B38</p><p>5X</p><p>→</p></div> <div><p>B39</p><p>1X</p><p>→</p></div> <hr/> <div><p>B38</p><p>6X</p><p>→</p></div> <div><p>B39</p><p>1X</p><p>→</p></div>
<div></div> <p>On adjustment <b>SECY</b>: In some system configurations it is necessary to take off heading information from the compass direct - additional to the heading information on the CAN bus. This heading information is uncorrected (without SEC)!</p> <p>Corrected heading information (with SEC) can be taken off in these system configurations from the distribution unit only.</p>	
<p>continued on next page</p>	




# Installation and Service manual Compass STD 22



# Installation and Service manual Compass STD 22



Compass  
STD 22



## Installation and Service manual Compass STD 22

### 3.4.3.7 Function check on externally connected course receivers, Function check of RoT

Unscrew and remove the cover of the compass enclosure.





Figure 65: DIP switch B37 and button B38/B39


Initial status:




Checking connected course receivers (course data).

With this function the RoT of connected RoT-Indicators\* can be tested as well (the rate of turn which is generated by this DIP switch position is 20° per minute).

Switch B 37 (DIP switch)




B 39



Outer sphere turns cw

130.0  
129.9  
129.8  
129.7  
129.6

B38




Outer sphere turns ccw

130.5  
130.4  
130.3  
130.2  
130.1

**\*Remark:** Only for RoT-Indicators which are connected to the Distribution Unit.

**Note:** A clockwise (cw) rotation of the outer sphere refers to a ships turn direction counterclockwise.

OPEN



Display

## **Installation and Service manual Compass STD 22**

---

intentionally left blank



---

## **4 Fuses, jumper, LED's, buttons and plugs**

The meaning and the location of fuses, jumper LED's, buttons and plugs of the 3 PCB's: is given in the annex.

PCB	Part no.	Part no. (E10)
Connection PCB	NB05-365	110-233.X13
Power Supply PCB	110-233.102	110-233.X12
Sensor PCB	110-233.X08	110-233.X11
Outer Sphere PCB	110-233.101	110-233.X10

After removal of the cover this information can be helpful to locate a fault.

**Installation and Service manual**  
**Compass STD 22**  
**Compass STD 22 Compact**

---

intentionally left blank

## **5 DIP SWITCH settings**

The facilities described below for entering settings and obtaining status information may only be used by suitably trained staff.


In particular, information and settings which are clearly identified as “service only” are only to be used by appropriately trained personnel.

Following adjustments and settings refer to the STD22 Compact Gyro Compass as well as for the STD 22 Gyro Compass.

Exceptions are marked.

With all DIP switches set to the “ON” position, the current heading is displayed again and all settings that have been made are stored in the compass.

Switch B 37 (DIP switch)
















The individual switches are moved up to turn them “OFF” and down to turn them “ON”.

# Installation and Service manual

## Compass STD 22

### Compass STD 22 Compact

#### 5.1 Overview of functions of all DIP switch settings

Serial no.	DIP switch setting	Function
1	 1 2 3 4 5 6 7 8	Normal operation
2	 1 2 3 4 5 6 7 8	Setting compass zero (Alignment error)
3	 1 2 3 4 5 6 7 8	Set the repetition rate (1s/100ms) of the NMEA heading data output and the output with or without ROT
4	 1 2 3 4 5 6 7 8	Set the CAN bus address (for gyro compass STD 22 only)
5	 1 2 3 4 5 6 7 8	Set the interfaces for Channel 1 and Channel 2 (compass outputs)
6	 1 2 3 4 5 6 7 8	Set the ROT turning direction (Port +; STB -)
7	 1 2 3 4 5 6 7 8	Bypass the settling phase ( <b>Service only</b> )
8	 1 2 3 4 5 6 7 8	Set the speed source for SEC
9	 1 2 3 4 5 6 7 8	Check connected course receivers (course data) (follow up turning) Function check of RoT
10	 1 2 3 4 5 6 7 8	Check the fan, the display and the follow-up. <b>DO NOT PERFORM DURING THE HEATING PHASE!!</b>
11	 1 2 3 4 5 6 7 8	Turn off the follow-up system ( <b>Service only</b> )
12	 1 2 3 4 5 6 7 8	Adjustments to read-out of data. see following steps.
12 Step 1	 1 2 3 4 5 6 7 8	Indicate encoder heading

# **Installation and Service manual** **Compass STD 22** **Compass STD 22 Compact**















Compass  
STD 22

Serial no.	DIP switch setting	Function
12 Step 2	 1 2 3 4 5 6 7 8	Indicate alignment error
12 Step 3	 1 2 3 4 5 6 7 8	Indicate SEC (Speed Error Correction)
12 Step 4	 1 2 3 4 5 6 7 8	Indicate ship's mains input voltage (24VDC) Nominal value: 18.0....36.0V
12 Step 5	 1 2 3 4 5 6 7 8	Indicate internal operating voltage of Power Supply PCB (14VDC) Nominal value: 14.0...16.0V
12 Step 6	 1 2 3 4 5 6 7 8	Indicate encoder supply voltage (15VDC) Nominal Value: 14.5...15.5V
12 Step 7	 1 2 3 4 5 6 7 8	Indicate inductive DC transmission supply voltage (60VDC) Nominal value: 58.0....62.0V
12 Step 8	 1 2 3 4 5 6 7 8	Indicate internal operating voltage of Power Supply PCB (19VDC) Nominal value: 18.0...22.0V
12 Step 9	 1 2 3 4 5 6 7 8	Indicate present current due to inductive transmission Nominal value: 0.05...4.0A typical: 2.0 A
12 Step 10	 1 2 3 4 5 6 7 8	Indicate operating voltage of heating Nominal value: 27.0...32.0V
12 Step 11	 1 2 3 4 5 6 7 8	Indicate heating voltage at heating element Nominal value: 0...23.5V
12 Step 12	 1 2 3 4 5 6 7 8	Indicate temperature of the supporting liquid in °C Nominal value: Operating temperature 49.4...50.1°C
12 Step 13	 1 2 3 4 5 6 7 8	Indicate supporting liquid 2.0 - 1.6 = level OK 0.1 - 0.0 = level too low

# Installation and Service manual

## Compass STD 22

### Compass STD 22 Compact

Serial no.	DIP switch setting	Function
12 Step 14	 1 2 3 4 5 6 7 8	Indicate operating voltage (73VAC) Nominal Value: <65.0...79.0V
12 Step 15	 1 2 3 4 5 6 7 8	Indicate DC operating voltage for 400Hz (78 - 79.5VDC) Nominal value: 78V Tolerance: <77.0...79.5V
12 Step 16	 1 2 3 4 5 6 7 8	Indicate gyro supply 54-56V <sub>EFF</sub> Nominal value: During "start-up" 45...60V During operation 53...58V
12 Step 17	 1 2 3 4 5 6 7 8	Indicate gyro current 160-250mA <sub>EFF</sub> Nominal value: During "start-up" 150...400mA During operation 120...350mA
12 Step 18	 1 2 3 4 5 6 7 8	Indicate operating voltage (13-17VDC) Nominal value: <15.5V
12 Step 19	 1 2 3 4 5 6 7 8	Indicate internal operating voltage 15VDC (14.5-15.5VDC)
12 Step 20	 1 2 3 4 5 6 7 8	Indicate internal operating voltage 24VDC (23-35 VDC)
12 Step 21	 1 2 3 4 5 6 7 8	Indicate pump voltage 24V 50Hz (24V +/- 1V, 50 Hz) Nominal value: 23.5...24.5V
12 Step 22	 1 2 3 4 5 6 7 8	Indicate pump current (150mA) Nominal value: 140...180mA
12 Step 23	 1 2 3 4 5 6 7 8	Indicate pick-up voltage (coded) <5mV
12 Step 24	 1 2 3 4 5 6 7 8	Indicate program number and software version of the program for the microprocessor on the sensor PCB.
12 Step 25	 1 2 3 4 5 6 7 8	Indicate program number and software version of the program for the microprocessor on the Power Supply PCB.

# Installation and Service manual Compass STD 22 Compass STD 22 Compact



Compass  
STD 22

Serial no.	DIP switch setting	Function
12 Step 26	 1 2 3 4 5 6 7 8	Indicate program number and software version of the program for microprocessor <u>MC 1</u> on the outer sphere PCB.
12 Step 27	 1 2 3 4 5 6 7 8	Indicate program number and software version of the program for microprocessor <u>MC 2</u> on the outer sphere PCB.
12 Step 28	 1 2 3 4 5 6 7 8	Operating time (years)
12 Step 29	 1 2 3 4 5 6 7 8	Operating time (hours)
12 Step 30	 1 2 3 4 5 6 7 8	Future purpose
12 Step 31	 1 2 3 4 5 6 7 8	Future purpose
13	 1 2 3 4 5 6 7 8	Error logbook
SEC 1 to 35	 1 2 3 4 5 6 7 8	DIP switch settings, Speed Error Correction (SEC) (for development purposes only see section 5.1.5)
14	 1 2 3 4 5 6 7 8	Delete: - Error logbook complete - Operating hours (years and hours)

# Installation and Service manual

## Compass STD 22

### Compass STD 22 Compact

#### 5.1.1 Adjustments of parameters (in ascending order of function)

DIP-switch	Step	Display	Function	Push button B38 (left)	Push button B39 (right)
1	0	ALEr	Alignment error setting	decrease	increase
1+2	0	Addr.	Address setting CAN bus	downwards	upwards
1 to 8	0	Fr.Cl	Clearing Logs		
	1	E.L.Ci	Error Log Clear, whole log will be cleared	choose	hold to 0 to clear
	2	Y.h.Cl	Years, hours Clear	choose	hold to 0 to clear
6	0	130.1	Fan, display and follow-up test	-----	-----
5	0	-FU-	Follow-up system manual operation, Function check of RoT	turns cw	turns ccw
7	0	FUoF	Follow-up system turn off for service	-----	activate
2	0	nNEA	NMEA telegram setting		
	1	nN1	NMEA telegram repetition 1Hz	choose	set
	2	nN10	NMEA telegram repetition 10Hz	choose	set
	3	HE.ro	Heading telegram with ROT	choose	set
	4	HE.--	Heading telegram without ROT	choose	set
	5	SECY	Activate SEC	choose	set
	6	SECn	Deactivate SEC	choose	set
	7	oELY	SEC with oil residual error	choose	set
	8	oELn	SEC without oil residual error	choose	set
	9	ddUY	System with DU	choose	set
	10	ddUn	System without DU	choose	set
	11	nMSy	NMEA with SEC	choose	set
	12	nMSn	NMEA without SEC	choose	set
1+2+3	0	Chn1	Output channel 1, type of telegram		
	1	HSEr	Select for heading serial	choose	set
	2	nNEA	Select for NMEA	choose	set
	3	Chn2	Output channel 2, type of telegram		
	4	HSEr	Select for heading serial	choose	set
	5	nNEA	Select for NMEA	choose	set
2+3	0	P ro	ROT polarity setting	choose	set
	1	ro	Positive polarity for ROT	choose	set
	2	ro -	Negative polarity for ROT	choose	set
3	0	A180	Settling phase bypass	choose	set



# Installation and Service manual **Compass STD 22** **Compass STD 22 Compact**



Compass  
STD 22

DIP-switch	Step	Display	Function	Push button B38 (left)	Push button B39 (right)
4	0	LOG	Speed log settings		
	1	PLoG	Select for Puls log input	choose	set
	2	PLd-	Select for Puls log input (input interface inverted)	choose	set
	3	PLd	Select for Puls log input (input interface <u>not</u> inverted)	choose	set
	4	uhu.	Select for NMEA speed input	choose	set
	5	ubu.u	Select for NMEA speed input, speed through the water	choose	set
	6	ubu.G	Select for NMEA speed input, speed over ground	choose	set
	7	GLoG	select for GPS speed input	choose	set

# Installation and Service manual

## Compass STD 22

### Compass STD 22 Compact

#### 5.1.2 Adjustments of parameters (in ascending order of their appearance)

DIP-switch	Step	Display	Function	Push button B39 (right)	Push button B38 (left)
8	0	GYro	Reading measured data of the gyro		
	1	Enco	Encoder value	choose	display
	2	ALEr	Alignment error	choose	display
	3	SEC	SEC value	choose	display
	4	Pbor	24 V ships mains after input filter 12-32 V	choose	display
	5	Co14	14 V for 60 V inverter	choose	display
	6	P-En	15 V for encoder supply	choose	display
	7	P-60	60 V stabilized / ferrite transformer bridge	choose	display
	8	Co19	19 V from ferrite transformer	choose	display
	9	IndA	Current of ferrite transformer bridge	choose	display
	10	Co31	Voltage for heating circuit	choose	display
	11	C°-U	Voltage on heater element	choose	display
	12	-C°-	Supporting liquid temperature	choose	display
	13	Li-U	Supporting liquid level	choose	display
	14	Co73	73 V from ferrite transformer	choose	display
	15	78-U	78 V stabilized for gyro AC converter	choose	display
	16	GY-U	Gyro supply voltage	choose	display
	17	GY-A	Gyro supply current	choose	display
	18	Co15	15 V from ferrite transformer	choose	display
	19	P-15	15 V stabilized	choose	display
	20	P-24	24 V for pump AC converter	choose	display
	21	U-Pu	24 V AC pump voltage	choose	display
	22	A-Pu	Pump current	choose	display
	23	Ab9r	Follow up voltager W1/W2	choose	display
	24	Pr-S	Software sensor pcb	choose	display
	25	Pr-P	Software Power Supply PCB	choose	display
	26	Pr61	Software MC1 outer sphere pcb	choose	display
	27	Pr62	Software MC2 outer sphere pcb	choose	display
	28	runY	Operating years	choose	display
	29	runh	Operating hours	choose	display
	30	0007	future purpose		
	31	0008	future purpose		
7+8	0	E.L.01	Errors according to error logbook	choose	number of errors
	1	E.L.02-24	Errors according to error logbook	choose	number of errors
		Clear selected error logbook		Hold 10s to clear	

# Installation and Service manual

## Compass STD 22

### Compass STD 22 Compact











































Compass  
STD 22

DIP-switch	Step	Display	Function	Push button B38 (left)	Push button B39 (right)
6+7+8	0	UnCo	Uncorrected heading	choose	display
	1	FF	Correction value SEC	choose	display
	2	SPD	Speed input value	choose	display
	3	Br10	Latitude input	choose	display
	4	Corr	Corrected heading	choose	display
	5	_roh	Rough heading	choose	display
	6	o_FF	Correction value SEC with acc error	choose	display
	7	_FF	Correction value SEC without acc error	choose	display
	8	_oF	Acceleration error	choose	display
	9	SCi	Telegram traffic on serial interface	choose	display
	10	SrCS	Speed information source	choose	display
	11	PULS	Value from puls log	choose	display
	12	vtG.S	Value from GPS speed	choose	display
	13	vtG.h	Heading from GPS	choose	display
	14	uhu	Speed from NMEA telegram	choose	display
	15	SPd.L	Speed data transfer	choose	display
	16	PoS	Latitude in degrees	choose	display
	17	ASPd	Speed alarms	choose	display
	18	PoS <sub>n</sub>	Latitude data transfer	choose	display
	19	APoS	Latitude alarm	choose	display
	20	nAUC	Number of telegrams with checksum	choose	display
	21	nAn1	1 <sup>st</sup> table of NMEA requests	choose	display
	22	nAn2	2 <sup>nd</sup> table of NMEA requests	choose	display
	23	nSGG	Strings of GGA telegram	choose	display
	24	nSGL	Strings of GLL telegram	choose	display
	25	nSLL	Strings of SLL telegram	choose	display
	26	nShu	String of VHW telegram	choose	display
	27	nStG	String of VTG telegram	choose	display
	28	nSbu	String of VBW telegram	choose	display
	29	Fb10	Software component SEC: Latitude	choose	display
	30	FS10	Software component SEC: Speed	choose	display
	31	FnSP	Software component SEC: Ships speed vector	choose	display
	32	FuTG	Software component SEC: Speed over ground	choose	display
	33	tiNE	Time since activating SEC	choose	display
	34	SCI	Display serial communication interface	choose	display


# Installation and Service manual Compass STD 22 Compass STD 22 Compact







## 5.1.3 7 segment displays and their meaning

	= A		= S
	= B		= T
	= C		= U
	= D		= V
	= E		= W
	= F		= X
	= G		= Y
	= H		= Z
	= I		= 1
	= J		= 2
	= K		= 3
	= L		= 4
	= M		= 5
	= N		= 6
	= O		= 7
	= P		= 8
	= Q		= 9
	= R		= 0
	= comma		= *
	= point		= LF (Line Feed)




#### 5.1.4 Functional description of DIP switch settings (for general use)

**Note:** In the following tables, a flashing display on the compass is represented like this.



Serial No.	Indications	Comments, Information
1	<p>Normal operation</p> <p>If the decimal point flashes during normal operation, a warning can be displayed by means of the following procedure.</p> <div style="text-align: center;">               flashing              Switch B 37 (DIP switch)         </div> <div style="text-align: center;"> <p>OPEN</p>               1 2 3 4 5 6 7 8         </div>	<div style="display: flex; align-items: center;"> <div style="text-align: center;"> <p>B39</p>  </div> <div style="margin: 0 10px;">→</div> <div style="text-align: center;">  </div> </div> <p>Indicate warning 4 to 8 (if a warning appears, refer to operator manual)</p> <hr style="border-top: 1px dashed black;"/> <div style="display: flex; align-items: center;"> <div style="text-align: center;"> <p>B38</p>  </div> <div style="margin: 0 10px;">→</div> <div style="text-align: center;">  </div> </div> <p>Indicate warning 1 to 4 (if a warning appears, refer to operator manual)</p>

# **Installation and Service manual** **Compass STD 22** **Compass STD 22 Compact**

Serial No.	Indications	Comments, Information
2	<p>Setting compass zero</p> <p>The compass zero must be set following installation. Use the pier course from the sea chart as reference.</p> <p>Switch B 37 (DIP switch)</p> 	<div style="border-bottom: 1px solid black; padding-bottom: 10px;"> <p><b>B38/B39</b></p>  <p style="text-align: center;">Setting compass zero</p> </div> <div style="padding-top: 10px;"> <p><b>B38/B39</b></p>  <p style="text-align: center;">Setting compass zero</p> </div>











# Installation and Service manual Compass STD 22 Compass STD 22 Compact



Compass  
STD 22

Serial No.	Indications	Comments, Information
3	<p>Set the repetition rate of the NMEA heading data output, the output with or without ROT (Rate of Turn), with or without oil residual error for the speed error correction and the setting of a connected Data Distribution Unit (not for STD 22 Compact Gyro Compass).</p> <p>1 heading data transmission 1 telegram per second 10 heading data transmission 10 telegrams per second HE.ro heading with ROT. HE.-- heading only SECY heading data incorporating Speed Error Correction SECN heading data without Speed Error Correction oELY Speed Error Correction with oil residual error (recommended setting) oELn Speed Error Correction without oil residual error ddUY with connected Data Distribution Unit ddUn without Data Distribution Unit (setting for STD 22 Compact Gyro Compass absolute necessary) nMSy NMEA with SEC nMSn NMEA without SEC The indications in the flashing display are selected.</p>	<p>Switch B 37 (DIP switch) OPEN</p> <p>1X</p> <p>B38</p> <p>B39</p> <p>1X</p> <p>2X</p> <p>B 38</p> <p>B 39</p> <p>1X</p> <p>continued on next page</p>










# Installation and Service manual Compass STD 22 Compass STD 22 Compact

Serial No.	Indications	Comments, Information
3 cont.	<p>Switch B 37 (DIP switch) OPEN</p>  <p>1 2 3 4 5 6 7 8</p> <p>↓</p> 	<p>B38</p>  <p>3X</p> <p>→</p>  <p>↓</p> <p>B39</p>  <p>1X</p> <p>→</p>  <p>↕</p> <hr/> <p>B38</p>  <p>4X</p> <p>→</p>  <p>↕</p> <p>B39</p>  <p>1X</p> <p>→</p>  <p>↕</p>
continued on next page		



Serial No.	Indications	Comments, Information
3 cont.	<p>Switch B 37 (DIP switch) OPEN</p> <div><div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div></div><div>12345678</div></div> <p>↓</p> <div><div>nNEA</div></div>	<div><div><div>B38</div><div><div>5X</div><div></div></div></div><div>→</div><div><div>SECY</div></div></div> <div><div><div>B39</div><div><div>1X</div><div></div></div></div><div>→</div><div><div>↵</div><div><div>SECY</div></div><div>↘</div></div></div> <div><div><div>B38</div><div><div>6X</div><div></div></div></div><div>→</div><div><div>SELn</div></div></div> <div><div><div>B39</div><div><div>1X</div><div></div></div></div><div>→</div><div><div>↵</div><div><div>SELn</div></div><div>↘</div></div></div>
	<div><div><div><div>!</div></div></div><div><div>On adjustment <b>SECY</b>:</div><div>In some system configurations it is necessary to take off heading information from the compass direct – additional to the heading information on the CAN bus. This heading information is uncorrected (without SEC)!</div><div>Corrected heading information (with SEC) can be taken off in these system configurations from the distribution unit only.</div></div></div>	
continued on next page		




**Installation and Service manual**  
**Compass STD 22**  
**Compass STD 22 Compact**

Serial No.	Indications	Comments, Information
3 cont.	<p>Switch B 37 (DIP switch) OPEN</p> 	<p><b>With Speed Error Correction has to be set always to oELY</b></p> <div style="display: flex; align-items: center;">  <div style="margin-left: 20px;">  </div> </div> <div style="display: flex; align-items: center; margin-top: 10px;">  <div style="margin-left: 20px;">  </div> </div> <hr style="border-top: 1px dashed black; margin: 10px 0;"/> <div style="display: flex; align-items: center;">  <div style="margin-left: 20px;">  </div> </div> <div style="display: flex; align-items: center; margin-top: 10px;">  <div style="margin-left: 20px;">  </div> </div> <p style="text-align: right; margin-top: 20px;">continued on next page</p>


# Installation and Service manual Compass STD 22 Compass STD 22 Compact



Compass  
STD 22

Serial No.	Indications	Comments, Information
3 cont.	<p>Switch B 37 (DIP switch) OPEN</p> 	<p><b>Has always be set to ddUY in case of STD 22 Gyro Compass</b></p>  <hr/>  <p><b>Has always be set to ddUn in case of STD 22 Compact Gyro Compass</b></p> <p>continued on next page</p>

# Installation and Service manual Compass STD 22 Compass STD 22 Compact






**Installation and Service manual**  
**Compass STD 22**  
**Compass STD 22 Compact**



Compass  
STD 22

Serial No.	Indications	Comments, Information
4	<p>Set the CAN bus address of the compass  <b>For STD 22 Gyro Compass only</b>                      (only with Distribution Unit, Operation Unit and for further CAN bus users)</p> <p>Every CAN bus user has an address. This address may be assigned within the system only once.                      The CAN bus address for compasses (in general) can be set within a range from 10 to 19 (see table below).                      The address 00 may not be used.</p>	<div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;"> <p>Switch B 37 (DIP switch)</p> </div> <div style="text-align: center;"> <p>B38</p> <hr style="border-top: 1px dashed black;"/> <p>B39</p> </div> </div>
<b>Example</b>		
	Devices	CAN bus address
1	Operator Units	01 to 09
2	Sensors (GPS compass)	10 to 13
	Sensors (Gyro compass)	14 to 19
3	Distribution Units	20 to 29













# **Installation and Service manual** **Compass STD 22** **Compass STD 22 Compact**

Serial No.	Indications	Comments, Information
5	<p>Set the interfaces for Channel 1 and Channel 2.</p> <p><b><u>For STD 22 Compact Compass only</u></b></p> <p>HSEr = Heading serial (Course bus)</p> <p>nMEA = NMEA 0183</p> <p>The “flashing” setting is accepted.</p> <p>Switch B 37 (DIP switch)</p> 	 <hr/>  <p style="text-align: center;">continued on next page</p>

Installation and Service manual  
Compass STD 22  
Compass STD 22 Compact







Compass  
STD 22

Serial No.	Indications	Comments, Information
cont. No. 5	<p>Switch B 37 (DIP switch)</p> <p>OPEN</p>  <p>1 2 3 4 5 6 7 8</p> <p>↓</p> 	<div>  <p>B38</p> <p>3X</p> <p>→</p>  </div> <hr/> <div>  <p>B38</p> <p>4X</p> <p>→</p>  <p>↓</p>  <p>B39</p> <p>↕</p>  <p>↕</p> </div> <hr/> <div>  <p>B38</p> <p>5X</p> <p>→</p>  <p>↓</p>  <p>B39</p> <p>↕</p>  <p>↕</p> </div>




# **Installation and Service manual** **Compass STD 22** **Compass STD 22 Compact**

Serial No.	Indications	Comments, Information
6	<p>Set the polarity of ROT turning direction</p> <p>This information is supplied together with the course data to connected course receivers.</p> <p>Press button B38 to toggle between the two possible polarities. Press button B39 to select the polarity of the rate of turn.</p> <p>The indications in the <u>flashing</u> display are selected.</p> <p>A positive rate of turn is indicated by the absence of a minus sign.</p>	



Serial No.	Indications	Comments, Information
7	<p>Bridging over settling time</p> <p><b><u>CAUTION! When the settling in stage is by-passed, the display and all connected course receivers indicate that the course data is usable, even though there may be significant deviations.</u></b></p> <p><b><u>FOR SERVICE PURPOSES ONLY</u></b></p> <div data-bbox="560 846 906 1317"> <p>Switch B 37 (DIP switch)</p> <p>OPEN</p>  <p>1 2 3 4 5 6 7 8</p> <p>↓ Example:</p>  </div>	<div data-bbox="943 846 1544 1317"> <p>B38</p>  <p>→ &lt;&lt; 000 &gt;&gt;</p> <p>↓</p> <p>B39</p>  <p>→ &lt;&lt; 180 &gt;&gt;</p> </div> <p>After the DIP switch is set into zero position the settling stage is by-passed</p>







# **Installation and Service manual** **Compass STD 22** **Compass STD 22 Compact**

Serial No.	Indications	Comments, Information
8	<p>Set the speed source for SEC <b>(STD22 Compact only)</b></p> <p>This setting is used to select the source of the speed information for automatic Speed Error Correction.</p> <p>PLoG = Pulse Log            PLd- = Puls Log (polarity of the input interface inverted)            PLd = Puls Log (polarity of the input interface not inverted)            uhu. = NMEA Log (means water speed in general)            ubu.u = means NMEA Log specified with speed through the water            ubu.G = means NMEA Log specified with speed over ground            GLoG = GPS-receiver speed</p> <p>The indications in the <u>flashing</u> display are selected.</p> <p>If the setting does not correspond to the connected device, the course correction relay responds and gives an appropriate warning only to devices which are connected to this alarm output.</p>	<div style="display: flex; justify-content: space-between;"> <div style="width: 45%;"> <p>Switch B 37 (DIP switch)</p>  </div> <div style="width: 50%;"> <div style="margin-bottom: 20px;"> <p>B38</p>  </div> <hr style="border-top: 1px dashed black;"/> <div> <p>B38</p>  </div> </div> </div>



Installation and Service manual  
Compass STD 22  
Compass STD 22 Compact








Compass  
STD 22




Serial No.	Indications	Comments, Information
cont. No. 8		<div data-bbox="954 465 1533 846"> <p>B38</p>  <p>3X</p> <p>⇒ PLd</p> <p>↓</p> <p>B39</p>  <p>1X</p> <p>⇒ &lt;&lt; PLd &gt;&gt;</p> </div> <hr/> <div data-bbox="954 869 1533 1249"> <p>B38</p>  <p>4X</p> <p>⇒ uhu.</p> <p>↓</p> <p>B39</p>  <p>1X</p> <p>⇒ &lt;&lt; uhu. &gt;&gt;</p> </div> <hr/> <div data-bbox="954 1272 1533 1653"> <p>B38</p>  <p>5 X</p> <p>⇒ ubu.u.</p> <p>↓</p> <p>B39</p>  <p>3X</p> <p>⇒ &lt;&lt; ubu.u. &gt;&gt;</p> </div>





**Installation and Service manual**  
**Compass STD 22**  
**Compass STD 22 Compact**

Serial No.	Indications	Comments, Information
cont. No. 8		<div style="text-align: center;">  </div> <hr style="border-top: 1px dashed black;"/> <div style="text-align: center;">  </div>





Serial No.	Indications	Comments, Information
9	<p>Check connected course receivers (check of follow-up function) and check of RoT. The check of RoT is only possible at RoT-Indicators which are connected to the Distribution Unit.</p> <p>Switch B 37 (DIP switch)</p> 	<p>B 39</p>  <hr/> <p>B38</p> 
		<p>10</p> <p>Check the fan, the display and the follow-up. <b>DO NOT PERFORM DURING HEATING STAGE!</b></p> <p><b><u>The current course is displayed on the connected course receivers.</u></b></p> <p>Switch B 37 (DIP switch)</p>  <p>B39</p>  <p><b>NOTE:</b> If this function is activated during the heating stage inadvertently, the compass must switched OFF and -ON again.</p>

# Installation and Service manual Compass STD 22 Compass STD 22 Compact





Serial No.	Indications	Comments, Information
11	<p>Turn off the follow-up system</p> <p><b>(SERVICE ONLY)</b></p> <p>These switches turn off the follow-up system of the compass, in other words, the display no longer follows the course.</p> <p><u>Caution:</u> The displayed course and the course for all connected course receivers do not correspond to the ship's course.</p>	<div> <div> <p>Switch B 37 (DIP switch)</p>  </div> <div> <p>B39</p>  <p>1X</p> <p><b>Follow Up oFF</b> Follow-up system turned off</p> <p>↓</p> <p>B38</p>  <p>1x</p> <p>The displayed value is exclusively for development purposes.</p> </div> </div>

Serial No.	Indications	Comments, Information
12	<p>Indicate Encoder heading</p> <p>Switch B 37 (DIP switch)</p> 	
12.1	<p>Indicate Alignment Error</p> <p>Switch B 37 (DIP switch)</p> 	









# **Installation and Service manual** **Compass STD 22** **Compass STD 22 Compact**

Serial No.	Indications	Comments, Information
12.2	<p>Indicate SEC (<u>S</u>peed <u>E</u>rror <u>C</u>orrection) value  The heading indication already takes this value into account.</p>	
	<p>Switch B 37 (DIP switch)</p> <p>OPEN</p> 	
12.3	<p>Indicate supply voltage DC (P = Power)  (input operating voltage 24VDC)</p>	
	<p>Switch B 37 (DIP switch)</p> <p>OPEN</p> 	



Serial No.	Indications	Comments, Information
12.4	<p>Indicate: Internal operating voltage of Power Supply PCB</p> <p>Switch B 37 (DIP switch) OPEN</p> 	
12.5	<p>Indicate: Encoder supply voltage</p> <p>Switch B 37 (DIP switch) OPEN</p> 	





# **Installation and Service manual** **Compass STD 22** **Compass STD 22 Compact**

Serial No.	Indications	Comments, Information
12.6	Indicate: Inductive DC transmission supply voltage	
	<p>Switch B 37 (DIP switch)</p> <p>OPEN</p>  <p>1 2 3 4 5 6 7 8</p> <p>↓</p> 	<p>B38</p>  <p>7X</p> <p>↓</p> <p>B39</p>  <p>1X</p>
12.7	Internal operating voltage of Power Supply PCB	
	<p>Switch B 37 (DIP switch)</p> <p>OPEN</p>  <p>1 2 3 4 5 6 7 8</p> <p>↓</p> 	<p>B38</p>  <p>8X</p> <p>↓</p> <p>B39</p>  <p>1X</p>









**Installation and Service manual**  
**Compass STD 22**  
**Compass STD 22 Compact**



Compass  
STD 22

Serial No.	Indications	Comments, Information
12.8	<p>Indicate: Operating current (inductive transmission) (for development purposes only)</p> <hr/> <p>Switch B 37 (DIP switch)</p> 	
12.9	<p>Indicate: operating voltage of heating</p> <hr/> <p>Switch B 37 (DIP switch)</p> 	





# **Installation and Service manual** **Compass STD 22** **Compass STD 22 Compact**

Serial No.	Indications	Comments, Information
12.10	Heating voltage at heating element	
	<p>Switch B 37 (DIP switch)</p> <p>OPEN</p>  <p>1 2 3 4 5 6 7 8</p> <p>↓</p> 	<p>B38</p>  <p>11X</p> <p>↓</p> <p>B39</p>  <p>1X</p>
12.11	Indicate temperature of the supporting liquid in °C Nominal value: 49.4°C to 51.1°C	
	<p>Switch B 37 (DIP switch)</p> <p>OPEN</p>  <p>1 2 3 4 5 6 7 8</p> <p>↓</p> 	<p>B38</p>  <p>12X</p> <p>↓</p> <p>B39</p>  <p>1X</p>





**Installation and Service manual**  
**Compass STD 22**  
**Compass STD 22 Compact**



Compass  
STD 22

Serial No.	Indications	Comments, Information
12.12	<p>Indicate supporting liquid level                      Indication "2.2" = liquid level OK                      Indication "0" = liquid level not OK</p> <hr/> <p>Switch B 37 (DIP switch)</p> 	
	<p>Indicate operating voltage</p> <hr/> <p>Switch B 37 (DIP switch)</p> 	





# **Installation and Service manual** **Compass STD 22** **Compass STD 22 Compact**

Serial No.	Indications	Comments, Information
12.14	Indicate DC operating voltage for 400Hz	
	<p>Switch B 37 (DIP switch)</p> 	
12.15	Indicate gyro supply	
	<p>Switch B 37 (DIP switch)</p> 	




**Installation and Service manual**  
**Compass STD 22**  
**Compass STD 22 Compact**



Compass  
STD 22

Serial No.	Indications	Comments, Information
12.16	Indicate gyro current in mA	
	<p>Switch B 37 (DIP switch)</p> 	
12.17	Indicate operating voltage 15VDC	
	<p>Switch B 37 (DIP switch)</p> 	

**Installation and Service manual**  
**Compass STD 22**  
**Compass STD 22 Compact**





Serial No.	Indications	Comments, Information
12.18	<p>Indicate internal operating voltage 15VDC</p> <p>Switch B 37 (DIP switch)</p> <p>OPEN</p> 	
		<p>Indicate internal operating voltage 24VDC</p> <p>Switch B 37 (DIP switch)</p> <p>OPEN</p> 







**Installation and Service manual**  
**Compass STD 22**  
**Compass STD 22 Compact**







Compass  
STD 22









Serial No.	Indications	Comments, Information
12.20	Indicate pump voltage 24V 50Hz	
	<p>Switch B 37 (DIP switch)</p> 	
12.21	Indicate pump current	
	<p>Switch B 37 (DIP switch)</p> 	

# **Installation and Service manual** **Compass STD 22** **Compass STD 22 Compact**

Serial No.	Indications	Comments, Information
12.22	<p>Indicate tap voltage (direct encoder voltage)  Balancing voltage indication: approx. 512 (= approx. 5mV)</p> <p>Switch B 37 (DIP switch)  OPEN</p> 	 <p>Button B39 hold down: display in degree  Button B39 released again: display in a coded value (appr. 182 per degree)</p>
12.23	<p>Indicate program number and software version of the program for the microprocessor on the sensor PCB.</p> <p>Switch B 37 (DIP switch)  OPEN</p> 	

Serial No.	Indications	Comments, Information
12.24	<p>Indicate program number and software version of the program for the microprocessor on the sensor PCB.</p> <p>Switch B 37 (DIP switch)</p> 	
12.25	<p>Indicate program number and software version of the program for microprocessor <u>MC 1</u> on the outer sphere PCB.</p> <p>Switch B 37 (DIP switch)</p> 	





# **Installation and Service manual** **Compass STD 22** **Compass STD 22 Compact**

Serial No.	Indications	Comments, Information
12.26	<p>Indicate program number and software version of the program for microprocessor <u>MC 2</u> on the outer sphere PCB.</p> <p>Switch B 37 (DIP switch)</p> <p>OPEN</p>  <p>1 2 3 4 5 6 7 8</p> <p>↓</p> 	<p>B38</p>  <p>26X</p> <p>↓</p> <p>B39</p>  <p>1X</p>
12.27	<p>Operating hours meter (years)</p> <p>Switch B 37 (DIP switch)</p> <p>OPEN</p>  <p>1 2 3 4 5 6 7 8</p> <p>↓</p> 	<p>B38</p>  <p>27X</p> <p>↓</p> <p>B39</p>  <p>1X</p>




**Installation and Service manual**  
**Compass STD 22**  
**Compass STD 22 Compact**



Compass  
STD 22

Serial No.	Indications	Comments, Information
12.28	<p>Operating hours meter (hours)</p> <p>Switch B 37 (DIP switch)</p> 	
12.29 12.30	<p>In F7 In F8 Both functions are for future purpose</p> <p>Switch B 37 (DIP switch)</p> 	






# **Installation and Service manual** **Compass STD 22** **Compass STD 22 Compact**

Serial No.	Indications	Comments, Information																		
13	<p>Error logbook. Indication of errors and warnings, stating the frequency of occurrence.</p> <p>Switch B 37 (DIP switch)</p> 	 <table border="0"> <tr><td>B38</td><td>2x↓</td><td>E.L. 3</td></tr> <tr><td>B38</td><td>3x↓</td><td>E.L. 4</td></tr> <tr><td>B38</td><td>4x↓</td><td>E.L. 5</td></tr> <tr><td>B38</td><td>5x↓</td><td>E.L. 6</td></tr> <tr><td>B38</td><td>6x↓</td><td>E.L. 7</td></tr> <tr><td colspan="2"></td><td>.....24</td></tr> </table> <hr/> <p>Number of errors/warnings occurring</p> 	B38	2x↓	E.L. 3	B38	3x↓	E.L. 4	B38	4x↓	E.L. 5	B38	5x↓	E.L. 6	B38	6x↓	E.L. 7			.....24
B38	2x↓	E.L. 3																		
B38	3x↓	E.L. 4																		
B38	4x↓	E.L. 5																		
B38	5x↓	E.L. 6																		
B38	6x↓	E.L. 7																		
		.....24																		
To delete error logbook:		press button B39 for approximately 10 seconds. the actual indicated line is deleted.																		

**Installation and Service manual**  
**Compass STD 22**  
**Compass STD 22 Compact**



Compass  
STD 22

Serial No.	Indications	Comments, Information
14	<p>Delete Error logbook complete. Delete hours meter complete (hours and years)</p> <p>Switch B 37 (DIP switch)</p> 	<p>B38</p>  <p>1X</p> <p>Delete Error log complete</p> <p>B39</p>  <p>Hold, until Error log is deleted complete</p>
		<p>B38</p>  <p>2X</p> <p>Delete hour meter complete</p> <p>B39</p>  <p>Hold, until hour meter is deleted complete</p>

# Installation and Service manual

## Compass STD 22

### Compass STD 22 Compact

Information concerning the error logbook (see also section 7.1):













Error-code	Comment	Error group
E.L.01	Serial connection of sensor card to Power Supply PCB faulty	PCbP
E.L.02	Inductive transmission faulty	PCbP
E.L.03	System voltage (B5.5 $\Rightarrow$ B5.8) on Power Supply PCB faulty	PCbP
E.L.04	Encoder voltage faulty	PCbP
E.L.05	System voltage (B5.1 $\Rightarrow$ B5.4) on Power Supply PCB faulty	PCbP
E.L.06	Encoder faulty	PCbS
E.L.07	CAN dialogue from outer sphere PCB to sensor PCB faulty	PCbS
E.L.08	Follow-up system faulty	PCbS
E.L.09	CAN1 and CAN2 operating voltage faulty	PCbC
E.L.10	Supporting liquid error	PCbG
E.L.11	System voltage (B21.5 $\Rightarrow$ B21.8) on outer sphere PCB faulty	PCbG
E.L.12	Operating voltage 24V faulty	PCbG
E.L.13	Operating voltage 15V faulty	PCbG
E.L.14	Heating operating voltage (B21.1 $\Rightarrow$ B21.4) faulty	PCbG
E.L.15	Operating voltage 72V faulty	PCbG
E.L.16	Operating voltage 78V faulty for 400 Hz	PCbG
E.L.17	Gyro supply 55V <sub>eff</sub> faulty	PCbG
E.L.18	Gyro current faulty	PCbG
E.L.19	Pump voltage faulty	PCbG
E.L.20	Pump current faulty	PCbG
E.L.21	Temperature sensor faulty	PCbG
E.L.22	Serial interface MC1 to MC2 faulty	PCbG
E.L.23	CAN interface from sensor card to outer sphere PCB faulty	PCbG
E.L.24	Heating system faulty	PCbG

















### 5.1.5 Functional description of DIP switch settings (SEC)

All data stated below should be selected and read out for servicing purposes only.

In standard operation the following data has no significance.

Seq. no.	Indications	Comments, Notes
1	<p>UnCo = (<u>U</u>ncorrected <u>C</u>ompass) = course without speed error correction value.</p> <p>Switch B37 (DIP switch) OPEN</p>  <p>1 2 3 4 5 6 7 8</p> <p>↓</p> 	<p>Displays the uncorrected gyro course.</p>  <p>B38</p> <p>→</p>  <p>↓ ↑</p>  <p>Identical with Seq.no. 6</p>
2	<p>FF = <u>F</u>ahrt<u>E</u>ehler (Speed error) = the value by which the compass course is to be corrected (result from SEC), displayed in degrees, display value approx. max. 10° (see also number 3).</p> <p>Switch B37 (DIP switch) OPEN</p>  <p>1 2 3 4 5 6 7 8</p>	<p>B38</p>  <p>1x</p> <p>→</p>  <hr/> <p>B39</p>  <p>→</p>  <p>↓ ↑</p>  <p>The automatic Speed Error Correction function is defective. Speed or/and position faulty.</p> 










# **Installation and Service manual** **Compass STD 22** **Compass STD 22 Compact**

Seq. no.	Indications	Comments, Notes
3	<p>SPd = <u>S</u>peed = Ship's speed. This speed is provided from the connected and selected Log.  (see also number 5).  Displayed in knots, astern speed (- knots) is also possible.</p>	<div> <p>Switch B37 (DIP switch)</p> <p>OPEN</p>  <p>1 2 3 4 5 6 7 8</p> </div> <div> <p>B38</p>  <p>2x</p> <p>→</p>  </div> <hr/> <div> <p>B39</p>  <p>→</p>  <p>↓ ↑</p>  </div> <div> <p>Connected Log not providing any speed data.</p>  </div>
4	<p>br 10 = Latitude (<u>B</u>reite) at a resolution of <math>\frac{1}{10}^{\circ}</math>.</p>	<div> <p>Switch B37 (DIP switch)</p> <p>OPEN</p>  <p>1 2 3 4 5 6 7 8</p> </div> <div> <p>B38</p>  <p>3x</p> <p>→</p>  </div> <hr/> <div> <p>B39</p>  <p>→</p>  <p>↓ ↑</p>  </div> <div> <p>No latitude data available (GPS-receiver defective).</p>  </div>







# Installation and Service manual Compass STD 22 Compass STD 22 Compact













Compass  
STD 22












Seq. no.	Indications	Comments, Notes
5	<p>Corr = <u>Corrected</u> course (course taking SEC into account).</p> <p>Switch B37 (DIP switch)</p> <p>OPEN</p>  <p>1 2 3 4 5 6 7 8</p>	<p>B38</p>  <p>4x</p>  <p>↓ ↑</p>  <p>The automatic Speed Error Correction function is defective. Speed or/and position faulty.</p> 
6	<p>_roh = <u>Rough</u> course (course without SEC).</p> <p>Switch B37 (DIP switch)</p> <p>OPEN</p>  <p>1 2 3 4 5 6 7 8</p>	<p>B39</p>  <p>5x</p>  <p>↓ ↑</p>  <p>Identical with Seq.no. 1</p>

**Installation and Service manual**  
**Compass STD 22**  
**Compass STD 22 Compact**

Seq. no.	Indications	Comments, Notes
7	<p>o_FF = Speed Error (FahrtEehler) + acceleration error. Indicated in degrees.</p> <p>Switch B37 (DIP switch)</p> <p>OPEN</p>  <p>1 2 3 4 5 6 7 8</p>	<p>B39</p>  <p>6x</p> <hr/> <p>B38</p>  <p>The automatic Speed Error Correction function is defective. Speed or/and position faulty.</p>
8	<p>_FF = Speed Error (FahrtEehler) without acceleration error. Indicated in degrees.</p> <p>Switch B37 (DIP switch)</p> <p>OPEN</p>  <p>1 2 3 4 5 6 7 8</p>	<p>B38</p>  <p>7x</p> <hr/> <p>B39</p>  <p>The automatic Speed Error Correction function is defective. Speed or/and position faulty.</p>

Seq. no.	Indications	Comments, Notes
9	<p>_oF = Acceleration Error (<u>Q</u>elrestfehler) (no speed error components).</p> <p>Switch B37 (DIP switch)</p> <p>OPEN</p>  <p>1 2 3 4 5 6 7 8</p>	<p>B39</p>  <p>8x</p>  <hr/> <p>B38</p>   <p>The automatic Speed Error Correction function is defective. Speed or/and position faulty.</p>
10	<p>Sci = Serial Interface (<u>S</u>chnittstelle), telegram traffic on serial interface.</p> <p>Switch B37 (DIP switch)</p> <p>OPEN</p>  <p>1 2 3 4 5 6 7 8</p>	<p>B39</p>  <p>9x</p>  <hr/> <p>B38</p>  <p>Contents alternate</p>  <p>Digit 2: NMEA interface (Speed in)          Digit 1: GPS-reciver interface          Digit 0: Sum of all telegrams on both interfaces</p>















# **Installation and Service manual** **Compass STD 22** **Compass STD 22 Compact**

Seq. no.	Indications	Comments, Notes
11	<p>SrC.S = <u>Source Speed Information</u>.  Data about the source providing the speed value.</p> <p>Switch B37 (DIP switch)</p> <p style="text-align: center;">OPEN</p>  <p style="text-align: center;">1 2 3 4 5 6 7 8</p>	<div style="display: flex; align-items: center;">  <div style="margin-left: 20px;"> <p>→</p>  </div> </div> <hr style="border-top: 1px dashed black;"/> <div style="display: flex; align-items: center;">  <div style="margin-left: 20px;"> <p>→</p>  <p>↓ ↑</p>  </div> </div> <p style="text-align: center;">Display options:</p> <div style="display: flex; justify-content: space-around;"> <div style="border: 1px solid black; padding: 2px; font-family: monospace; font-size: 1.2em;">PULS</div> <div style="border: 1px solid black; padding: 2px; font-family: monospace; font-size: 1.2em;">vTg</div> <div style="border: 1px solid black; padding: 2px; font-family: monospace; font-size: 1.2em;">uhW.</div> </div> <p> PULS = Pulse Log  vTg = Speed over ground  vhW = Speed trough water </p> <p>(vTg and vhW corresponds to NMEA 0183)</p>
12	<p>PULS = Speed value from Pulse Log.  Indicated in Kts.  Displays -no- if no Pulse Log selected or connected.  Displays 0000 if there is no input from selected source.  Display range -80 Kts to +80 Kts (astern and ahead)</p> <p>Switch B37 (DIP switch)</p> <p style="text-align: center;">OPEN</p>  <p style="text-align: center;">1 2 3 4 5 6 7 8</p>	<div style="display: flex; align-items: center;">  <div style="margin-left: 20px;"> <p>→</p>  </div> </div> <hr style="border-top: 1px dashed black;"/> <div style="display: flex; align-items: center;">  <div style="margin-left: 20px;"> <p>→</p> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; padding: 2px; font-family: monospace; font-size: 1.2em;">000.0</div> <div style="margin: 0 5px;">or</div> <div style="border: 1px solid black; padding: 2px; font-family: monospace; font-size: 1.2em;">-no-</div> </div> <p>↓ ↑</p>  </div> </div>












**Installation and Service manual**  
**Compass STD 22**  
**Compass STD 22 Compact**



Compass  
STD 22

Seq. no.	Indications	Comments, Notes
13	<p>vtG.S = Speed from GPS-receiver telegram (speed over ground).</p> <p>Switch B37 (DIP switch)</p> <p>OPEN</p>  <p>1 2 3 4 5 6 7 8</p>	<div style="display: flex; align-items: center;">  <div style="margin-left: 20px;">  </div> </div> <hr style="border-top: 1px dashed black;"/> <div style="display: flex; align-items: center;">  <div style="margin-left: 20px;">  <div style="text-align: center; margin: 5px;">             ↓ ↑           </div>  </div> </div> <div style="margin-top: 10px;"> <p>No, or faulty data from GPS-receiver (vTg- telegram).</p>  </div>
14	<p>vtG.h = Course value from GPS-receiver telegram</p> <p>Switch B37 (DIP switch)</p> <p>OPEN</p>  <p>1 2 3 4 5 6 7 8</p>	<div style="display: flex; align-items: center;">  <div style="margin-left: 20px;">  </div> </div> <hr style="border-top: 1px dashed black;"/> <div style="display: flex; align-items: center;">  <div style="margin-left: 20px;">  <div style="text-align: center; margin: 5px;">             ↓ ↑           </div>  </div> </div> <div style="margin-top: 10px;"> <p>No, or faulty data from GPS-receiver (vTg- telegram).</p>  </div>

# **Installation and Service manual** **Compass STD 22** **Compass STD 22 Compact**

Seq. no.	Indications	Comments, Notes
15	<p>vhw = Speed value in knots from NMEA telegram VHW (speed through water).</p>	
	<p>Switch B37 (DIP switch)</p> <p style="text-align: center;"><b>OPEN</b></p>  <p style="text-align: center;">1 2 3 4 5 6 7 8</p>	<div style="display: flex; align-items: center;">  <div style="margin-left: 20px;"> <p><b>B39</b></p> <p>14x</p> </div> <div style="margin-left: 20px;"> <p>→</p>  </div> </div> <hr style="border-top: 1px dashed black;"/> <div style="display: flex; align-items: center;">  <div style="margin-left: 20px;"> <p><b>B38</b></p> </div> <div style="margin-left: 20px;"> <p>→</p>  </div> </div> <p>No, or faulty serial speed data (vHw- telegram).</p> 
16	<p>SPd.L = Speed in knots (from Log).  The speed for which the source has been selected, is displayed.  The display alternates between 099.0 (=accepting value) and, say, 052.8 (speed in knots). If no value is accepted (transferred) the display stays at 099.0.</p>	
	<p>Switch B37 (DIP switch)</p> <p style="text-align: center;"><b>OPEN</b></p>  <p style="text-align: center;">1 2 3 4 5 6 7 8</p>	<div style="display: flex; align-items: center;">  <div style="margin-left: 20px;"> <p><b>B38</b></p> <p>15x</p> </div> <div style="margin-left: 20px;"> <p>→</p>  </div> </div> <hr style="border-top: 1px dashed black;"/> <div style="display: flex; align-items: center;">  <div style="margin-left: 20px;"> <p><b>B38</b></p> </div> <div style="margin-left: 20px;"> <p>→</p>  </div> </div> <p>If the display changes value (similar as shown), there is a data transfer on this interface. No change (constant 99.0) means there is no data transfer</p>









**Installation and Service manual**  
**Compass STD 22**  
**Compass STD 22 Compact**



Compass  
STD 22

Seq. no.	Indications	Comments, Notes																								
17	<p>PoS = Position – latitude in degrees.</p> <p>Switch B37 (DIP switch)</p> <p>OPEN</p> <p>1 2 3 4 5 6 7 8</p>	<div style="display: flex; align-items: center;"> <span style="margin: 0 10px;">→</span> </div> <p style="text-align: center;">16x</p> <hr style="border-top: 1px dashed black;"/> <div style="display: flex; align-items: center;"> <span style="margin: 0 10px;">→</span> </div> <div style="text-align: center; margin: 5px 0;">       ↓ ↑  </div> <div style="display: flex; align-items: center;"> <p>No latitude data available (GPS-receiver defective).</p> <span style="margin: 0 10px;">→</span> </div>																								
18	<p>ASPd = Alarm “speed”</p> <p>Switch B37 (DIP switch)</p> <p>OPEN</p> <p>1 2 3 4 5 6 7 8</p>	<div style="display: flex; align-items: center;"> <span style="margin: 0 10px;">→</span> </div> <p style="text-align: center;">17x</p> <hr style="border-top: 1px dashed black;"/> <div style="display: flex; align-items: center;"> <span style="margin: 0 10px;">→</span> </div> <div style="text-align: center; margin: 5px 0;">       3 2 1 0        ↓ ↑  </div>																								
	<table> <tr> <td>Digit 3 “Speed OK”</td><td>Display 1</td><td>Speed OK</td></tr> <tr> <td></td><td>Display 0</td><td>Speed not OK</td></tr> <tr> <td>Digit 2 “Speed Alarm</td><td>Display 1</td><td>Speed Alarm</td></tr> <tr> <td></td><td>Display 0</td><td>No Speed Alarm</td></tr> <tr> <td>Digit 1 “Auto Speed OK”</td><td>Display 1</td><td>Auto Speed OK</td></tr> <tr> <td></td><td>Display 0</td><td>Auto Speed not OK</td></tr> <tr> <td>Digit 0 “Auto Alarm”</td><td>Display 1</td><td>Auto Speed Alarm</td></tr> <tr> <td></td><td>Display 0</td><td>No Auto Speed Alarm</td></tr> </table>	Digit 3 “Speed OK”	Display 1	Speed OK		Display 0	Speed not OK	Digit 2 “Speed Alarm	Display 1	Speed Alarm		Display 0	No Speed Alarm	Digit 1 “Auto Speed OK”	Display 1	Auto Speed OK		Display 0	Auto Speed not OK	Digit 0 “Auto Alarm”	Display 1	Auto Speed Alarm		Display 0	No Auto Speed Alarm	
Digit 3 “Speed OK”	Display 1	Speed OK																								
	Display 0	Speed not OK																								
Digit 2 “Speed Alarm	Display 1	Speed Alarm																								
	Display 0	No Speed Alarm																								
Digit 1 “Auto Speed OK”	Display 1	Auto Speed OK																								
	Display 0	Auto Speed not OK																								
Digit 0 “Auto Alarm”	Display 1	Auto Speed Alarm																								
	Display 0	No Auto Speed Alarm																								









# **Installation and Service manual** **Compass STD 22** **Compass STD 22 Compact**

Seq. no.	Indications	Comments, Notes
19	<p>PoS<sub>n</sub> = Latitude value derived from automatic latitude input. Indicated in degrees.</p> <p>Switch B37 (DIP switch)</p> <p>OPEN</p>  <p>1 2 3 4 5 6 7 8</p>	<p>B39</p>  <p>18x</p> <hr/> <p>B38</p>  <p>If the display changes value (similar as shown), there is a data transfer on this interface. No change (constant 099.9) means there is no data transfer</p>
20	<p>APoS = Alarm position input</p> <p>Switch B37 (DIP switch)</p> <p>OPEN</p>  <p>1 2 3 4 5 6 7 8</p>	<p>B39</p>  <p>19x</p> <hr/> <p>B38</p>  <p>0001 = no position (alarm) 1100 = position o.k.</p>













**Installation and Service manual**  
**Compass STD 22**  
**Compass STD 22 Compact**


















Compass  
STD 22









Seq. no.	Indications	Comments, Notes
21	<p>nAUC = Number of telegrams with checksum.</p> <p>Switch B37 (DIP switch) OPEN</p>  <p>1 2 3 4 5 6 7 8</p>	<p>B39</p>  <p>20x</p> <p>B38</p>  <p>1st digit = number of decoder requests 2nd digit = number of read-in NMEA-telegrams with correct check sum</p> 
22	<p>nAn1 = 1st table for NMEA-requests</p> <p>Switch B37 (DIP switch) OPEN</p>  <p>1 2 3 4 5 6 7 8</p>	<p>B39</p>  <p>21x</p> <p>B38</p>  <p>L = telegram type GLL G = telegram type GGA t = telegram type VTG h = telegram type VHW 1st digit = number of L-types 2nd digit = number of G-types 3rd digit = number of t-types 4th digit = number of h-types</p> 











# **Installation and Service manual** **Compass STD 22** **Compass STD 22 Compact**

Seq. no.	Indications	Comments, Notes
23	<p>nAn2 = 2nd table for NMEA-requests</p> <p>Switch B37 (DIP switch) OPEN</p>  <p>1 2 3 4 5 6 7 8</p>	<div> <p>B39</p>  <p>22x</p> <p>⇒ </p> </div> <hr/> <div> <p>B38</p>  <p>1x</p> <p>⇒ </p> </div> <div> <p>B38</p>  <p>1x</p> <p>⇒ </p> </div> <p>b = telegram type VBW  l = telegram type SLL  1st digit = number of b-types  2nd digit = number of l-types</p>
24	<p>nSGG = NMEA-telegram (Strings of the GGA-telegram)</p> <p>Switch B37 (DIP switch) OPEN</p>  <p>1 2 3 4 5 6 7 8</p>	<div> <p>B39</p>  <p>23x</p> <p>⇒ </p> </div> <hr/> <div> <p>B38</p>  <p>1x</p> <p>⇒ </p> <p>Number of ASCII-characters per telegram  0000 = no telegram</p> <p>The number of operations depends on the number of characters.  (1 display content = max. 4 ASCII-character)</p> <p><b>See sequ. no 25</b></p> </div>











Seq. no.	Indications	Comments, Notes
25	<p>nSGL = NMEA-telegram (Strings of the GLL-telegram)</p> <p>Switch B37 (DIP switch) OPEN</p>  <p>1 2 3 4 5 6 7 8</p>	<p>B39</p>  <p>24x</p>  <hr/> <p>B38</p>  <p>1x</p> <p>Example:</p>  <p>Length of the telegram = 44 ASCII-characters</p> <p>B38</p>  <p>2x</p>  <p>B38</p>  <p>3x</p>  <p>B38</p>  <p>4x</p>  <p>B38</p>  <p>5x</p>  <p>B38</p>  <p>6x</p> 

# Installation and Service manual Compass STD 22 Compass STD 22 Compact











Seq. no.	Indications	Comments, Notes
cont. 25	nSGL = NMEA-telegram (Strings of the GLL-telegram)	
	<p>Switch B37 (DIP switch) OPEN</p>  <p>1 2 3 4 5 6 7 8</p>	<p>B39</p>  <p>24x</p> <hr/> <p>B38</p>  <p>7x</p> <p>B38</p>  <p>8x</p> <p>B38</p>  <p>9x</p> <p>B38</p>  <p>10x</p> <p>B38</p>  <p>11x</p> <p>B38</p>  <p>12x</p> <p>Checksum</p>

Seq. no.	Indications	Comments, Notes
cont. 25	nSGL = NMEA-telegram (Strings of the GLL-telegram)	
	<p>Switch B37 (DIP switch) OPEN</p>  <p>1 2 3 4 5 6 7 8</p>	<div style="display: flex; align-items: center;">  <div style="margin-left: 20px;"> <p>B39</p> <p>24x</p> </div> <div style="margin-left: 20px;"> <p>⇒</p>  </div> </div> <hr style="border-top: 1px dashed black;"/> <div style="display: flex; align-items: center;">  <div style="margin-left: 20px;"> <p>B38</p> <p>13x</p> </div> <div style="margin-left: 20px;"> <p>⇒</p>  </div> </div>
	<p>With the 1st operation of the contact switch B38, the number of ASCII-characters is displayed.          If the display shows "0000", no telegram-output took place.          With every further operation of contact switch B38, 4 consecutive ASCII-characters are displayed.</p>	
26	nSLL = NMEA-telegram (Strings of the SLL-telegram)	
	<p>Switch B37 (DIP switch) OPEN</p>  <p>1 2 3 4 5 6 7 8</p>	<div style="display: flex; align-items: center;">  <div style="margin-left: 20px;"> <p>B39</p> <p>25x</p> </div> <div style="margin-left: 20px;"> <p>⇒</p>  </div> </div> <hr style="border-top: 1px dashed black;"/> <div style="display: flex; align-items: center;">  <div style="margin-left: 20px;"> <p>B38</p> <p>1x</p> </div> <div style="margin-left: 20px;"> <p>⇒</p>  </div> </div> <p style="margin-top: 10px;">Number of ASCII-characters per telegram 0000 = no telegram</p> <p style="margin-top: 10px;">The number of operations depends on the number of characters. (1 display content = max. 4 ASCII-characters)</p> <p style="margin-top: 10px;"><b>See seq. no. 25</b></p>











# **Installation and Service manual** **Compass STD 22** **Compass STD 22 Compact**















Seq. no.	Indications	Comments, Notes
27	<p>nShw = NMEA-telegram (Strings of the VHW-telegram)</p> <p>Switch B37 (DIP switch) OPEN</p>  <p>1 2 3 4 5 6 7 8</p>	<div style="display: flex; justify-content: space-between;"> <div style="width: 45%;"> <p>B39</p>  <p>26x</p> </div> <div style="width: 45%;">  </div> </div> <hr style="border-top: 1px dashed black;"/> <div style="display: flex; justify-content: space-between;"> <div style="width: 45%;"> <p>B38</p>  <p>1x</p> </div> <div style="width: 45%;">  <p>Number of ASCII-characters per telegram 0000 = no telegram</p> </div> </div> <p>The number of operations depends on the number of characters. (1 display content = max. 4 ASCII-characters)</p> <p><b>See seq. no. 25</b></p>
28	<p>nStG = NMEA-telegram (Strings of the VTG-telegram)</p> <p>Switch B37 (DIP switch) OPEN</p>  <p>1 2 3 4 5 6 7 8</p>	<div style="display: flex; justify-content: space-between;"> <div style="width: 45%;"> <p>B39</p>  <p>27x</p> </div> <div style="width: 45%;">  </div> </div> <hr style="border-top: 1px dashed black;"/> <div style="display: flex; justify-content: space-between;"> <div style="width: 45%;"> <p>B38</p>  <p>1x</p> </div> <div style="width: 45%;">  <p>Number of ASCII-characters per telegram 0000 = no telegram</p> </div> </div> <p>The number of operations depends on the number of characters. (1 display content = max. 4 ASCII-characters)</p> <p><b>See seq. no. 25</b></p>






Seq. no.	Indications	Comments, Notes
29	<p>nSbw = NMEA-telegram (String of the VBW-telegram)</p> <p>Switch B37 (DIP switch) OPEN</p>  <p>1 2 3 4 5 6 7 8</p>	<p>B39</p>  <p>28x</p> <p>⇒ </p> <hr/> <p>B38</p>  <p>1x</p> <p>⇒ </p> <p>Number of ASCII-characters per telegram 0000 = no telegram</p> <p>The number of operations depends on the number of characters. (1 display content = max. 4 ASCII-characters)</p> <p><b>See seq. no. 25</b></p>
30	<p><b>Development only!</b></p> <p>Fb10 = Software component of speed error correction: Latitude</p> <p>Switch B37 (DIP switch) OPEN</p>  <p>1 2 3 4 5 6 7 8</p>	<p>B39</p>  <p>29x</p> <p>⇒ </p> <hr/> <p>B38</p>  <p>⇒ </p> <p>Latitude</p>

**Installation and Service manual**  
**Compass STD 22**  
**Compass STD 22 Compact**

Seq. no.	Indications	Comments, Notes
31	<b>Development only!</b> FS10 = Software component speed error correction: Ship's speed	
	Switch B37 (DIP switch) <b>OPEN</b>  1 2 3 4 5 6 7 8	<div>           B39   30x   </div> <hr/> <div>           B38                Ship's speed (kn)         </div>
32	<b>Development only!</b> FnSP = Software component speed error correction: North-component of the ship's-speed-vector	
	Switch B37 (DIP switch) <b>OPEN</b>  1 2 3 4 5 6 7 8	<div>           B39   31x   </div> <hr/> <div>           B38                North-component of the ship's-speed-vector            (with negative sign = south component)         </div>

Seq. no.	Indications	Comments, Notes
33	<p style="text-align: center;"><b>Development only!</b></p> <p>FutG = Software component speed error correction: Course over ground (Value of the VTG-telegram)</p>	
	<p>Switch B37 (DIP switch) OPEN</p>  <p style="text-align: center;">1 2 3 4 5 6 7 8</p>	<div style="display: flex; align-items: center;"> <div style="margin-right: 10px;"> <p>B39</p>  <p>32x</p> </div> <div style="text-align: center;"> <p>⇒</p>  </div> </div> <hr style="border-top: 1px dashed black;"/> <div style="display: flex; align-items: center;"> <div style="margin-right: 10px;"> <p>B38</p>  </div> <div style="text-align: center;"> <p>⇒</p>  <p>0000 = no telegram 123.4 = course value</p> </div> </div>
34	<p>time = Time since activating speed error correction. (Reset with power-off)</p>	
	<p>Switch B37 (DIP switch) OPEN</p>  <p style="text-align: center;">1 2 3 4 5 6 7 8</p>	<div style="display: flex; align-items: center;"> <div style="margin-right: 10px;"> <p>B39</p>  <p>33x</p> </div> <div style="text-align: center;"> <p>⇒</p>  </div> </div> <hr style="border-top: 1px dashed black;"/> <div style="display: flex; align-items: center;"> <div style="margin-right: 10px;"> <p>B38</p>  <p>1x</p> </div> <div style="text-align: center;"> <p>⇒</p>  </div> </div> <div style="display: flex; align-items: center; margin-top: 10px;"> <div style="margin-right: 10px;"> <p>B38</p>  <p>2x</p> </div> <div style="text-align: center;"> <p>⇒</p>  </div> </div> <div style="display: flex; align-items: center; margin-top: 10px;"> <div style="margin-right: 10px;"> <p>B38</p>  <p>3x</p> </div> <div style="text-align: center;"> <p>⇒</p>  </div> </div>

# **Installation and Service manual** **Compass STD 22** **Compass STD 22 Compact**

Seq. no.	Indications	Comments, Notes
35	<p style="text-align: center;"><b>Development only!</b></p> <p>SCI . = Serial Communication Interface (NMEA Log / GPS input)</p> <hr/> <div style="display: flex; justify-content: space-between;"> <div style="width: 45%;"> <p>Switch B37 (DIP switch) <b>OPEN</b></p>  <p style="text-align: center;">1 2 3 4 5 6 7 8</p> </div> <div style="width: 50%;"> <div style="margin-bottom: 20px;"> <p>B39</p>  <p>34x</p> </div> <hr style="border-top: 1px dashed black;"/> <div> <p>B38</p>  </div> </div> </div> <p>The content of the two digits is during a data transfer unrecognisable.  Just the digits <math>1_{(16)}</math> and <math>0_{(16)}</math> are visible for a short moment; <math>10_{(16)}</math> means line feed.  All other sequentially indicated values are for development purpose only.</p>	

## **6 Tasks to be performed regularly**

A task to perform regularly is to clean the internal of the gyro compass time by time.  
Especially the bottom filter has to be cleaned.

### **6.1 Changing the supporting liquid and distilled water**

At 18 months intervals the supporting liquid and distilled water must be changed.



The supporting liquid and distilled water must not be changed whilst at sea  
(except in the case of dual systems).

#### Tools/special tools required:

- Filling device
- Injector

#### Spare parts required:

- Supporting liquid
- Distilled water

#### If required:

- Screw (distilled water)
- Screw (supporting liquid)
- Screw (ventilation)

#### **6.1.1 Removing the outer sphere from the compass enclosure**

- Wait min. 15 minutes until the gyrosphere does not turn any more.
- Turn off the 24V power supply of the gyro compass and secure it against reconnecting.
- Undo the two screws at the top and bottom of the door of the gyro compass enclosure and lift out the door, paying attention to the earthing strip.
- Remove the plug from the outer sphere (see Figure 66/2).

# Installation and Service manual

## Compass STD 22

### Compass STD 22 Compact

---




Figure 66: Dismantling the outer sphere

- Place both hands (see Figure 66/1 ) under 2 of the 4 snap closures and release them by pressing with the thumbs.
- Carefully turn the outer sphere through 90° and repeat the process with the other two snap closures. The outer sphere is now free and can be removed.
- Still holding the outer sphere with both hands, lower it slightly (this releases the locking device), carefully remove it from the compass enclosure and set it down.




Figure 67: Dismantled outer sphere (overhead view)

#### 6.1.1.1 Draining the supporting liquid and distilled water

(see Figure 67)

- Remove the ventilation screw (Figure 67/1) to vent the system
- Remove the supporting liquid screw (Figure 67/2) so that the supporting liquid can be poured out
- Holding the outer sphere with both hands, pour out the supporting liquid and throw it away (no special measures are needed for disposal).
- Remove the distilled water screw (Figure 67/3), so that the distilled water can be poured out. Remove the remaining distilled water from the outer sphere with the injector.

## Installation and Service manual


### Compass STD 22

### Compass STD 22 Compact


---



- Used supporting liquid and used distilled water must not be reused.
  - All the following tasks on the outer sphere must be carried out slowly. On no account do them jerkily. Slow handling is necessary, because otherwise the gyrosphere will fail to float in the supporting liquid, and jerky movements will cause it to strike against the inner wall of the outer sphere. There is a risk of damage. Continue to handle in this way until you have finished filling with the new liquids.
- 
- After pouring out the liquids (distilled water and supporting liquid) for the first time, **slowly** return the outer sphere to the initial position.
  - Wait approximately 3 to 5 minutes (until the remaining content of the distilled water container has flowed into the outer sphere) and then carefully repeat the pouring out process. If necessary, use the injector to suck out the remaining distilled water through the distilled water filling opening.
  - Attach the filling device to the distilled water bottle and pour the entire contents (230cm<sup>3</sup>) into the distilled water filling opening (look for the identifying label).
  - Close the distilled water filling opening with the screw. Use a new sealing ring.
  - Attach the filling device to the supporting liquid bottle and pour the supporting liquid (840cm<sup>3</sup>) into the supporting liquid filling opening (look for the identifying label).
  - Check the liquid level at the measuring cone (Figure 67/1).
  - Using the injector, top up or suck out supporting liquid (check via the measuring cone) until the "liquid level: OK" is reached.
  - Close the distilled water filling opening with the screw. Use a new sealing ring.



Liquid level: OK  
(cold supporting liquid)



Liquid level: too low

Figure 68: Measuring cone (top view)



- Close the distilled water filling opening with the screw.  
Use a new sealing ring.
- Place the outer sphere in the compass enclosure.



- Pay attention to the two locking pins (Figure 67/4) on the closure.

- Hold the outer sphere with both hands and guide it under the snap closures on the pendulum joint.
- Using the thumbs, press down and engage the two snap closures.
- Carefully turn the outer sphere through 90° and repeat the process with the other two snap closures. The outer sphere is now fastened to the pendulum joint.
- Guide the cable with the plug to the left around the outer sphere and plug it in as shown in (Figure 66/2).
- Close the door of the enclosure and fasten it with screws, paying attention to the earthing strip.

When the power supply is switched on, the compass is ready for use again. Run the heating and settling in stage as described in section 3.4.3.2.

# Installation and Service manual

## Compass STD 22

### Compass STD 22 Compact

---

## 7 Error messages and warnings

### 7.1 Error messages

An error is indicated in the digital display of the compass by a flashing “Erro” (for error).





Figure 69: “Error message” in digital display

# **Installation and Service manual** **Compass STD 22** **Compass STD 22 Compact**



Compass  
STD 22

Following error groups can be displayed:

- PCbP = Error on Power Supply PCB
- PCbS = Error on sensor PCB
- PCbC = Error on connection PCB
- PCbG = Error on outer sphere PCB

Following error codes are possible (referring to their error group):

Error-log	Comment	Error group
E.L.01	Serial connection of Sensor PCB to Power Supply PCB faulty	PCbP
E.L.02	Inductive transmission faulty	PCbP
E.L.03	System voltage (B5.5 $\Rightarrow$ B5.8) on Power Supply PCB faulty	PCbP
E.L.04	Encoder voltage faulty	PCbP
E.L.05	System voltage (B5.1 $\Rightarrow$ B5.4) on Power Supply PCB faulty	PCbP
E.L.06	Encoder faulty	PCbS
E.L.07	CAN dialogue from outer sphere PCB to sensor PCB faulty	PCbS
E.L.08	Follow-up system faulty	PCbS
E.L.09	CAN1 and CAN2 operating voltage faulty	PCbC
E.L.10	Supporting liquid error	PCbG
E.L.11	System voltage (B21.5 $\Rightarrow$ B21.8) on sensor PCB faulty	PCbG
E.L.12	Operating voltage 24V faulty	PCbG
E.L.13	Operating voltage 15V faulty	PCbG
E.L.14	Heating operating voltage (B21.1 $\Rightarrow$ B21.4) faulty	PCbG
E.L.15	Operating voltage 72V faulty	PCbG
E.L.16	Operating voltage 78V faulty for 400 Hz	PCbG
E.L.17	Gyro supply 55V <sub>eff</sub> faulty	PCbG
E.L.18	Gyro current faulty	PCbG
E.L.19	Pump voltage faulty	PCbG
E.L.20	Pump current faulty	PCbG
E.L.21	Temperature sensor faulty	PCbG
E.L.22	Serial interface MC1 to MC2 faulty	PCbG
E.L.23	CAN interface from outer sphere PCB to sensor PCB faulty	PCbG
E.L.24	Heating system faulty	PCbG

To delete the content of the error log book, see section 5.1.4 Nr. 14

# Installation and Service manual

## Compass STD 22

### Compass STD 22 Compact

---

## 7.2

### Warnings

Warning indicate a malfunction during operational use.

The heading continues to be displayed.

A warning is indicated by a flashing decimal point.




Figure 70: DIP switch B37 and button B38/B39



The following warnings may appear:

- C1= Fan failure
- C2= Heater failure
- C3= Supporting liquid > 60°C
- C4= Supporting liquid level too low
- C5= Voltage cut-off

### **7.2.1 Warning 1 “Fan failure”**

This warning is generated if the fan does not switch itself on as a result of the temperature of the supporting liquid (it should switch on when the supporting liquid reaches 51°C).

Whether the fan is operational or not is registered from the fan's current consumption; it therefore follows that the fan is defective if this warning is displayed.

To prevent overheating due to fan failure, it is recommended that you do the following:

- Check whether the fan screen is covered and check to see that air can enter the enclosure unhindered at the base.
- Open the door on the compass
- If necessary cool the outer sphere using an external fan.

These measures should be continued until warning 1 stops.

**It is essential that the fan be replaced at the earliest opportunity.**

NOTE: A critical situation occurs, if the ambient temperature is extremely high and warning 3 is displayed “Temperature of supporting liquid more than 60°C”. Constant high temperature may effects to the life cycle of the gyro compass. A higher temperature for a short moment has no importance.

# Installation and Service manual

## Compass STD 22

### Compass STD 22 Compact

---

#### 7.2.2 Warning 2 “Heater failure”

This warning is output when the heater ( $\geq 45^{\circ}\text{C}$ ) has failed.

Compass operation is not restricted if the temperature is more than  $45^{\circ}\text{C}$  (see also warning “fan failure”).

A temperature drop down below  $45^{\circ}\text{C}$  leads to an error message “Error” and the heading information will not longer displayed ( as well as the heading information to the connected heading receivers).

To prevent the supporting liquid from cooling further, it is recommended that to do the following:

- Close the door on the compass, or
- introduce warm air.

These measures should be continued until warning 2 stops.

**It is essential that the heater be repaired at the earliest opportunity.**

#### 7.2.3 Warning 3 “Supporting liquid $> 60^{\circ}\text{C}$ ”

This warning is output when the temperature of the supporting liquid is higher than  $60^{\circ}\text{C}$ .

To prevent the temperature from rising further, it is recommended that you do the following:

- Open the door on the compass
- If necessary cool the outer sphere using an external fan.
- Check the ambient temperature. If the ambient temperature is higher than  $60^{\circ}\text{C}$  steps should be taken to cool it down.

These measures should be continued until warning 3 stops.

**If warning 3 is displayed in combination with warning 1, the fan must be replaced at the earliest opportunity.**

See also warning “fan failure”



#### **7.2.4      Warning 4 “Supporting liquid level too low”**

This warning is output when the level of the supporting liquid in the outer sphere is too low. The supporting liquid is determined by an immersion probe installed in the upper part of the outer sphere.

You must check the supporting liquid immediately and if necessary top up with distilled water - only distilled water - (one 240cm<sup>2</sup> bottle) in to the ventilation outlet until the measuring cone shows the desired level, the remaining content of the bottle has to be filled into the inlet for distilled water, see service manual).

This measure does not compensate the planned replacement of the supporting liquid!!! In certain circumstances (if the level of the supporting liquid falls suddenly) you must establish the cause (possibly a leak) and correct the fault.

If the level of supporting liquid is too low, the gyro-current is interrupted and an Error is displayed, the heading information will not longer displayed ( as well as the heading information to the connected heading receivers).

Please note: At the Operator Unit for Gyro compass STD 20 this warning is shown as C4 “Temperature”.

#### **7.2.5      Warning 5 “Voltage cut-off”**

This warning is output if the supply voltage is cut off for a short time. The cut-off period is determined by the fall in supporting liquid temperature. If the temperature falls below 45°C the compass recognises that the voltage supply has been switched off in the conventional way.

In the case of a voltage cut-off (supporting liquid temperature does not fall to below 45°C) and the voltage supply has been restored, the settling stage is indicated again (see also section 3.4.3.2 “Compass indications during the settling stage”).

Note:    Heading indication can be incorrect. Wait for a complete follow up,  
            Check voltage supply to the gyro compass!

# Installation and Service manual Compass STD 22 Compass STD 22 Compact

8


## NMEA-Formats

•

### NMEA 0183 Format GGA

GGA⇒Global Positioning System Fix Data


**\$--GGA,hhmmss.ss,IIII.II,a,yyyyy.yy,a,x,xx,x.x,x.x,M,x.x,M,x.x,xxxx\*\*hh<CR><LF>**



### • NMEA 0183 Format GLL

GLL ⇒ Geopgrhic Position - Latitude/Longitude

**\$--GLL,IIII.II,a,yyyyy.yy,a,hhmmss.ss,A,a\*\*hh<CR><LF>**








# Installation and Service manual Compass STD 22 Compass STD 22 Compact

---

- **NMEA 0183 Format VHW**

VHW⇒ Water Speed and Heading

**\$--VHW,x.x,T,x.x,M,x.x,N,x.x,K\*hh<CR><LF>**



Speed, km/hr  
Speed, knots  
Heading, degrees Magnetic  
Heading, degrees True  
Talker

**Installation and Service manual**  
**Compass STD 22**  
**Compass STD 22 Compact**



Compass  
STD 22

---

intentionally left blank

# Installation and Service manual Compass STD 22 Compass STD 22 Compact




Kompaß  
STD 22

Kreiselkompaß STD.22  
Gyro Compass STD.22  
Type 110-233.NG001



Ersatzteilkatalog  
SPARE PARTS  
CATALOGUE




14.617

# Installation and Service manual Compass STD 22 Compass STD 22 Compact

Kreiselkompaß STD.22  
Gyro Compass STD.22  
Type 110-233.NG001



Ersatzteilkatalog  
SPARE PARTS  
CATALOGUE



# Installation and Service manual


## Compass STD 22

### Compass STD 22 Compact



Kompaß  
STD 22

Kreiselkompaß STD.22  
Gyro Compass STD.22  
Type 110-233.NG001



Ersatzteilkatalog  
SPARE PARTS  
CATALOGUE

Pos.	Lager-Nr. Stock-No.	Benennung	Designation	Zeichnungs-Nr. Part-No.	Stck. Qty.	Herst.-Code MFRC	Versorgungs-Nr. NSN
1	3604361	SPG-Versorgung	Power Supply PCB	110-233.102	1	D2865	
2	3604352	Anschluss-PCB	Connection PCB	NB 05-356	1	D2865	
3	3604660	Sensor-PCB	Sensor PCB	110-233.X08	1	D2865	
4	1762140	G-Sicherungseinsatz	Fuse	T 10 A L 250V 19195	1	D8882	5920-12-314-2556
5	1762017	G-Sicherungseinsatz	Fuse	T 1 A L 250V IEC 127-2	3	D8882	5920-12-167-4252
6	1504226	Lüfter	Fan	110-233.00-002	1	D2865	
7	3604068	Schrittmotor, vollst.	Step Motor, compl.	110-233.47	1	D2865	
8	3604360	Hüllkugel-PCB	Outer Sphere PCB	110-233.101	1	D2865	
9	3604567	Encoder, kompl.	Encoder, compl.	110-233.X01	1	D2865	
10 <sup>1</sup>	3604060	Gelenk	Hinge	110-233.11	1	D2865	
11	3604090	Kabelstamm	Cable Loom	110-233.28	1	D2865	
12	3604569	Obere Hüllkugel	Upper Hemisphere	110-233.X07	1	D2865	
13	3604661	Klemmenleiste mit Temperatursensor	Terminal PCB with Temperature Sensor	110-233.X09	1	D2865	
14	3602315	Pumpe	Pump	110-231.40	1	D2865	
15	3602608	Heizung, kompl.	Heater, compl.	110-231.X01	1	D2865	
16	3604568	Hüllkugel, kompl.	Outer Sphere, compl.	110-233.X04	1	D2865	
17	3604571	Untere Hüllkugel	Lower Hemisphere	110-233.X02	1	D2865	
18	1502254	Tragflüssigkeit	Supporting Liquid	148-162 E01	1	D2865	6810-12-160-1000
19	1508499	Destilliertes Wasser	Distilled Water	148-398	1	D2865	
20	1507674	Kappe	Filler Pipe	148-398.00-002	1	D2865	5340-12-349-9869
21	4004566	Kreiselkugel, neu	Gyrosphere, new	111-006.E01	1	D2865	6605-12-349-5847
	4004792	Kreiselkugel, AT	Gyrosphere, Reconditioned	111-006.E01 AT		D2865	
100	3604573	Kleinteile-Satz	Set of small Parts	110-233.X50		D2865	
101	3608939	Satz Dichtungen	Set of Gaskets	110-222.X01		D2865	5330-12-343-3789
	3604572	Schraubensatz	Set of Screws	110-233.X03		D2865	

<sup>1</sup> incl. Pos. 11

All depicted items which are not mentioned in the text are not applicable for this unit. Since further development may necessitate making modifications to existing equipment, its conformity with the relevant illustrations and drawings is not always ensured. Raytheon Marine will be under no liability whatever that may arise from any such differences.

14.617 RA/S-SU 0311 EDITION 01

3

**Installation and Service manual**  
**Compass STD 22**  
**Compass STD 22 Compact**

---

intentionally left blank

# Installation and Service manual Compass STD 22 Compass STD 22 Compact




Kompaß  
STD 22

Kreiselkompaß STD.22  
Gyro Compass STD.22  
Type  
110-233.NG001E10



Ersatzteilkatalog  
SPARE PARTS  
CATALOGUE






## Compass STD 22 Compact

110-233.NG001E10



# CATALOGUE



# Installation and Service manual

## Compass STD 22

### Compass STD 22 Compact



Kompaß  
STD 22

Kreiselkompaß STD.22  
Gyro Compass STD.22  
Type  
110-233.NG001E10



Ersatzteilkatalog  
SPARE PARTS  
CATALOGUE

Pos.	Lager-Nr. Stock-No.	Benennung	Designation	Zeichnungs-Nr. Part-No.	Stck. Qty.	Herst.-Code MFRC	Versorgungs-Nr. NSN
1	3609658	SPG-Versorgung	Power Supply PCB	110-233.X12	1	D2865	
2	3609659	Anschluss-PCB	Connection PCB	110-233.X13	1	D2865	
3	3609657	Sensor-PCB	Sensor PCB	110-233.X11	1	D2865	
4	1762140	G-Sicherungseinsatz	Fuse	T 10 A L 250V 19195	1	D8882	5920-12-314-2556
5	1762017	G-Sicherungseinsatz	Fuse	T 1 A L 250V IEC 127-2	3	D8882	5920-12-167-4252
6	1504226	Lüfter	Fan	110-233.00-002	1	D2865	
7	3604068	Schrittmotor, vollst.	Step Motor, compl.	110-233.47	1	D2865	
8	3609386	Hüllkugel-PCB	Outer Sphere PCB	110-233.X10	1	D2865	
9	3604567	Encoder, kompl.	Encoder, compl.	110-233.X01	1	D2865	
10 <sup>1</sup>	3604060	Gelenk	Hinge	110-233.11	1	D2865	
11	3604090	Kabelstamm	Cable Loom	110-233.28	1	D2865	
12	3604569	Obere Hüllkugel	Upper Hemisphere	110-233.X07	1	D2865	
13	3604661	Klemmleiste mit Temperatursensor	Terminal PCB with Temperature Sensor	110-233.X09	1	D2865	
14	3602315	Pumpe	Pump	110-231.40	1	D2865	
15	3602608	Heizung, kompl.	Heater, compl.	110-231.X01	1	D2865	
16	3604568	Hüllkugel, kompl.	Outer Sphere, compl.	110-233.X04	1	D2865	
17	3604571	Untere Hüllkugel	Lower Hemisphere	110-233.X02	1	D2865	
18	1502254	Tragflüssigkeit	Supporting Liquid	148-162 E01	1	D2865	6810-12-160-1000
19	1508499	Desitliertes Wasser	Distilled Water	148-398	1	D2865	
20	1507674	Kappe	Filler Pipe	148-398.00-002	1	D2865	5340-12-349-9869
21	4004566	Kreiselkugel, neu	Gyrosphere, new	111-006.E01	1	D2865	6605-12-349-5847
	4004792	Kreiselkugel, AT	Gyrosphere, Reconditioned	111-006.E01 AT		D2865	
100	3604573	Kleinteile-Satz	Set of small Parts	110-233.X50		D2865	
101	3608939	Satz Dichtungen	Set of Gaskets	110-222.X01		D2865	5330-12-343-3789
		Schraubensatz	Set of Screws	110-233.X03		D2865	

<sup>1</sup> incl. Pos 11

All depicted items which are not mentioned in the text are not applicable for this unit. Since further development may necessitate making modifications to existing equipment, its conformity with the relevant illustrations and drawings is not always ensured. Raytheon Marine will be under no liability whatever that may arise from any such differences.



14.628RA/S-SU 0508 EDITION 01

3

**Installation and Service manual**  
**Compass STD 22**  
**Compass STD 22 Compact**

---

intentionally left blank





No. Designation

- 1 Terminal L2
- 2 Terminal L1
- 3 LED H1
- 4 Jumper B32
- 5 Fuse E1
- 6 Plug B8
- 7 Jumper B31
- 8 Plug B2
- 9 Plug B7
- 10 Fuse E2
- 11 Plug B3
- 12 Fuse E3
- 13 LED H5
- 14 Plug B4
- 15 Fuse E4
- 16 Plug B6
- 17 LED H7
- 18 LED H11
- 19 LED H10
- 20 LED H6
- 21 Plug B5
- 22 Plug B1
- 23 LED H2
- 24 LED H3
- 25 LED H4
- 26 LED H9
- 27 LED H8

Remarks

- Connection to the Voltage supply PCB
- Connection Supply Voltage 24VDC
- Indication Supply Voltage 24VDC
- Terminator for für CAN1
- Compass, 10A, T
- CAN-bus, CAN1
- Terminator for CAN2
- serial Interface NMEA/Coursebus Channel1
- CAN-Bus, CAN2
- Channel1, 1A, T
- serial Interface NMEA/Coursebus Channel2
- Channel2, 1A, T
- Function indicator of relay D4, AVAILABLE
- Output Coursebus
- Coursebus output, 1A, T
- Statussignals
- Output Channel2 (lights up red = Coursebus)
- Output Channel2 (lights up green = NMEA)
- Output Channel1 (lights up green = NMEA)
- Output Channel1 (lights up red = Coursebus)
- NMEA In, Puls Log In, QS (STD 22C)
- Connection to the Sensor PCB
- Function indicator of relay D1, QS
- Function indicator of relay D2, SEC
- Function indicator of relay D3, System error
- CAN2 Supply Voltage +5VDC
- CAN1 Supply Voltage +5VDC

NB05-356  
Connection PCB





No.	Designation	Remarks
1	Plug B51	Connection to Supply PCB (STD 22)
2	Plug B1	Connectio to the NMEA-THREESTATE-MODUL
3	Plug B2	Connection to the Shaft-Encoder
4	Push button B11	Processor Reset
5	LED H1	Processor monitoring
6	Plug B3	Connection to the step motor
7	Jumper B4	Testpurpose only, Output Coursebus or NMEA
8	Plug B9	Connection for programming FLASH-PROM
9	DIP switch B37	Setting of parametrs and operation modes, read-out of Compass information
10	Push button B39	Selection and setting in combination with DIP switch
11	Display	Selection and setting in combination with DIP switch
12	Push button B38	Selection and setting in combination with DIP switch

110-233.X08  
Sensor PCB





lights up (red) on malfunction of the supply PCB  
Processor monitoring  
Connection for the fan




No.	Designation	Remarks
1	Plug B21	Connection to the ferrite transformer
2	LED H4	Processor clock MC2
3	Jumper B22	Development only
4	Plug B30	Internal CAN bus
5	Plug B23	Connection to the terminal Strip PCB
6	LED H1	Processor clock MC1
7	Push button B11	Reset function (after flashing of MC1)
8	LED H3	Flashing MC1 (lights up when jumper B20 is inserted)
9	Jumper B20	Has to be inserted to flash MC1
10	Plug B18	Connection to flash MC1
11	LED H2	Flashing MC2 (lights up when jumper B 19 is inserted)
12	Plug B8	Connection to flash MC2
13	Jumper B19	Has to be inserted to flash MC2
14	Push button B10	Reset function (after flashing of MC2)

110-233.101  
Outer Sphere PCB





No.	Designation	Remarks
1	Terminal L2	Connection to the Voltage supply PCB
2	Switch B32	Terminator for CAN1 (switched into upper position = terminator set)
3	Terminal L1	Connection Supply Voltage 24V DC
4	LED H1	Indication Supply Voltage 24V DC
5	Plug B8	CAN-bus, CAN1
6	Fuse E1	Compass, 10A, T
7	Switch B31	Terminator for CAN2 (switched into upper position = terminator set)
8	Plug B7	CAN-bus, CAN2
9	Plug B2	serial Interface NMEA/Coursebus Channel 1
10	LED H8	CAN1 Supply Voltage +5V DC
11	LED H10	Output Channel1 (lights up green = NMEA)
12	Fuse E2	Channel1, 1A, T
13	Plug B3	serial Interface NMEA/Coursebus Channel2
14	LED H7	Output Channel2 (lights up red = Coursebus)
15	LED H11	Output Channel2 (lights up green = NMEA)
16	Fuse E3	Channel2, 1A, T
17	Plug B4	Output Coursebus
18	LED H12	Output Coursebus (B4) (lights up red = Coursebus)
19	LED H5	Function indicator of relay D4, AVAILABLE
20	Fuse E4	Coursebus output, 1A, T
21	LED H4	Function indicator of relay D3, SYSTEM ERROR
22	Plug B6	Statussignals
23	Plug B1	Connection to Sensor PCB
24	LED H2	Function indicator of relay D1, QS
25	LED H3	Function indicator of relay D2, SEC
26	LED H9	CAN2 Supply Voltage +5VDC
27	LED H8	CAN1 Supply Voltage +5VDC






# E10 110-233.X11 Sensor PCB




No.	Designation	Remarks
1	Plug B4	Connection inductivity primary coil
2	LED H1	Output voltage for inductive transmission
3	LED H2	Output voltage for inductive transmission
4	Terminal L1	Connection for Ship's supply 24VDC
5	Plug B5	Connection inductivity secondary coil
6	LED H3	Operating voltage relay-supply 12VDC
7	Plug B50	Connection to the Sensor PCB
8	Jumper B7	Only for manufacturers application
9	LED H9	Operating voltage Shaft-Encoder 15VDC
10	Plug B2	Connection for programming FLASH-PROM
11	LED H6	lights up (red) while programming
12	Jumper B3	Must be set to FLASH the processor
13	Push button B10	Processor Reset
14	LED H7	lights up (red) on malfunction of the supply PCB
15	LED H8	Processor monitoring
16	Terminal L2	Connection for the fan



No..	Designation	Remarks
1	Plug B21	Connection to the ferrite transformer
2	LED H4	Processor clock MC2
3	Jumper B22	Development only
4	Plug B30	Internal CAN bus
5	Stecker B23	Connection to the terminal Strip PCB
6	LED H1	Processor clock MC1
7	Push button B11	Reset function (after flashing of MC1)
8	Plug B18	Connection to flash MC1
9	LED H3	Flashing MC1 (light up when Plug B18 is connected)
10	LED H2	Flashing MC2 (lights up when Plug B8 is connected)
11	Plug B8	Connection to flash MC2
12	Push button B10	Reset function (after flashing of MC2)






E10 110-233.X10  
Outer Sphere PCB



CAD




DISTANCE FROM MAGNETIC COMPASS										m										mm										m									
STANDARD TYPE:										STEERING TYPE:																													







ID.-NR.: 5015898

\* BUILD LOOP THROUGH FERRITE CORE  
(FERRITE CORES ARE- DELIVERED  
WITH THE DISTRIBUTION UNIT)

[illegible]





CROSS SECTION  $\approx 2.5^2$

30

(OPTION)

121-062  
AC/DC-CONVERTER

U14 (OPTION)

(OPTION)

עין

121-062  
AC/DC-CONVERTER

ID. - NR.: 5015898

CAAD

CABLE		SERIENNUMMER		NAME		DATUM		ARTIKEL-NR.	
F	6597.110	259305	5TE	FEHR	19.05.95	19.05.95			
E	6588.110	100525	5TE	WACH	6.10.95	19.05.95			
D	6494.110	101003	1KE	FRSIG	B / 18.06.93				
C	6177.110	036993	KE						
B		176693	ADT						
A		136693	ADT						

GYRO COMPASS STD.22

CABLE AND CONNECTION DIAGRAM

ZEICHNUNGSNUMMER

110-233.HP009

BL. 3

VON 3


ERS. FÜR

ERS. DURCH

Raytheon

Raytheon Marine GmbH

Germany










U11 GYRO COMPASS STD.22  
110-233

CONNECTION PCB  
NB85-356 E10









TYPE OF ENCLOSURE: EN 60529 IP22

\* REFERRING TO DRILLING SCHEME ON BOARD

DIMENSIONS WITHOUT TOLERANCES ARE MAXIMUM DIMENSIONS


121-062.HP005




05014438

CAD

CAD

	mm — (INCH)		SCALE	WEIGHT: ca. 5 Kg
	DRAWING TITLE:		AC/DC-Converter DIMENSIONAL DRAWING	
	DRAWING NO.:			
	121-062.HP005			
	SH. 1			
OF 1				
REV.		REVISIONS	DATE	NAME
A		1156.121	06.10.03	Zm
DR.		15-Jul-02	Zm	
APPR.		13.10.03	Raytheon	
CHK.		13.10.03	Rum	
RELEASE:		12.04.03		
<b>Raytheon</b> Raytheon Marine GmbH Germany				






DIN CODE	BENENNUNG DENOMINATION	TYP-/ZEICHNUNGS-NR. TYPE NO./DRAWING NO.	POS.NR. POS.NO.	AUS STOCKLISTE FROM PARTS LIST	GILT FÜR APPLIES TO
U1	SENSOR PCB	110-233.100	6	110-233.NG001	
U2	HOLLKUGEL-PCB / OUTER SPHERE PCB	110-233.101	2	110-233.101	
U3	SPG-VERSORGUNG / POWER SUPPLY	110-233.102	7	110-233.NG001	
U4	HOLLKUGEL / OUTER SPHERE	110-233.20	3	110-233.NG001	
U5	KLEMMENLEISTEN-PCB/TERMINAL STRIP PCB	110-233.15	3	110-233.20	
U6	ANSCHLUSS-PCB / CONNECTION PCB	NB05-356	8	110-233.NG001	
U10	ELEKTR.-OPT. WINKELCODIERER / ELECTR.-OPT. ANGLE CODER	CSA 964096 GF04	5	110-233.01	
U11	SCHRITTMOTOR / STEPPING MOTOR	110-233.47	5	110-233.NG001	
U12	LÜFTER / FAN	110-233.00-002	4	110-233.NG001	
U13	PRIMÄRSPULE / PRIMARY COIL	110-233.02	3	110-233.01	
U14	SEKUNDÄRSPULE / SECONDARY COIL	110-233.03	4	110-233.01	
U15	HEIZPATRONE / HEATING CARTRIDGE	110-231.22	12	110-233.20	
U16	PUMPE / PUMP	110-231.40	2	110-233.20	
U17	OBERE HOLLKUGEL / UPPER HEMISPHERE	110-233.25	1	110-233.20	
U18	LAGERSCHALE / BEARING BOWL	110-233.37	4	110-233.20	
U21	KABEL / CABLE	NB06-288.11	11	NB06-288	
U22	KABEL / CABLE	NB05-356.11	11	NB05-356	
U23	KABELSTAMM / CABLE LOOM	110-233.28	35	110-233.11	
U24	SCHUTZLEITER / PROTECTIVE CONDUCTOR	110-231.13	25	110-233.07	


BL.2 : A2 - C

<div>CAD</div>	CAD		B	4511	C	M	1:1
	ALLGEMEINTOLERANZ ISO 2768 - mK						
	2003		DATUM	NAME			BENENNUNG
	BEARB	01.09.	KEMPfMANN			GYRO COMPASS STD.22	
	GEPR	01.09.	Wally			BAUSCHALTPLAN / WIRING DIAGRAM	
	NORM	1.10	Kaw				
	FREIG	07.07.03					
							ZEICHNUNGSNUMMER
							110-233.HP008
							BL. 1
							VON 2
2	B	6477.110	01.09.03	KE			
2	A	6470.110	10.07.03	KE			
BLATT	ZUST	ÄNDERUNG	DATUM	NAME	ERS. DURCH		
				Raytheon			
				Raytheon Marine GmbH			
				Germany			




BL.1 : A4 - E

CAD		B 4511 C	
BENENNUNG		GYRO COMPASS STD.22	
BAUSCHALTPLAN / WIRING DIAGRAM		110-233.HP008	
ZEICHNUNGSNUMMER		BL. 2	
ERS. FÜR		VON 2	
RAYTHEON		RAYTHEON MARINE GMBH	
GERMANY		GERMANY	
DATE		NAME	
2003		KEMPEN	
BEARBEITET		GEPRÜFT	
01.03.		1.10.	
NORM		PRELIS	
07.07.03		07.07.03	







05015310

[illegible]