

DSC 9000 SERIES

TECHNICAL MANUAL

500 09-96
910 000 63
Issue A6

All information contained in the manual including drawings, specifications, data or other material, is the property of SKANDINAVISK TELEINDUSTRI SKANTI A/S, is disclosed in confidence for use only in operating and maintaining the equipment described herein, is subject to change without notice, is not to be copied and is not to be used or disclosed for any other purpose, without the written consent of SKANDINAVISK TELEINDUSTRI SKANTI A/S.

TABLE OF CONTENTS**1. INTRODUCTION**

Table of Contents	1-1
General Description	1-3
Basic Versions	1-4
Technical Data	1-5

2. OPERATION

Table of Contents	2-1
DSC 9000 front panel	2-2
Keys and indicators	2-3
Aural alarm signals	2-5
Remote alarms	2-5
Remote activation of distress alert	2-5
Multiple Control Units	2-6
Menu tree	2-7
Distress alert	2-08
Editing a distress alert	2-10
Sending distress alert	2-14
Receiving distress acknowledgement	2-16
Sending distress relay call	2-18
Receiving distress relay acknowledgement	2-22
Sending a call	2-24
Receiving acknowledgement	2-28
Sending a direct-dial call	2-30
Receiving distress alert	2-36
Acknowledging a distress alert	2-38
Relaying a received distress alert	2-40
Receiving distress relay	2-42
Receiving a call	2-44
Sending an acknowledgement	2-46
Receiving a direct-dial call	2-48
Status display	2-50
Change status	2-52
Programming: automatic acknowledgement	2-54
Programming: position	2-56
Programming: printer	2-58
Programming: clock setting	2-59
Programming: sound setting	2-60
Programming: light setting	2-62
Programming: contrast setting	2-63
Programming: DSC-frequency list	2-64
Pre-programmed DSC frequencies	2-65
Programming: MMSI list	2-66
Programming: telephone list	2-67
Test: info	2-68
Test: self-test	2-69
Test: RX-audio	2-70
Test: TX-test	2-71

3. INSTALLATION

Table of Contents	3-1
Description	3-3
Mounting the units	3-3
Power supply	3-4
Earth connections	3-4
Antenna	3-5

Interconnection of units	3-5
Connection of MF/HF transceiver	3-6
Connection of an additional DU	3-7
Connection of radiotelex equipment	3-7
Connection of navigation equipment	3-8
Connection of a printer	3-9
Connection of a distress alarm box	3-10
Connection of remote alarms	3-10
Figures and tables	3-11
-	-
Connectors	3-27
-	-
Optional handset hook-switch for TRP 8000	3-40
Handset with built-in hook switch	3-42
Connector for built-in handset hook-switch	3-42
Distress alarm box	3-43
Radiotelex interconnections	3-44
Installation wiring diagram	3-45
Pcb 717 jumper and adjustment locations	3-47
Installation configuration	3-48
Configuration of self-id	3-48
Configuration of group-id	3-48
Configuration of control unit priority	3-48
Configuration of radio interface	3-49
Configuration of handset hook-switch interface	3-49
Configuration of DSC-watch	3-50
Configuration of telex interface	3-50
Configuration of printer interface	3-50
Configuration of external alarms	3-51
Configuration of formats	3-51
Configuration of messages	3-52
Accessories included	3-53
Optional accessories	3-54

4. TECHNICAL DESCRIPTION

Table of Contents	4-1
DSC Control Unit, DCU 9000	4-3
DSC Unit, DU 9001	4-5
DSC Unit, DU 9006	4-7
Block Diagram DCU 9000	4-9
Interconnection Diagram DCU 9000	4-10
Block Diagram DU 9001	4-11
Interconnection Diagram DU 9001	4-12
Block Diagram DU 9006	4-13
Interconnection Diagram DU 9006	4-14

5. SERVICE

Table of Contents	5-1
Preventive Maintenance	5-3
Self-test	5-5
DSC 9000 spare-parts	5-13
SKANTI Service Agents	5-20

1. INTRODUCTION Table of Contents

General Description	1-3
Basic Versions	1-4
Technical Data	1-5

GENERAL DESCRIPTION

The DSC 9000 is an MF/HF DSC Controller-Receiver which complies with the GMDSS requirements specified in SOLAS 88, chapter IV, when it is connected to a SKANTI TRP 7000 or TRP 8000 or another suitable HF transceiver.

It is designed in accordance with the recommendations and specifications of the IMO, ITU and CEPT for Class-A DSC equipment in the maritime mobile MF/HF service.

The Digital Selective Calling (DSC) system is a world-wide system for ship-to-shore, shore-to-ship, and ship-to-ship calling. It is an essential element in the Global Maritime Distress and Safety System (GMDSS) but is also used for public correspondence with land networks through coast stations providing this service.

Calls may be directed to single stations, to groups of stations or to all ships, and contain information about the category of the call (distress, urgency, safety, ship's business or routine), proposed frequency for subsequent communication, etc. In distress calls the distress position, nature of distress, etc. may be included.

Visual and audible signals advise the receiving party when calls are received. When contact has been established, frequencies are changed to the indicated working frequencies and the communication is carried out as usual.

DSC 9000 MF/HF Controller-Receiver is a compact equipment in modular design featuring the latest SMD technology. It consists of:

DCU 9000, DSC Control Unit, compact and easy to use, with large 160-character backlit LCD display with 4 lines. Splash-proof, backlit keyboard with tactile and audible feed-back. Up to 5 DCU 9000 sets may be connected to the DU 9000. The units are chain connected with a single cable.

DU 9000 DSC Unit, containing single channel or scanning receiver, power supply module, and the PCP module (Programmable Communication Processor) with DSC modulator, two DSC demodulators, and processor for control of the DSC unit and the communication with the DCU 9000, the HF transceiver and other connected equipment.

The unit is fully remote controlled from the DCU 9000 and may be installed in any convenient, suitable place. An additional DU 9006 DSC Unit configured as a DSC watch receiver may be connected where a second continuous watch receiver is needed.

The DSC 9000 MF/HF Controller-Receiver has complete control of the SKANTI TRP 7000 or TRP 8000 HF transceiver. This feature gives automatic transfer of the receiver and transmitter frequencies from the DSC 9000 to the HF transceiver. Furthermore, if an additional DU 9006 watch receiver is not connected, the receiver in the SKANTI TRP 7000 or TRP 8000 may be utilized for scanning of DSC calling channels while the receiver in the DSC 9000 simultaneously maintains distress and safety watch.

Interface (NMEA) to navigational equipment is included for automatic position updating. An external distress button may be connected for remote activation of distress calls, and external alarms may be connected for remote indication of received calls.

A serial interface for connection of a printer is included for selectable print-out of all calls, distress and safety calls only, transmitted and received calls, or received calls only as well as the possibility of printing out Short-dial list, DSC frequency list, MMSI list, Telephone list and configuration settings.

Received calls are stored until read-out. Up to 20 different distress calls and 20 other calls can be contained in the store.

The DSC 9000 remembers the last transmitted call in each format and category for easy repetition. Furthermore a short-dial register is included which may contain up to 99 user pre-programmed calls for easy recall.

When sending acknowledgements or calls in response to a received call, relevant information is automatically transferred from the received call for fast and easy response.

The DSC 9000 has direct-dial facilities in accordance with the operational procedures specified for ship stations in Recommendation ITU-R M.1080: INTERNATIONAL MARITIME MF/HF RADIOTELEPHONE SYSTEM WITH AUTOMATIC FACILITIES BASED ON DSC SIGNALLING FORMAT.

The DSC 9000 has built-in test facilities for easy routine testing and as an aid for trouble shooting and service.

BASIC VERSIONS

- **DSC 9001 - MF/HF DSC Controller-Receiver**

Built-in DSC watch receiver for the MF distress DSC frequency 2187.5 kHz.

The second demodulator may be used with the SKANTI TRP 7000 or TRP 8000 transceivers for scanning and DSC watch of 6 freely selectable MF/HF DSC channels.

- **DSC 9006 - MF/HF DSC Controller-Receiver**

Built-in 6-channel scanning MF/HF DSC watch receiver. The second demodulator may be used with the SKANTI TRP 7000 or TRP 8000 transceivers for scanning and DSC watch of 6 freely selectable MF/HF DSC channels.

TECHNICAL DATA**GENERAL**

Complies with the relevant IMO performance standards, the ITU Radio Regulations, the relevant ITU recommendations and meets the performance specifications of CEPT for MF/HF DSC equipment (T/R 34-01 E, Annex XIII).

Power Supply:

12/24/32 V battery.

Connection will not earth supply battery.

Supply Voltage Variation:

10.8 to 41.6 V DC

Power Consumption:

15 W to 50 W (50 W during the first min.) depending on backlight intensity and number of control units.

With additional DU add 15 W (50 W during the first min.)

Operating Temperature Range:

-20C to +55C

RECEIVER WITH DSC DECODER 1**Frequency Range:**

DU 9001: 2187.5 kHz

DU 9006: 0.1 - 30 MHz

Frequency Selection:

DU 9001: Fixed

DU 9006: Scanning of up to six frequencies may be selected from pre-programmed or user-programmed frequencies.

Frequency accuracy:

Better than 10 Hz

Antenna Impedance:

50 ohms

Receiver Bandwidth:

Passband (6 dB) min. +/- 125 Hz

Attenuation at +/- 550 Hz min. 60 dB

Calling Sensitivity:

Antenna input (EMF) for symbol error rate

below 1×10^{-2} : 0 dB μ V.

Adjacent Channel Selectivity:

With a wanted signal 20 dB μ V, an unwanted signal 500 Hz off tune 60 dB μ V does not deteriorate the symbol error rate below 1×10^{-2} .

Co-Channel Rejection:

With a wanted signal 20 dB μ V, an unwanted signal on the same frequency 14 dB μ V does not deteriorate the symbol error rate below 1×10^{-2} .

RF Intermodulation Response:

With a wanted signal 20 dB μ V, two unwanted signals more than 30 kHz off tune 70 dB μ V do not deteriorate the symbol error rate below 1×10^{-2} .

Interference Rejection and Blocking Immunity:

With a wanted signal 20 dB μ V, an unwanted signal in the frequency range 100 kHz to 2 GHz (except a +/- 3 kHz band around the tuned frequency) 90 dB μ V does not deteriorate the symbol error rate below 1×10^{-2} .

Dynamic Range:

With a wanted signal 80 dB μ V the symbol error rate is below 1×10^{-2} .

Conducted Spurious Emission:

Less than 1 nW measured at the antenna connector

Input Protection:

30 V RMS (EMF) for up to 15 min.

DSC DECODER 2**Input Frequency:**

1700 Hz +/- 85 Hz.

Modulation rate:

100 baud.

Input Level:

Nominally 0 dBm.

Dynamic Range:

+10/-30 dB.

Input Impedance:

600 ohms, free of earth.

Scanning Interface:

Scanning of up to six frequencies may be selected from pre-programmed or user-programmed frequencies.

Scanning table and step commands are transferred via transceiver interface.

Stops on 100 baud dot pattern only.

DSC ENCODER**Modulation:**

Phase continuous AFSK keying.

Output Frequency:

1700 Hz +/-85 Hz.

Frequency Accuracy:

Better than 0.5 Hz.

Modulation Rate:

100 baud, +/-30 ppm.

Output Level:

Adjustable, -10 to +10 dBm, 600 ohms.

Output Impedance:

600 ohms, free of earth.

Unwanted Spectral Components:

More than 60 dB below mean power output level.

TRANSCEIVER CONTROL**Control Data Interface:**

Serial interface, compatible with RS-232.

Baud Rate: 2400 bps(T+Bus) /
4800 bps(NMEA).

Interface Protocol:

T+Bus(default) / T+Bus, one way / NMEA

TX Key Signal:

Open collector output, compatible with RS-410 type N.

Max current 50mA. Max voltage 32V. Low for keying TX.

Handset On-Hook Signal:

RS-410 type N input. Internally pulled up to 12V through 1.8 kohm.

Should be connected to GND when handset is off-hook or on-hook as determined by configuration.

RADIOTELEX INTERFACE**Control Data Interface:**

Serial interface, compatible with RS-232.

Opto-isolated (internally selected).

Baud rate: 2400 bits/sec.

Interface Protocol: T+Bus.

TX Key Signal:

RS-410 type N input.

Internally pulled up to 12V through 1kohm.

Should be connected to GND for keying TX.

OTHER INTERFACES**Navigator (DU or DCU):**

Serial interface, opto-isolated, conforming with NMEA 0183. Baud rate: 4800 bits/sec.

Printer (DU or DCU):

Serial interface compatible with RS-232, opto-isolated (internally selected). Baud rate: 300 - 9600 bits/sec.

External Distress Alarm Button (DU or DCU):

RS-410 type N input.

Internally pulled up to 12V through 1.8kohm.

Should be connected to GND when distress button is activated.

Alarm Out (DCU):

Open collector output, compatible with RS-410 type N.

Max current 50mA. Max voltage 32V.

Low when Distress lamp is on.

Alarm 1 Out (DU):

Open collector output, compatible with RS-410 type N.

Max current 50mA. Max voltage 32V. Low as determined by configuration.

Alarm 2 Out (DU):

Open collector output, compatible with RS-410 type N.

Max current 50mA. Max voltage 32V. Low as determined by configuration.

Scan S/S (DU):

Open collector output, compatible with RS-410 type N.

Max current 50mA. Max voltage 32V. Not used at present.

OPERATIONAL FACILITIES**Display:**

4 lines x 40 characters alpha-numeric dot matrix LCD module with black characters and yellow LED backlight.

Keyboard:

20 back-illuminated keys with tactile feedback.

Visual Indicators:

Green, red and yellow LEDs for indication of Supply On, reception/transmission of distress or urgency and other calls respectively.

Aural Alarm Signals:

Specific acoustic signals for distress/urgency calls and other calls.

Non-Volatile Memory:

Nine-digit self-ID is permanently stored and cannot be changed by the user.

Battery Backed-up Memory:

Capacity for storing
20 received distress calls
20 other received calls
10 Tx-calls
100 DSC frequency pairs
100 MMSI numbers
100 telephone numbers

BACK-UP BATTERY**Battery type:**

Li/SOCl₂

Part number 107 811 60

Life Time:

6-12 years dependent on working conditions.

DIMENSIONS AND WEIGHTS**DCU 9000 Control Unit:**

Width: 330 mm

Height: 132.5 mm

Depth: 43 mm

Weight: 1.4 Kg

DU 9000 DSC Unit:

Width: 370 mm

Height: 132.5 mm

Depth: 291.5 mm

Weight: 7.4 Kg, DU 9001

7.5 Kg, DU 9006

2. OPERATION Table of Contents**General**

DSC 9000 front panel	2-2
Keys and indicators	2-3
Aural alarm signals	2-5
Remote alarms	2-5
Remote activation of distress alert	2-5
Multiple Control Units	2-6
Menu tree	2-7

Operating instructions

Distress alert, info	2-8
Distress alert	2-9
Editing a distress alert, info	2-10
Editing a distress alert	2-11
Editing a distress alert, info	2-12
Editing a distress alert cont'd	2-13
Sending distress alert, info	2-14
Sending distress alert	2-15
Receiving distress acknowledgement, info	2-16
Receiving distress acknowledgement	2-17
Sending distress relay call, info	2-18
Sending distress relay call	2-19
Sending distress relay call, info	2-20
Sending distress relay call cont'd	2-21
Receiving distress relay acknowledgement, info	2-22
Receiving distress relay acknowledgement	2-23
Sending a call, info	2-24
Sending a call	2-25
Sending a call, info	2-26
Sending a call cont'd	2-27
Receiving acknowledgement, info	2-28
Receiving acknowledgement	2-29
Sending a direct-dial call, info	2-30
Sending a direct-dial call	2-31
Sending a direct-dial call, info	2-32
Sending a direct-dial call cont'd	2-33
Sending a direct-dial call, info	2-34
Sending a direct-dial call cont'd	2-35
Receiving distress alert, info	2-36
Receiving distress alert	2-37

Acknowledging a distress alert, info	2-38
Acknowledging a distress alert	2-39
Relaying a received distress alert, info	2-40
Relaying a received distress alert	2-41
Receiving distress relay, info	2-42
Receiving distress relay	2-43
Receiving a call, info	2-44
Receiving a call	2-45
Sending an acknowledgement, info	2-46
Sending an acknowledgement	2-47
Receiving a direct-dial call, info	2-48
Receiving a direct-dial call	2-49
Status display	2-50
Change status	2-52


Programming

Programming: Automatic acknowledgement	2-54
Programming: position	2-56
Programming: printer	2-58
Printer status	2-58
Print lists	2-58
Programming: clock setting	2-59
Programming: sound setting	2-60
Distress-alarm sound	2-60
Call-alarm sound	2-60
Key-beep sound	2-61
Programming: light setting	2-62
Programming: contrast setting	2-63
Programming: dsc-frequency list	2-64
Pre-programmed dsc frequencies	2-65
Programming: MMSI list	2-66
Programming: telephone list	2-67


Test

Test: info	2-68
Accumulated on-time	2-68
Version	2-68
Test: self-test	2-69
Test: RX-audio	2-70
Test: TX-test	2-71

DSC 9000 FRONT PANEL




KEYS AND INDICATORS




Switches DSC 9000 on.
Switches DSC 9000 off when pressed for 6 seconds.



Selects DISTRESS mode.
Starts transmission of a distress alert if pressed for 6 seconds.




Selects TX-CALL menu.
Completes a composition of a TX-CALL using the information from the last call in the selected Format.
Starts transmission of a composed call if so is indicated.
Starts transmission of an acknowledgement if a call requiring acknowledgement is displayed.




Change the content of a selection field.
Move between commands.




Change list numbers.
Change between numbers and letters in alpha-numeric fields.




Enters the content of a selection or entry field and moves to the next step.
Executes a selected command.



Moves to the previous step.
Deletes the character at the cursor when keying in a value.
Interrupts transmission of a call in progress.
Stops an aural alarm signal.




Selects the MAIN-MENU.



Enter numbers or letters in entry fields.



Switches illumination of display and keyboard backlight between "day" and "night" settings (unless a numeric entry is expected).




Steady green light

Indicates that the supply is on.




Slow flashing red light

A distress call (distress format or category) has been received .
The lamp remains flashing until the call has been read out.




Quick flashing red light

A distress alert will be transmitted if the Distress key is kept pressed for 5 seconds.




Steady red light

A distress alert transmission is in progress.
Distress alert will be automatically retransmitted.



Slow flashing yellow light

A call other than distress has been received. The lamp remains flashing until the call has been read out.



Steady yellow light

Transmission of a call (other than distress) is in progress.

AURAL ALARM SIGNALS

<u>Distress Alarm:</u>	User-programmable sound indicating that a distress or urgency call has been received. Remain activated until a key is pressed
<u>Call alarm:</u>	User-programmable sound indicating that a call (other than distress or urgency) has been received. Remain activated for 1/4 - 4 minutes (programmable) or until a key is pressed or, for Direct-dial and Selective telephony calls, the handset of the radiotelephone is lifted off-hook.

REMOTE ALARMS

External alarm devices may be connected to DSC 9000 and configured to be active when

- the aural distress alarm sounds, or
- the aural call alarm sounds, or
- either alarm sounds *), or
- the distress lamp is illuminated and when the aural distress alarm sounds

*)Different on/off patterns so it is possible to distinguish between distress alarm and call alarm.

REMOTE ACTIVATION OF DISTRESS ALERT

An external push button may be connected to the equipment for remote initiation of a distress alert.

The external push button may be combined with a lamp configured to follow the distress lamp.

The external push button is operated in the same way as the Distress key on DCU 9000. To initiate a distress alert press the push-button for 6 sec (until the distress lamp stops quick-flashing and shows steady light). Then release. If not released within 5 s transmission does not start.

MULTIPLE CONTROL UNITS

Up to 5 DCU 9000 control units may be connected simultaneously to a DU 9000. One of the control units may be given priority (by configuration).

Only one control unit can be *active* at a time while all others are *passive*. When switching on, the control unit on which the SUPPLY ON/OFF button was pressed becomes *active*. After an interruption in external power supply all control units will be *passive*.

If the active control unit is in the MAIN-MENU, STATUS or RX-CALL states or if all control units are passive, the display of a passive control unit shows:






STAND-BY

>STATUS<

If the active control unit is in any other state the display of a passive control unit shows:

BUSY


Only a passive control unit with higher priority can interrupt the active control unit in this case.

Only the keys , , ,  and  are functioning on a passive control unit.

An incoming call activates the visual and audible indicators of all control units. Light and sound levels are individually adjustable.

The RX-CALL is displayed only on the active control unit.

MENU TREE



**DISTRESS ALERT, INFO**

To edit the Information, release
immediately.



DISTRESS ALERT

1. Press  for 6 seconds.

The displayed distress alert information will be transmitted when the key is released after the 6 seconds has elapsed.

Example:

DISTRESS

Position: 55°59'N 133°22'W at 1229 UTC

Undesignated distress USB telephony

- Keep pressing 5 sec to send message -



EDITING A DISTRESS ALERT, *INFO*

Position

The position is updated automatically by the ships navigational equipment or it may have been keyed in manually, see PROGRAMMING POSITION.

Automatic updated position information is 'frozen' at the moment the Distress button is pressed and may be corrected manually by selecting >EDIT<.

Nature of Distress

Selectable Options:

- Fire, explosion
- Flooding
- Collision
- Grounding
- Danger of capsizing
- Sinking
- Disabled and adrift
- Undesignated distress
- Abandoning ship

Type of Subsequent Distress Communication

Selectable Options:

- USB telephony
- AM telephony
- FEC telex

EDITING A DISTRESS ALERT



1. Press and release .

2. Accept the **Position** if ok.

Press .



DISTRESS
Position: (55°59'N 133°22'W at 1229 UTC)

>POSITION OK< EDIT UNKNOWN

3. Select the **Nature of Distress** using the   keys.

Press .

DISTRESS
Position: 55°59'N 133°22'W at 1229 UTC
<Undesignated distress> USB telephony
- - Change by [<] [>] or press [Enter] - -

4. Select the **Type of Subsequent Distress Communication** using the   keys.

Press .

DISTRESS
Position: 55°66'N 133°22'W at 1229 UTC
Undesignated distress <USB telephony>
- - Change by [<] [>] or press [Enter] - -

5. To send on one DSC distress frequency select >SINGLE<.

Press .

DISTRESS
Position: 55°59'N 133°22'W at 1229 UTC
Undesignated distress USB telephony
DSC distress freq: ALL >SINGLE<



EDITING A DISTRESS ALERT, INFO

DSC Distress frequency



If >ALL< is selected, the distress alert will be sent on all six DSC Distress frequencies in turn.

Note: The Frequency is preset to 2187.5 kHz if watch receiver 1 is set to 'Distress watch MF' (DSC 9001).

If a single frequency is selected the Distress Alert will be sent on that frequency 5 times, in each transmission.

EDITING A DISTRESS ALERT Cont'd





6. Select a DSC Distress Frequency using the   keys.

Press .

DSC FREQUENCY SELECTION

<97 DISTRESS Tx: 8414.5 Rx: 8414.5 kHz>

-- Change by [<] [>] or press [Enter] --

7. Press  for 6 seconds to transmit the Distress Alert immediately or press  to return to the Main Menu.

DISTRESS

Position: 55°59'N 133°22'W at 1229 UTC

Undesignated distress USB telephony

- Press [Distress] 6 sec to send message

**SENDING DISTRESS ALERT, *INFO***


If the transmitter is off the light in the distress lamp does not turn into steady light and the last line shows "-- Switch transmitter on --".


If the distress alert was transmitted on a single frequency, the transceiver is set automatically to telephony or telex mode as indicated in the call and to the appropriate distress frequency in the same band as the call.


After 3 minutes, if a single frequency was selected, the last line shows "-Press [Enter] to select DSC frequency-". Another DSC frequency may then be selected and the distress alert repeated on this frequency.

Automatic transmission if [Enter] is not pressed.

SENDING DISTRESS ALERT



1. Press  for 6 seconds.
The Distress key lamp flashes quickly.
The display shows the Distress Message.



DISTRESS

Position: 55°59'N 133°22'W at 1229 UTC
Undesignated distress USB telephony
- Keep pressing 5 sec to send message -

2. The display shows the remaining number of seconds


DISTRESS

Position: 55°59'N 133°22'W at 1229 UTC
Undesignated distress USB telephony
- Keep pressing 1 sec to send message -

DISTRESS

Position: 55°59'N 133°22'W at 1229 UTC
Undesignated distress USB telephony
----- Release button -----

When the time is out the Distress lamp will light steady.



- 3 Release  to start the transmission..

DISTRESS


Position: 55°59'N 133°22'W at 1229 UTC
Undesignated distress USB telephony
----- Tuning transmitter -----
----- Transmitting -----

4. The Distress Alert Transmission is automatically repeated at intervals of 3.5 - 4.5 minutes.

DISTRESS

Position: 55°59'N 133°22'W at 1229 UTC
Undesignated distress USB telephony
- Awaiting acknowledgement -

5. The Distress Alert repetition continues until:
the Distress Acknowledgement is received

or  is pressed.



RECEIVING DISTRESS ACKNOWLEDGEMENT, *INFO*

If SET UP is entered, the transceiver is set automatically to telephony or telex mode as indicated , and to the appropriate distress and safety frequency in the same band as the acknowledgement call.

END should be entered when communication is completed. The display returns to STATUS display or to RX-CALL if not all received calls have been read out and scanning is resumed on the transceiver if so selected.

The Distress Acknowledgement is an All Ships Call and therefore received not only by the ship in distress.

RECEIVING DISTRESS ACKNOWLEDGEMENT




1. The Distress Acknowledgement is received.
The Distress lamp flashes slowly.

The display shows which station has acknowledged the Distress Alert.

Press

Enter



RX-CALL All ships from: 001234567
Category: Distress Distress ack
Received on 8414.5 kHz > MORE <

2. The display shows the Distress message acknowledged.

DISTRESS-ACKNOWLEDGEMENT TO:123456789
Position: 55°66'N 133°22'W at 1229 UTC
Undesignated distress USB telephony
>SET UP< QUIT

3. Enter SET UP and hook off the Transceiver handset to commence the Distress traffic by telephony.

The Transceiver is automatically set to the Distress traffic frequency.

DISTRESS-ACKNOWLEDGEMENT TO:123456789
Position: 55°66'N 133°22'W at 1229 UTC
Undesignated distress USB telephony
>END<


4. When communication is completed, enter END.

**SENDING DISTRESS RELAY CALL, INFO**

To relay a received distress alert please refer to page 2-41

SENDING DISTRESS RELAY CALL



1. Press  **Call**
Select the format e.g. Selective call.

TX-CALL Saved call: Enter number 0-9

DIRECT-DIAL
>SELECTIVE< GROUP AREA ALL-SHIPS

Press  **Enter**.

2. Key in the Maritime Mobile Service Identity number of the coast station.

TX-CALL Selective to: **(001234567)**

Press  **Enter**.

- Enter maritime mobile service identity -

3. Select Distress Category.

TX-CALL Selective to: 001234567
Category: <Distress>

Press  **Enter**.

-- Change by [<] [>] or press [Enter] --

4. Select Distress Relay.

TX-CALL Selective to: 001234567
Category: Distress <Distress relay>

Press  **Enter**.

-- Change by [<] [>] or press [Enter] --

5. Key in the Maritime Mobile Service Identity of the ship in distress if known.

DISTRESS-RELAY Ship: (123456789)

Press  **Enter**.

- Enter maritime mobile service identity -

6. Key in the position.

DISTRESS-RELAY Ship:123456789
Position: 55°59'N 133°22'W at 1229 UTC

Press  **Enter**.

>POSITION-OK< EDIT



SENDING DISTRESS RELAY CALL, INFO

Nature of Distress

Selectable Options:

- Fire, explosion
- Flooding
- Collision
- Grounding
- Danger of capsizing
- Sinking
- Disabled and adrift
- Undesignated distress
- Abandoning ship

Type of Subsequent Distress Communication

Selectable Options:

- USB telephony
- AM telephony
- FEC telex

The distress relay call is automatically transmitted 5 times, total duration approx. 50 sec.

Following transmission of a selective call the receiver is set to the DSC RX frequency and awaits an acknowledgement within 5 minutes.

For All ships, Group or Area calls no acknowledgement is expected. In this case the transceiver is set automatically to telephony or telex mode as indicated in the call and to the appropriate distress and safety frequency in the same band as the call.

SENDING DISTRESS RELAY CALL Cont'd



7. Select the nature of distress.

Press Enter.

DISTRESS-RELAY Ship:123456789
Position: 55°59'N 133°22'W at 1229 UTC
<Undesignated distress>
-- Change by [<] [>] or press [Enter] --

8. Select the type of subsequent distress communication.

Press Enter.

DISTRESS-RELAY Ship:123456789
Position: 55°59'N 133°22'W at 1229 UTC
Undesignated distress <USB telephony>
-- Change by [<] [>] or press [Enter] --

9. Press Enter.

DISTRESS-RELAY Ship:123456789
Position: 55°59'N 133°22'W at 1229 UTC
Undesignated distress USB telephony
- Press [Enter] to select DSC frequency -

10. Select one of the DSC Distress Frequencies (94-99).

Press Enter.

DSC FREQUENCY SELECTION
<97 DISTRESS Tx:8414.5 Rx:8414.5 kHz>
-- Change by [<] [>] or press [Enter] --

11. Press ○ Call to transmit the message.

TX-CALL Selective to: 001234567
Category: Distress Distress relay

- Press [Call] to send on 8414.5 kHz -
----- Tuning transmitter -----
----- Checking for free channel -----
----- Transmitting -----
----- Awaiting ack on 8414.5 kHz -----

If no acknowledgement has been received when the time expires, the display shows.

The call may be repeated on another frequency by selecting REPEAT.

No acknowledgement received

REPEAT >QUIT<



RECEIVING DISTRESS RELAY ACKNOWLEDGEMENT, *INFO*

If SET UP is entered, the appropriate transmitter and receiver are set automatically to telephony or telex mode as indicated in the acknowledgement, and to the appropriate distress and safety frequency in the same band as the acknowledgement call. (If not configured for automatic control of telex receiver and transmitter, the telephony receiver and transmitter are set to USB at the telephony distress frequency in the same band.)


If the handset is lifted off-hook while the acknowledgement is displayed, the telephony transmitter and receiver are set automatically to the telephony distress and safety frequency in the same band as the acknowledgement call.

END should be entered when communication is completed. The display returns to STATUS or to RX-CALL if not all received calls have been read out and scanning is resumed on the transceiver if so selected.

RECEIVING DISTRESS RELAY ACKNOWLEDGEMENT



1. The Distress Acknowledgement is received.
The Distress lamp flashes slowly.



RX-ACKNOWLEDGEMENT from: 001234567
Category: Distress Distress relay

Received on 8414.5 kHz **> MORE <**

2. The display shows the Distress relay message acknowledged.

DISTRESS-RELAY Ship:123456789
Position: 55°59'N 133°22'W at 1229 UTC
Undesignated distress USB telephony
>SET UP< QUIT

3. Enter SET UP or hook off the Transceiver handset to commence the Distress traffic by telephony.
The Transceiver is automatically set to the Distress traffic frequency.

DISTRESS-RELAY Ship:123456789
Position: 55°59'N 133°22'W at 1229 UTC
Undesignated distress USB telephony
>END<

4. When communication is completed, enter END.

**SENDING A CALL, INFO**

Note: Some formats may be disabled by configuration.

Categories

Seleable options:

<u>All ships call</u>	<u>Area / Group / Selective</u>
Distress	Distress
Urgency	Urgency
Safety	Safety
	Ship's business
	Routine

Type of subsequent communication / Telecommand.

Seleable options:

USB telephony
FEC telex
ARQ telex

For distress category additionally:

Distress relay


Note: Telecommands may be added dependent on configuration.

SENDING A CALL



1. Press .

2. Select the format. e.g. Selective call .

Press .

3. Key in the Maritime Mobile Service Identity of the station you want to call.

Press .

4. Select the Category.

Press .

5. Select the type of subsequent communication/telecommand.

Press .

TX-CALL Saved call: 0-9

DIRECT-DIAL
>SELECTIVE< GROUP AREA ALL-SHIPS

TX-CALL Selective to: (001234567)

- Enter maritime mobile service identity -

TX-CALL Selective to: 001234567
Category: <Routine>

-- Change by [<] [>] or press [Enter] --

TX-CALL Selective to: 001234567
Category: Routine < USB telephony>

-- Change by [<] [>] or press [Enter] --

**SENDING A CALL, INFO****Additional information**

When calling a coast station select NONE.

When calling another ship select FERQUENCY and key-in the proposed working frequencies.

Note: Transmission is prevented until the channel is free. This feature may be overruled by pressing Call again.

The duration of an MF/HF DSC call is approx. 10 sec. Following transmission of selective or direct-dial calls the receiver is set to the DSC RX frequency and awaits an acknowledgement within 5 minutes for selective calls and 25 seconds for direct-dial calls.

All ships, group and area calls require no acknowledgement. When the transmission is completed the transceiver is set to the mode and frequencies indicated in the call by pressing ENTER or, for telephony calls, lifting the handset off hook within 1 minute.



END should be entered when communication is completed. For telephony calls just place the handset on-hook. The display returns to STATUS or to RX-CALL if not all received calls have been read out and scanning is resumed on the transceiver if so selected.

SENDING A CALL Cont'd

6. Select the Additional information.
e.g. "NONE"

Press  .


Press  .

7. Select the DSC Frequency using
the   keys or
by entering a List number.

Press  .

8. Select SEND.

Press  .

9. Press  to send
the Selective call.

TX-CALL Selective to: 001234567
Category: Routine USB telephony
Additional information:
>NONE< POSITION FREQUENCY CHANNEL

TX-CALL Selective to: 001234567
Category: Routine USB telephony
- Press [Enter] to select DSC frequency -

DSC FREQUENCY SELECTION
<08 NATIONAL Tx: 2159.5 Rx 1624.5>
-- Change by [<] >] or press [Enter] --

TX-CALL Selective to: 001234567
Category: Routine USB telephony
DSC Tx: 2159.5 kHz EDIT SAVE >SEND<

TX-CALL Selective to: 001234567
Category: Routine USB telephony
- Press [Call] to send on 2159.5 kHz -

----- Tuning transmitter -----
----- Checking for free channel -----
----- Transmitting -----
----- Awaiting ack on 1624.5 kHz -----

If no acknowledgement has been received
when the time expires, the display shows.

The call may be repeated on the same or
another DSC frequency .Further call attempts to
the same coast station should be delayed at least
15 minutes, if acknowledge is still not received.

No acknowledgement received

REPEAT >QUIT<



RECEIVING ACKNOWLEDGEMENT, *INFO*

If SET UP is entered the mode and frequency of the transceiver is set as indicated in the call.


If the handset is lifted off-hook while an RX-call indicating telephony mode is displayed, the mode and frequency is set as indicated in the call.

END should be entered when communication is completed. For telephony calls just place the handset on hook. The display returns to STATUS or to RX-CALL if not all received calls have been read out and scanning is resumed on the transceiver if so selected.

RECEIVING ACKNOWLEDGEMENT



1. The Acknowledgment is received.
The Call lamp flashes.



RX-ACKNOWLEDGEMENT from: 001234567
Category: Routine USB telephony
Working freq. Tx: 2076.0 Rx: 1813.0 kHz
 >SET UP< QUIT

2. Enter SET UP or hook off the Transceiver handset to commence the communication by telephony.
The Transceiver is automatically set to the mode and frequencies indicated in the acknowledgement.

RX-ACKNOWLEDGEMENT from: 001234567
Category: Routine USB telephony
Working freq. Tx: 2076.0 Rx: 1813.0 kHz
 >END<

3. When communication is completed, enter END.



SENDING A DIRECT-DIAL CALL, INFO

Direct-dial calls are used for direct telephone dialling of a land subscriber through an appropriate coast station providing automatic connection with the public switched telephone network.

Note: Not all coast stations provide this service.

To recall a saved call press the short-dial number (0-9).

To repeat a call press the call button.

Alternatively the MMSI list number (0-99) may be entered if the coast station has been programmed into the MMSI list. When Enter is pressed the programmed name of the coast station will be shown next to the 9-digit MMSI number.

Alternatively the telephone list number (0-99) may be entered if the number has been programmed into the telephone list. When Enter is pressed the programmed name of the coast station will be shown next to the telephone number.

The name of the coast station or the country may be used instead of NATIONAL, please refer to page 2-64 PROGRAMMING DSC-FREQUENCY LIST for further information.

SENDING A DIRECT-DIAL CALL



1. Press .

2. Select Direct-dial.

To edit the call


Press .



3. Key in the Maritime Mobile Service Identity of the coast station.


Press .

4. Key in the telephone no. of the land subscriber

Press .

Press .

5. Select the DSC frequency of the coast station using the   keys or by entering a List number.

Press .

TX-CALL Saved call: 0-9
Repeat: Call
>DIRECT-DIAL<
SELECTIVE GROUP AREA ALL-SHIP

TX-CALL Direct-dial to: (002192000)
- Enter Maritime Mobile Service Identity -

TX-CALL Direct-dial to: 002192000
Tel:(42482544)
----- Enter telephone number -----

TX-CALL Direct-dial to: 002192000
Tel: 42482544
-- Press [Enter to select DSC frequency--

DSC FREQUENCY SELECTION
<08 NATIONAL Tx: 2159.5 Rx 1624.5>
-- Change by [<] [>] or press [Enter] --



SENDING A DIRECT-DIAL CALL, INFO

To save the call select SAVE and press the Enter button.

Acknowledgement from the coast station is normally received within 25 sec.

If the coast station cannot comply immediately with the call request due to the appropriate working frequencies being busy or for other reasons, this will be indicated in the acknowledgement.

The coast station evaluates the working channel quality during the DSC call. If quality is satisfactory the acknowledgement contains the same working frequencies. The coast station then starts dialling the subscriber.


If the working channel quality evaluation indicates that quality is not satisfactory the coast station may suggest other working frequencies. In this case the DSC calls are repeated on the new working frequencies.

If the working channel quality evaluation again indicates that quality is not satisfactory and no other channels are available the coast station sends an acknowledgement indicating -Cannot use Channel-.


SENDING A DIRECT-DIAL CALL Cont'd



5. Select SEND



6. Press



When acknowledgement is received and the coast station can comply immediately the call is automatically repeated on the working frequency contained in the acknowledgment.

Lift the handset off hook and wait for the called subscriber to answer the telephone

When the call is completed or in case of no answer, place the handset on-hook. An 'End of call' DSC message is then sent to the coast station to stop call timing.



TX-CALL Direct-dial to: 002192000
Tel: 42482544
DSC tx: 2159.5 kHz EDIT SAVE > SEND<

TX-CALL Direct-dial to: 002192000
Tel: 42482544
-- Press [Call] to send on 2159.5 kHz --
----- Tuning transmitter -----
----- Checking for free channel -----
----- Transmitting -----
---- Awaiting ack on 1624.5 kHz ----

TX-CALL Direct-dial to: 002192000
Tel: 42482544
Working freq. Tx: 2076.0 Rx: 1813.0 kHz
----- Setting-up transceiver -----
----- Tuning transmitter -----
----- Transmitting -----
---- Awaiting ack on 1813.0 kHz ----

RX-ACKNOWLEDGEMENT from: 002192000
Tel: 42482544 USB telephony
Working freq. Tx: 2076.0 Rx: 1813.0 kHz
Received on 1813.0 kHz >END<

TX-CALL Direct-dial to: 002192000
Tel: 42482544 End of call
----- Tuning transmitter -----
----- Transmitting -----
---- Awaiting ack on 1813.0 kHz ----



SENDING A DIRECT-DIAL CALL, *INFO*

SENDING A DIRECT-DIAL CALL Cont'd

The acknowledgement from the coast station may contain information on the chargeable duration of the call.



RX-ACKNOWLEDGEMENT from: 002192000
Tel: 42482544 End of call
Duration: 0 hours 6 min 35 sec
 >QUIT<



RECEIVING DISTRESS ALERT, *INFO*

If SET UP is entered, the transceiver is set automatically to telephony or telex mode as indicated in the call, and to the appropriate distress and safety frequency in the same band as the call.

If received on an HF Distress frequency ACK is replaced by RELAY.

See page 2-39 for acknowledging a Distress Alert and page 2-41 for Relaying a Distress Alert.

END should be entered when communication is completed. The display returns to STATUS or to RX-CALL if not all received calls have been read out and scanning is resumed on the transceiver if so selected.

Note: A Distress Alert may be received on more frequencies.

RECEIVING DISTRESS ALERT



1. A Distress Alert is received.



2. Enter SET UP. The transceiver is now automatically set to the Distress traffic frequency.

Hook off the transceiver handset to acknowledge the receipt of the Distress alert by telephony.

RX-CALL Distress from: 123456789
 Position: 55°59'N 133°22'W at 1229 UTC
 Undesignated distress USB telephony
 Received on 2187.5 kHz > SET UP< END

3. When communication is completed, enter END.

RX-CALL Distress from: 123456789
 Position: 55°59'N 133°22'W at 1229 UTC
 Undesignated distress USB telephony
 Received on 2187.5 kHz ACK > END<



ACKNOWLEDGING A DISTRESS ALERT, *INFO*

Ships receiving a DSC distress alert from another ship should defer the acknowledgement of the distress alert for a short interval, if the ship is within an area covered by one or more coast stations, in order to give the coast station time to acknowledge the DSC distress alert first.

Start of transmission is automatically delayed until 1 minute has passed since receipt of the Distress Alert. In this periode the displays shows ' Call in progress '.

END should be entered when communication is completed. The display returns to STATUS or to RX-CALL if not all received calls have been read out and scanning is resumed on the transceiver if so selected.

ACKNOWLEDGEING A DISTRESS ALERT



1. A distress alert is received on 2187.5 kHz and SET UP is selected

2. Select ACK.

Press 


RX-CALL Distress from: 123456789
Position: 55°59'N 133°22'W at 1229 UTC
Undesignated distress USB telephony
Received on 2187.5 kHz **>ACK< END**

3. Select Continue.

Press 

DSC distress acknowledgements are normally made by coast stations only.

>CONTINUE< RETURN

4. Press  to transmit the Distress Acknowledgement.

DISTRESS-ACKNOWLEDGEMENT TO:987654321
Position: 55°59'N 133°22'W at 1229 UTC
Undesignated distress USB telephony
- Press [Call] to send on 2187.5 kHz -

----- Call in progress -----
----- Tuning transmitter -----
----- Checking for free channel -----
----- Transmitting -----

5. When communication is completed, enter END.

DISTRESS-ACKNOWLEDGEMENT TO:987654321
Position: 55°59'N 133°22'W at 1229 UTC
Undesignated distress USB telephony
> END <



RELAYING A RECEIVED DISTRESS ALERT, *INFO*

The distress relay call is automatically transmitted 5 times.

Regarding receiving distress relay acknowledgement, please refer to page 2-23

RELAYING A RECEIVED DISTRESS ALERT



1. A Distress Alert is received on an HF frequency and SET UP is selected. Select RELAY.

Press  .

RX-CALL: Distress from:123456789
Position: 55°59'N 133°22'W at 1229 UTC
Undesignated distress USB telephony
Received on 8414.5 kHz RELAY >END<

2. Key in the Maritime Mobile Service Identity number of the coast station.

Press  .

TX-CALL Selective to: (001234567)

- Enter maritime mobile service identity -

3. The Distress message is displayed.

Press  .

DISTRESS-RELAY Ship:123456789
Position: 55°59'N 133°22'W at 1229 UTC
Undesignated distress USB telephony
- Press [Enter] to select DSC frequency -


4. Select the DSC distress frequency using

the   keys.

Press  .

DSC FREQUENCY SELECTION
<97 DISTRESS Tx:8414.5 Rx:8414.5 kHz>

-- Change by [<] [>] or press [Enter] --

5. Press  to transmit the message.

TX-CALL Selective to: 001234567
Category: Distress Distress relay

- Press [Call] to send on 8414.5 kHz -

----- Tuning transmitter -----

----- Checking for free channel -----

----- Transmitting -----

----- Awaiting ack on 8414.5 kHz -----

**RECEIVING DISTRESS RELAY, *INFO***

If SET UP is entered, the transceiver is set automatically to telephony or telex mode as indicated in the call, and to the appropriate distress and safety frequency in the same band as the call.

END should be entered when communication is completed. The display returns to STATUS or to RX-CALL if not all received calls have been read out and scanning is resumed on the transceiver if so selected.

RECEIVING DISTRESS RELAY



1. A Distress Relay is received.

Press Enter



RX-CALL All ships from: 001234567
Category: Distress Distress relay

Received on 8414.5 kHz >MORE<

2. Enter SET UP. The transceiver is now automatically set to the Distress traffic frequency.

DISTRESS-RELAY Ship:123456789
Position: 55°59'N 133°22'W at 1229 UTC
Undesignated distress USB telephony
>SET UP< QUIT

Hook off the transceiver handset to acknowledge the receipt of the call by telephony.

DISTRESS-RELAY Ship:123456789
Position: 55°59'N 133°22'W at 1229 UTC
Undesignated distress USB telephony
> END<

3. When communication is completed, enter END.



RECEIVING A CALL, INFO

For calls requiring acknowledgement, please refer to page 2-47.

An incoming call will be displayed immediately if the equipment is in the MAIN-MENU or STATUS states. From other states the display returns to the last received RX-CALL instead of STATUS display if a call has been received.

The visual and audible indicators will signal that a call has been received. The visual indicator remains activated until the call has been read out.

If the call does not contain mode information ACCEPT is omitted.

If SET UP is entered the mode and frequency of the transceiver is set as indicated in the call.


END should be entered when communication is completed. The display returns to STATUS or to RX-CALL if not all received calls have been read out and scanning is resumed on the transceiver if so selected.

All-ships, Group and Area calls, not having Distress or Urgency category, are considered obsolete when 5 minutes have passed since the reception of the call. The call is then treated as 'read-out'.

RECEIVING A CALL



1. A Call is received.



RX-CALL All ships to: 001234567
 Category: Safety USB telephony
 Working freq. TX: ----- RX: 1734.0
 Received on 2187.5 kHz >SET UP< QUIT

2. Enter SET UP.
 The transceiver is now automatically set to the mode and frequencies indicated in the call.

RX-CALL All ships to: 001234567
 Category: Safety USB telephony
 Working freq. TX: ----- RX: 1734.0
 Received on 2187.5 kHz > END<


3. When communication is completed, enter END.

All incoming calls are stored. The store has capacity for storing 20 different Distress calls and 20 different other calls. The oldest call in the group in question is deleted when the capacity is exceeded.

To see the content of the store,

press Main Menu >RX-CALLS< Enter

RX-CALLS 1229 UTC 1 JUL 1992
 Distress call from: 123456789
 Received on 2187.5 kHz
 - Change by [<] [>] or [Enter] to view --



selects next or previous call,



displays the complete call.



SENDING AN ACKNOWLEDGEMENT, *INFO*

Selective calls and Direct-dial calls require acknowledgement.

If the call contains Polling, Ship position, or legal mode and Frequency information, transmission of acknowledgement may be initiated by just pressing [Call]. Steps 2 to 5 are then automatically performed.

If the call is a telephony call the same is obtained by just lifting the handset off hook.

When transmission is completed and if the acknowledgement contains mode information, the transceiver is set to the mode and frequencies indicated in the acknowledgement call by pressing [Enter] or, for telephony calls, lifting the handset off-hook within one minute..

END should be entered when communication is completed. For telephony calls just place the handset on hook. The display returns to STATUS or to RX-CALL if not all received calls have been read out and scanning is resumed on the transceiver if so selected.

Note: If the call is not acknowledged within 4.5 minutes ACK is replaced by >TX-CALL<. If this is entered the information in the received call is transferred to a TX-CALL.

SENDING AN ACKNOWLEDGEMENT



1. A CALL requiring acknowledgement is received.

2. Select ACK

Press

Enter

RX-CALL Selective to: 001234567
 Category: Routine USB telephony
 Working freq. TX: 8222.0 RX: 8746.0
 Received on 8436.5 kHz >ACK< END

3. Information is transferred from the received call.
 If able to answer the call, select
 ABLE TO COMPLY

Press

Enter


TX-ACKNOWLEDGEMENT to: 001234567
 Category: Routine USB telephony
 Working freq. TX: 8222.0 RX: 8746.0
 UNABLE TO COMPLY >ABLE TO COMPLY<

4. If frequencies are ok, select OK

Press

Enter

TX-ACKNOWLEDGEMENT to: 001234567
 Category: Routine USB telephony
 Working freq. TX: 8222.0 RX: 8746.0
 >OK< EDIT

5. Press  Call to send the acknowledgement.

or
 provided the call is a telephony call:
 Just hook off the Transceiver handset.
 Steps 2 to 5 are then automatically
 performed.

TX-ACKNOWLEDGEMENT to: 001234567
 Category: Routine USB telephony
 Working freq. TX: 8222.0 RX: 8746.0
 - Press [Call] to send on 8415 kHz -



RECEIVING A DIRECT-DIAL CALL, INFO

Direct-dial calls are used for direct telephone dialling of the ship by a land subscriber through an appropriate coast station providing automatic connection with the public switched telephone network.

If incoming telephone calls cannot be answered for a period, the automatic acknowledgement status of the DSC 9000 should be changed to 'Unable to comply with telephony calls'. In this case the acknowledgement will contain the message 'Unable to comply', and the coast station will after receipt of that message transmit a busy signal to the calling subscriber.

The coast station evaluates the working channel quality during the DSC call. If quality is satisfactory the acknowledgement contains the same working frequencies. The coast station then starts dialling the subscriber.


If the working channel quality evaluation indicates that quality is not satisfactory the coast station may suggest other working frequencies. In this case the DSC calls are repeated on the new working frequencies.

If the working channel quality evaluation again indicates that quality is not satisfactory and no other channels are available the coast station sends an acknowledgement indicating -Cannot use Channel-.

RECEIVING A DIRECT-DIAL CALL



1. A call is received and an acknowledgement is initiated automatically.



```

TX-ACKNOWLEDGEMENT    to: 002192000
Tel : --                USB telephony
Working freq. TX: 2076.0  RX: 1813.0
----- Tuning transmitter -----
----- Checking for free channel -----
----- Transmitting -----
                                     > SET UP <
  
```

2. Lift handset off-hook
or



press
within one minute.
A DSC call is then sent on
the working frequency.

```

TX-CALL    Direct-dial    to: 002192000
Tel : --    USB telephony
Working freq. TX: 2076.0  RX: 1813.0
----- Setting-up transceiver -----
----- Tuning transmitter -----
----- Transmitting -----
----- Awaiting ack on 1813.0 kHz -----
  
```

The coast station evaluates channel quality.
If satisfactory no acknowledgement is sent
and communication with the land subscriber
may begin. After 15 sec the bottom line changes to

> END <

When the call is completed place the handset
on-hook. An 'End of call' DSC message is sent
to the coast station to stop call timing.

```

TX-CALL    Direct-dial    to: 002192000
Tel : --    USB telephony
Working freq. TX: 2076.0  RX: 1813.0
----- Tuning transmitter -----
----- Checking for free channel -----
----- Transmitting -----
----- Awaiting ack on 1813.0 kHz -----
  
```

The acknowledgement from the coast station
may contain information on the chargeable
duration of the call.

```

RX-ACKNOWLEDGEMENT    to: 123456789
Tel: --                End of call
Duration: 0 hours 6 min 35 sec
                                     >QUIT<
  
```

STATUS DISPLAY

The STATUS display comes up when power is switched on or when selected from the MAIN-MENU by selecting STATUS and pressing "Enter". The equipment automatically returns to STATUS display after 10 minutes unless an RX-CALL is displayed or if in Distress Transmit mode.

```
STATUS                      1107 UTC
Distress watch: 2  4  6  8 12 16 MHz
Calling watch:  08 09 11 17 20
                >WATCH ON/OFF< STATUS CHANGE
```

Status display example.

WATCH ON/OFF is omitted if DSC watch-receiver 2 is an additional DU 9006 configured as a DSC watch receiver.

The STATUS display shows the present status of:

- Time**
- Automatic acknowledgement**
- DSC watch-receiver 1**
- DSC watch-receiver 1's watch frequency or frequencies**
- DSC watch-receiver 2**
- DSC watch-receiver 2's watch frequency or frequencies**

Time (UTC) may be set in the programming menu.

Automatic acknowledgement status:

- (Empty)
- Aut ack: Unable

The Automatic ack display field is empty if automatic acknowledgement is set to able to comply. May be changed by selecting >STATUS CHANGE<.

DSC watch-receiver 1 status:

- Distress watch
- Calling watch
- none

Watch-receiver 1 is the built-in receiver of DSC 9001/6. Its status is selected in the configuration menu.

DSC watch-receiver 1 frequency status:

Distress watch MF	2187.5 kHz
Distress watch MF/HF	2, 4, 6, 8, 12, 16 MHz (DSC 9006 only,example)
Calling watch	08, 09, 10, 11, 17, 20 (DSC 9006 only,example)

Shows the frequency(ies) watched by watch-receiver 1.

Calling watch frequencies may be changed by selecting >STATUS CHANGE<.

DSC watch-receiver 2 status:

Distress watch
Calling watch
none

Watch-receiver 2 is either the receiver of the associated MF/HF transceiver (WATCH ON/OFF displayed) or an additional DU 9006 configured as a DSC watch receiver (continuously on). Its status is selected in the configuration menu.

Note: The STATUS line is empty if 'None' is selected by configuration.

DSC watch-receiver 2 frequency status:


Distress watch MF	2187.5 kHz
Distress watch MF/HF	2, 4, 6, 8, 12, 16 MHz (example)
Calling watch	08, 09, 10, 11, 17, 20 (example)

Shows the frequency(ies) watched by watch-receiver 2.

Shows 'Off' if the receiver is switched off.

Calling watch frequencies may be changed by selecting >STATUS CHANGE<.

Watch on the associated MH/HF transceiver may be interrupted/restarted by selecting >WATCH ON/OFF<.

CHANGE STATUS

The change status menu allows selection of:

Automatic acknowledgement
DSC watch-receiver 1's watch frequencies
DSC watch-receiver 2's watch frequencies

Automatic acknowledgement may be set to

Able to comply
Unable to comply with telephony calls

For 'Unable to comply with telephony calls' the reason may be set to

- No reason given
- Congestion
- Station barred
- No operator
- Temporarily no operator
- Equipment disabled

When set to 'Unable to comply with telephony calls' automatic acknowledgement transmissions in response to calls containing a telephony telecommand will contain 'Unable to comply' and the additional message selected.

Automatic acknowledgement transmission takes place only if enabled by automatic ack programming. Automatic acknowledgement of direct-dial calls takes place if Direct-dial format is enabled by configuration. If Direct-dial format is enabled automatic ack of polling calls from coast stations is automatically enabled.

Automatic acknowledgement transmissions does not take place if the handset is off-hook or the equipment is not in STATUS, MAIN-MENU, or RX-CALL state.

Automatic acknowledgement transmissions does not take place if the call is received with error or has distress category.


DSC watch-receiver frequency may be changed as follows:

Distress watch

No change possible.

Calling watch

Frequencies may be selected from the DSC frequency list.
The arrow keys will switch between the selected frequency numbers.
The Enter key will display the frequencies selected and the arrow keys will now move between the frequencies of the DSC frequency list or a list number may be entered. Pressing Enter will select the displayed frequency pair.

PROGRAMMING: AUTOMATIC ACKNOWLEDGEMENT**Polling calls**

press .

PROGRAMMING Automatic acknowledgement

>POLLING< POSITION OTHER

Select between: Off
 All stations
 Specific stations only

press

PROGRAMMING Aut ack of polling calls
 < Specific stations only>

-- Change by [<] [>] or press [Enter] --

If 'Specific stations only' is selected, enter the MMSI number of the stations.

press

PROGRAMMING Aut ack of polling calls
 Specific stations only (002191000)
 (-)
 -- Enter MMSI; use # for any digit --

Position calls

press .

PROGRAMMING Automatic acknowledgement

POLLING >POSITION< OTHER


Select between: Off
 All stations
 Specific stations only

press

PROGRAMMING Aut ack of position calls
 < Specific stations only>

-- Change by [<] [>] or press [Enter] --

If 'Specific stations only' is selected, enter the MMSI number of the stations.

press 

PROGRAMMING Aut ack of position calls
Specific stations only (002191000)
()
-- Enter MMSI; use # for any digit --

Other calls

press 

PROGRAMMING Automatic acknowledgement


POLLING POSITION > OTHER<

Select between: Off
All stations
Specific stations only

press 


PROGRAMMING Aut ack of other calls
< Specific stations only>
-- Change by [<] [>] or press [Enter] --

If 'Specific stations only' is selected, enter the MMSI number of the stations.

press 

PROGRAMMING Aut ack of other calls
Specific stations only (002191000)
()
-- Enter MMSI; use # for any digit --

PROGRAMMING: POSITION**Automatic updating**

If automatic updating from the NMEA input is used the actual position is displayed,  will return to the STATUS display

If not automatically updated, the DSC 9000 should be regularly updated manually in order to be able to receive Area calls correctly.

Manual updating

Select >EDIT< .

Press .

PROGRAMMING Position
55 ° 59 ' N 133 ° 20' W at 1229 UTC
OK > EDIT<

Enter the latitude.

Press .

PROGRAMMING Position
(55 ° 59 ') ° ' at UTC
----- Enter latitude -----

Select S or N using an arrow key.

Press .

PROGRAMMING Position
55 ° 59 ' <N> ° ' at UTC
-- Change by [<] [>] or press [Enter] --

Enter the longitude.

Press .

PROGRAMMING Position
55 ° 59 ' N (133 ° 20') at UTC
----- Enter longitude -----

Select E or W using an arrow key.


Press .

PROGRAMMING Position
55 ° 59 ' N 133 ° 20' <W> at UTC
-- Change by [<] [>] or press [Enter] --


Enter the time.

Press 

PROGRAMMING Position
55 ° 59 ' N 133 ° 20' W at (1229) UTC
--- Enter the time of the position ---

Press  to return to the
STATUS display.

PROGRAMMING Position
55 ° 59 ' N 133 ° 20' W at 1229 UTC
>END<



If more than 12 hours have elapsed since the last updating, the time will be deleted.

PROGRAMMING: PRINTER

Printer Status



The **Printer Status** menu allows selection of:

- Print all calls**
- Print all distress and safety calls**
- Print all RX calls**
- Print distress and safety RX calls**
- Print all RX calls with symbols**
- No print-out**

The arrow key switches between the above options and Enter selects the displayed option and returns to STATUS menu.

Print Lists



The **Print Lists** menu allows selection of:

- Print short-dial list**
- Print DSC frequency list**
- Print Channel list**
- Print MMSI number list**
- Print telephone list**
- Print configuration settings**

The arrow key switches between the above options and Enter selects the displayed option, starts print-out and returns to STATUS menu.

PROGRAMMING: CLOCK SETTING



Enter the UTC time

Press

PROGRAMMING Clock setting
(1229) UTC

----- Enter UTC time -----

Enter the day of month

Press

PROGRAMMING Clock setting
1229 UTC (12)

----- Enter day of month-----

Select the month using an arrow key

Press

PROGRAMMING Clock setting
1229 UTC 12 <Jun>

-- Change by [<] [>] or press [Enter] --

Enter the year

Press

PROGRAMMING Clock setting
1229 UTC 12 Jun (1992)

----- Enter year -----

Press to return to the
STATUS display.

PROGRAMMING Clock setting
1229 UTC 12 Jun 1992

>END<

PROGRAMMING: SOUND SETTING**Distress-alarm sound**

>DISTRESS-ALARM<

Select sound type A or B using an arrow key.

Press

```

PROGRAMMING  Distress-alarm sound
Type <A >    Volume *****
-- Change by [<] [>] or press [Enter] --
  
```

Select the volume level using the arrow keys.

Press

```

PROGRAMMING  Distress-alarm sound
Type A       < Volume **.....>
-- Change by [<] [>] or press [Enter] --
  
```

Press to return to the STATUS display.

>CHANGE< will return to the beginning of distress-alarm sound programming.

>TEST< will generate the selected sound in the loudspeaker.

```

PROGRAMMING  Distress-alarm sound
Type A       Volume **.....
CHANGE TEST >END<
  
```

Call-alarm sound

>CALL-ALARM<

Select for how long the call-alarm shall last using the arrow keys.

Press

```

PROGRAMMING  Call-alarm sound
Duration <.5> Type    Volume *****
-- Change by [<] [>] or press [Enter] --
  
```

Select sound type C or D using an arrow key.

Press


```

PROGRAMMING  Call-alarm sound
Duration .5  Type <C> Volume *****
-- Change by [<] [>] or press [Enter] --
  
```

Select the volume level using the arrow keys.

Press 

PROGRAMMING Call-alarm sound
Duration .5 Type C < Volume** >

Press  to return to the STATUS display.
>CHANGE< will return to the beginning of call-alarm sound programming.
>TEST< will generate the selected sound in the loudspeaker.


PROGRAMMING Call-alarm sound
Duration .5 Type C Volume **

CHANGE TEST >END<

Key-beep sound

>KEY-BEEP< 

Select the volume level using the arrow keys.

Press  to return to the STATUS display.

PROGRAMMING Key-beep sound
Illegal key volume < Volume** >
-- Change by [<] [>] or press [Enter] --

PROGRAMMING: LIGHT SETTING



Select the "Day" setting for the display backlight using the arrow keys.

Press 

```

PROGRAMMING  Backlight  Indicators
              Day:  <*****.>  *****..
              Night:  **.....  ***.....
-- Change by [<] [>] or press [Enter] --
  
```

Select the "Day" setting for the indicators using the arrow keys.

Press 

```

PROGRAMMING  Backlight  Indicators
              Day:  *****..  <*****.>
              Night:  **.....  ***.....
-- Change by [<] [>] or press [Enter] --
  
```


Select the "Night" setting for the display backlight using the arrow keys.

Press 

```


PROGRAMMING  Backlight  Indicators
              Day:  *****..  *****..
              Night:  <*.....>  ***.....
-- Change by [<] [>] or press [Enter] --
  
```

Select the "Night" setting for the indicators using the arrow keys.

Press  to return to the STATUS display.

```


PROGRAMMING  Backlight  Indicators
              Day:  *****..  *****..
              Night:  **.....  <***.....>
-- Change by [<] [>] or press [Enter] --
  
```



The light in the Distress and Call indicators cannot be reduced completely.

PROGRAMMING: CONTRAST SETTING

Select the contrast setting using the arrow keys.

Press  to return to the STATUS display.

The screenshot shows the 'PROGRAMMING' menu with 'Contrast setting' highlighted. The display shows '< * * * * >' for the contrast level. Below this, it says '-- Change by [<] [>] or press [Enter] --'.

PROGRAMMING: DSC-FREQUENCY LIST




The DSC-frequency list is pre-programmed but can be changed as described below.

Use the arrow key to change between the DSC-frequency numbers or enter the DSC-frequency number of the frequency pair that you want to change and press



PROGRAMMING DSC frequency list
 <01 NATIONAL TX: 2156.0 RX: 1621.0 kHz>
 -- Change by [<] [>] or press [Enter] --

Press  to edit the displayed frequency pair.

Enter a name for this frequency number.



PROGRAMMING DSC frequency list
 01 (NATIONAL) TX: 2156.0 RX: 1621.0 kHz
 ----- Enter name -----

Enter the DSC transmit frequency.



PROGRAMMING DSC frequency list
 01 NATIONAL (TX: 2156.0) RX: 1621.0 kHz
 ---- Enter own DSC transmit frequency ----

Enter the DSC receive frequency.



PROGRAMMING DSC frequency list
 01 NATIONAL TX: 2156.0 (RX: 1621.0) kHz
 ---- Enter own DSC receive frequency ----



If all fields are empty or "0" the number is deleted from the list.
 The distress and safety frequencies (94-99) cannot be edited.
 The pre-programmed DSC frequency list is printed on the next page.

PRE-PROGRAMMED DSC FREQUENCIES

01	NATIONAL	Tx:	2156.0	Rx:	1621.0 kHz
02	NATIONAL		2156.5		1621.5
03	NATIONAL		2157.0		1622.0
04	NATIONAL		2157.5		1622.5
05	NATIONAL		2158.0		1623.0
06	NATIONAL		2158.5		1623.5
07	NATIONAL		2159.0		1624.0
08	NATIONAL		2159.5		1624.5
09	SHIP		2177.0		2177.0
10	INTER		2189.5		2177.0
11	INTER 1		4208.0		4219.5
12	INTER 2		4208.5		4220.0
13	INTER 3		4209.0		4220.5
14	INTER 1		6312.5		6331.0
15	INTER 2		6313.0		6331.5
16	INTER 3		6313.5		6332.0
17	INTER 1		8415.0		8436.5
18	INTER 2		8415.5		8437.0
19	INTER 3		8416.0		8437.5
20	INTER 1		12577.5		12657.0
21	INTER 2		12578.0		12657.5
22	INTER 3		12578.5		12658.0
23	INTER 1		16805.0		16903.0
24	INTER 2		16805.5		16903.5
25	INTER 3		16806.0		16904.0
26	INTER 1		18898.5		19703.5
27	INTER 2		18899.0		19704.0
28	INTER 3		18899.5		19704.5
29	INTER 1		22374.5		22444.0
30	INTER 2		22375.0		22444.5
31	INTER 3		22375.5		22445.0
32	INTER 1		25208.5		26121.0
33	INTER 2		25209.0		26121.5
34	INTER 3		25209.5		26122.0
35	INTER		458.5		455.5
94	DISTRESS		2187.5		2187.5
95	DISTRESS		4207.5		4207.5
96	DISTRESS		6312.0		6312.0
97	DISTRESS		8414.5		8414.5
98	DISTRESS		12577.0		12577.0
99	DISTRESS		16804.5		16804.5


PROGRAMMING: MMSI LIST

Use the arrow key to change between the MMSI list numbers or enter the MMSI list number that you want to program and press



```

PROGRAMMING                                MMSI list
<01  Name: LYNGBY  MMSI: 002191000>
--  Change by [<] [>] or press [Enter]  --
  
```

Press  to edit the displayed MMSI list number.

Enter a name for the vessel or coast station.



```

PROGRAMMING                                MMSI list
01  Name: (LYNGBY)  MMSI: 002191000
-----  Enter name  -----
  
```

Enter the MMSI number of the vessel or coast station.



```

PROGRAMMING                                MMSI list
01  Name: LYNGBY  MMSI: (002191000)
- Enter maritime mobile service identity -
  
```



If all fields are empty or "0" the number is deleted from the list.

Either the nine-digit MMSI number or the MMSI list number (0-99) may be entered when composing a TX-CALL.

When [Enter] is pressed the name and the nine-digit MMSI number is displayed.

When entering an unprogrammed list number the illegal-key sound is given and the number is deleted.

If, when receiving a call, the MMSI number of the calling station is found in the MMSI list, the name of the station will be displayed along with the nine-digit MMSI number.

PROGRAMMING: TELEPHONE LIST



Use the arrow key to change between the telephone list numbers or enter the telephone list number that you want to program and

press

PROGRAMMING Telephone list
 <01 4542482544 SKANTI>
 -- Change by [<] [>] or press [Enter] --

Press to edit the displayed telephone list number.

Enter the telephone number.

Press

PROGRAMMING Telephone list
 01 (4542482544) SKANTI
 ----- Enter telephone number -----

Enter the name of the subscriber.

Press

PROGRAMMING Telephone list
 01 4542482544 (SKANTI)
 ----- Enter name -----



If all fields are empty or "0" the number is deleted from the list.

Either the telephone number or the telephone list number (1-99) may be entered when composing a Direct-dial call.

When [Enter] is pressed the telephone number and the name is displayed.

When entering an unprogrammed list number the illegal-key sound is given and the number is deleted.

TEST: INFO**Accumulated ON-time**

>ACCUMULATED-ON-TIME<

 The number of operating hours is displayed.

 Press to return to the STATUS display.

TEST Accumulated ON-time
 Operating hours: 128
 >END<

Version

>VERSION<

TEST Version
 DCU > DU <

> DCU <

 The program version and date for DCU is displayed.

TEST Version
 DCU program: 01.07.00 Date: 930621
 >END<


Press to return to the STATUS display.



The program version and date is displayed if selecting DU.
 If an additional DU is connected the program version and date for both units are shown. DU 2 denotes the additional unit.

TEST: SELF-TEST

The test starts immediately and will continue until all test are completed and found ok.

Press  to end the test and return to status display.

TEST	Automatic Self-test
Completed	19 steps ok
	0 bypassed
	0 failed
	>END<

If a test fails the self-test will stop and display:

test step no.	
name of the failing test	
error code	

Press  to continue.


TEST	Automatic Self-test
03 Synthesizer test:	Failed
Error code: 0301	>CONTINUE< END

If any the self test will stop on the next failure.

Press  to continue.

TEST	Automatic Self-test
04 Synthesizer test:	Failed
Error code: 0411	>CONTINUE< END

When all test are completed a test status is displayed.

Press  to end the test and return to status display.

TEST	Automatic Self-test
Completed	19 steps ok
	0 bypassed
	2 failed
	>END<



The error code consists of step number (2 digits), indication of previous faults (1 digit: 0=no, 1=yes) and failure type (1 digit).

If an additional DU is connected a selftest on that is included in the sequence. The display will indicate that DU 2 is tested.

TEST: RX-AUDIO

Select which receiver to test using the arrow keys.


Press  to perform the audio test.

TEST

RX-audio

>WATCH-1< WATCH-2 TRANSCEIVER

Adjust the volume level using the arrow keys.

Press  to end the test and return to the status display.

TEST


Watch-1

RX-audio

>END<


TEST: TX-TEST

A message of warning is displayed.

Press  to continue with the test.


TEST TX-test
A test message is transmitted on a
distress frequency in this test
>CONTINUE< END

Enter the MMSI number of the coast station
to receive the test call.

Press  .

TX-CALL Selective to: (00123456)

-Enter the maritime mobile service identity-

Press  to select the DSC frequency.

TX-CALL Selective to: (00123456)

- Press [Enter] to select DSC frequency -

Select a DSC distress frequency
using the arrow keys.

Press  .

DSC FREQUENCY SELECTION
<94 DISTRESS Tx: 2187.5 Rx 2187.5>
-- Change by [<] [>] or press [Enter] --

Press  to transmit the test.

TX-CALL Selective to: 00123456
Category: Safety Test


- Press [Call] to send on 2187.5 kHz -

----- Tuning transmitter -----

----- Checking for free channel -----

----- Transmitting -----

----- Awaiting ack on 2187.5 kHz -----

Press  to return to status display.

RX-ACKNOWLEDGEMENT from: 00123456
Category: Safety Test
No additional information
Received on 2187.5 kHz >END<

3. INSTALLATION Table of Contents

Description	3-3	Connectors	3-27
Mounting the units	3-3	Supply terminal strip, DU 9000	3-28
Power supply	3-4	Supply cable specifications	3-29
Earth connections	3-4	Earth connections	3-30
Antenna	3-5	Antenna connector	3-30
Interconnection of units	3-5	Interconnection of units	3-31
Connection of MF/HF transceiver	3-6	Net connector, DCU 9000 and DU 9000	3-32
Connection of an additional DU	3-7	Mounting bracket terminal board	3-33
Connection of radiotelex equipment	3-7	Aux connector, DCU 9000	3-34
Connection of navigation equipment	3-8	Com connector, DU 9000	3-36
Connection of a printer	3-9	Aux connector, DU 9000	3-38
Connection of a distress alarm box	3-10	Optional handset hook-switch for TRP 8000	3-40
Connection of remote alarms	3-10	Handset with built-in hook switch	3-42
Figures and tables			
DCU 9000 mounting on DU 9000	3-12	Connector for built-in handset hook-switch	3-42
DCU 9000 - DU 9000 outline	3-13	Distress alarm box	3-43
DCU 9000 - DU 9000 interconnecting ribbon cable	3-14	Radiotelex interconnections	3-44
Cable connection for DCU 9000 mounting on DU 9000	3-15	Installation wiring diagram	3-45
DCU 9000 with mounting bracket	3-16	Pcb 717 jumper and adjustment locations	3-47
DCU 9000 installation with mounting bracket	3-17	Installation configuration	3-48
DCU 9000 installation with mounting bracket "Low profile mounting"	3-18	Configuration of self-id	3-48
DCU 9000 installation with mounting bracket "Flush mounting"	3-19	Configuration of group-id	3-48
DCU 9000 installation with mounting bracket 19 inch panel mounting	3-20	Configuration of control unit priority	3-48
Terminal board mounting options	3-21	Configuration of radio interface	3-49
DCU 9000 without mounting bracket	3-22	Configuration of handset hook-switch interface	3-49
DCU 9000 without mounting bracket 19 inch panel mounting	3-23	Configuration of DSC-watch	3-50
Cable connections for DCU without mounting bracket	3-24	Configuration of telex interface	3-50
DU 9000 outline	3-25	Configuration of printer interface	3-50
DU 9000 cable connections	3-26	Configuration of external alarms	3-51
		Configuration of formats	3-51
		Configuration of messages	3-52
		Accessories included	3-53
		Optional accessories	3-54

DESCRIPTION

General

Correct installation of the DSC 9000 is important for maximum performance and reliability. This chapter provides specific information about the installation of each unit, their interconnection and connection to other equipment.

Mounting the Units

DCU 9000 Control Unit

The DCU 9000 control unit is adaptable to a variety of mounting methods and should be placed with convenient operation in mind. It may be mounted directly on the front of the DU 9000 forming an integrated controller-receiver unit, or it may be installed separately with or without the mounting bracket.

DCU 9000 mounting on DU 9000

When mounted on the front of the DU 9000 (fig. 1 at page 3-12), the two units must be interconnected by means of the ribbon cable included. Depending on which way the DCU 9000 is turned relative to the DU 9000, the cable must be bent as shown in fig.3a at page 3-14 or fig.3b at page 3-14 respectively. To install the ribbon cable, remove the top cover of the DU 9000. Plug the cable into the corresponding socket on PCP 717 and place it between the two guiding tabs at the front top of the DU 9000. Refit the top cover. Plug the D-sub connector into the Net socket on the DCU 9000 as shown in fig.4 at page 3-15 and arrange the ribbon cable appropriately before fixing the DCU 9000 to the DU 9000.

All external connections to the DSC 9000 are made to the connectors at the rear of the DU 9000.

DCU 9000 with Mounting Bracket

The mounting bracket (fig. 5 at page 3-16) is used for table mounting of the DCU 9000, and may also be used for bulkhead and console mounting as shown in fig.6 at page 3-17 and fig.7 at page 3-18. Fig.7 shows how the mounting bracket may be installed behind a bulkhead or a console panel for low profile mounting. Fig.8a and 8b at page 3-19 and fig.9a and 9b at page 3-20 shows how flush mounting may be obtained and gives the dimensions for the necessary hardware.

External connections to the DCU 9000 are made to the terminal strips of the mounting bracket. For top side cable entry the Terminal Board may be dismantled and turned 180 degrees as illustrated in fig.10b at page 3-21.

DCU 9000 without Mounting Bracket

The DCU 9000 without mounting bracket may be bulkhead or console mounted as shown in fig.11 at page 3-22. Fig.12a and 12b at page 3-23 shows how flush mounting may be obtained and gives the dimensions for the necessary hardware.

External connections to the DCU 9000 are made to the connectors at the back of the unit as illustrated in fig.13 at page 3-24.

DU 9000

The DU 9000 DSC unit should be installed in a dry place near the associated radiotelephone and consideration should be given to accessibility for service. Airspace should be provided around the unit for adequate air circulation through the unit and the heat sink at the exterior of the unit. Fig 14 at page 3-25 shows the mounting possibilities and overall dimensions and shows the minimum distances to other objects ensuring good cooling.

External connections to the DU 9000 are made to the connectors at the back of the unit as illustrated in fig.15 at page 3-26.

Power Supply

The DSC 9000 operates at voltages between 10.8 and 41.6 VDC and may be powered from a 12V, 24V, or 32V battery or from an AC Power Supply Unit with a DC output voltage within the specified range.

When used with a Skanti TRP 7000 or TRP 8000 transceiver the AC Power Supply Unit of the transceiver is capable of supplying the additional power required by the DSC 9000.

The supply leads are connected to the supply terminal strip of the DU 9000. The supply terminal strip is adapted for screened power supply cable. Note that fuses must be provided in the supply leads to protect the cable. Table 2 at page 3-29 shows the necessary cable cross section and external fuse rating.

Earth connection of the equipment will not cause the battery to be earthed. Maximum permissible peak voltage between the battery terminals and the earth is 100V. The supply input is protected against polarity reversal.

Earth Connections

The earth terminal of each unit, where separated, should be connected to earth using 2.5mmSq wire, see fig.18 at page 3-30. The wire should be as short as possible and preferably be connected to a separate earth screw, which should not be shared by any other equipment. The earth lead should run as far away from the transmitter earth lead as possible.

Antenna

The antenna should be erected well in the clear and kept away as far as possible from electrical equipment in order to minimize noise. Length: 7-30m.

Electrical installation such as cable braiding and instruments in the vicinity of the antenna should be earthed effectively, and the instruments in question should be fitted with noise-interference suppression devices, effective in the range 0.1 to 30 MHz.

The antenna feed-in should be coaxial cable, which should be as short as possible, especially in the case of short antennas. If a long cable is used an impedance matching transformer should be inserted in the antenna end of the feeder. For connector and cable specifications, see fig.19 at page 3-30.

Interconnection of Units

The units of the DSC 9000 are interconnected using a screened multiwire cable containing 5 twisted pairs of wire between the Net connectors of each unit.

Important: Each unit contains a jumper which connects a 120 ohm resistor between terminals 2 and 3 of the net connectors, providing the necessary termination impedance for the serial data bus of the net. The jumper must be removed if the unit is not located at the end of the chain.
See fig. 20 at page 3-31

The DU 9000-end of the cable is prepared by soldering a 9-pole D-Sub connector at the as described in fig.21 at page 3-32. Assure that the twisted wires are correctly paired.

Where the mounting bracket is used, the DCU 9000-end of the cable is connected to the terminal strip of the bracket, see fig.22 at page 3-33. Otherwise a 9-pole D-sub connector is used at this end as well.

Prepared 5x2x0.25mmSq screened cable with 9-pole D-sub connector at each end may be obtained from Skanti in 3m and 10m lengths:

3m: Part number 106 803 61

10m: Part number 106 803 51

Up to 5 control units may be connected to the DU 9000. The units must be chain connected.

Table 1 below shows the maximum permissible cable lengths for different numbers of control units, using the cable type specified in fig.21 at page 3-32.

Number of Control Units	Maximum cable length
1	180m
2	100m
3	75m
4	58m
5	47m

Table 1

Where control units are distributed along the line, their relative contribution to the cable load may be calculated by dividing each length of cable by the maximum length specified for the number of control units sharing that particular length of cable. The sum of all relative contributions must not exceed 1.

Example:

One control unit located 20m from the DU 9000

One control unit located 140m from the first DCU 9000

$$\frac{20}{100} + \frac{140}{180} = 0.2 + 0.78 = 0.98$$

which is less than 1 and thus acceptable.

One of the control units may be given priority, see the *Installation Configuration* section at page 3-48.

Connection of MF/HF Transceiver

The MF/HF transceiver is connected to the 25 pole D-sub connector marked **Com** on the DU 9000. See table 5 at page 3-37 for pin assignments and fig 24 at page 3-36 for connector and cable specifications.

The installation wiring diagram on page 3-45 details the connections for Skanti transceivers TRP 7000 and TRP 8000.

Note: *Telex filter is necessary in TRP 7000/8000*

The DSC 9000 is factory configured for control of frequency and mode for automatic set-up of the radio equipment for DSC traffic and automatic change-over to working frequencies and mode as indicated in DSC calls. If not used for Radiotelex the receiver in the TRP 7000 or TRP 8000 may be utilized for scanning of up to 6 DSC calling channels while the built-in receiver of the DSC 9000 simultaneously maintains continuous watch.

Note: *For automatic mode set-up and external control of scanning receiver the program version of TRP 7000 or TRP 8000 must be compatible.*

To enhance the automatic control facilities a handset hook signal must be fed to the DSC 9000.

For TRP 7000 the handset hook-switch is built-in.

For TRP 8000 with old handset type, an optional hook-switch must be installed below the handset holder, see fig.26 at page 3-40.

For TRP 8000 with new handset type with built-in hook-switch, connection is made via a Din-connector, inserted in the extra socket of the handset holder. See fig.27 at page 3-42 for pin assignments.

The handset hook signal is used for stop and start of scanning on the transceiver scanning receiver, for inhibiting automatic acknowledgement transmission while the transceiver is used for telephony and for initiating automatic set-up of working frequencies, etc.

The AF output level from the DSC 9000 for transmitter modulation is factory preset to 0 dBm which matches Skanti transceivers TRP 7000 and TRP 8000. Adjustment, where required, is possible over the range -10 dBm to +10 dBm by trimpot R8, located on PCB 717, see fig. 31 at page 3-47.

The AF input level to the DSC 9000 from the external receiver should be in the range -30 to +10 dBm. The TRP 7000 and TRP 8000 are factory preset to 0 dBm. The input impedance is factory set to 600 ohms. High impedance is selectable by removing jumper J1 on PCB 717, see fig. 31 at page 3-47.

See the *Installation Configuration* section at page 3-48 for change of Radio Interface configuration.

Connection of an Additional DU

A DU 9006 DSC Unit may be connected to the DSC 9000 as an additional DU if a second continuous watch receiver is needed.

The built-in watch receiver of the DSC 9000 is typically used for the mandatory continuous DSC watch-keeping on the distress and safety frequency/-ies. Reception of DSC calls for public correspondence in the MF/HF bands demands an additional receiver, keeping watch on the appropriate calling frequencies. The DSC 9000 allows the receiver of the associated TRP 7000 or TRP 8000 to be used as this second watch receiver, but in cases where this is not desired, either because the transceiver is used for automatic telex or because continuous DSC calling watch is required, a DU 9006 configured as watch receiver may be used. When connected, this will automatically take over the watch-receiver 2 function otherwise assigned to the transceiver.

The DU 9006 is configured by inserting a coded 25-pole D-sub plug in the **AUX** socket. The plug is coded by connecting pin 18 to pin 23 and pin 10 to pin 25.

For interconnection with the DSC 9000 the Net connectors are used, please refer to page 3-5 *Interconnection of Units*. The antenna signal may conveniently be taken off at the antenna output of the DSC 9000. Power consumption of the DU 9006 is 15 W except for max. one minute following switch-on during which period it is 50 W. The installation wiring on page 3-45 shows the necessary connections. No other connections should be made to the additional DU.

First time the combination is switched on with a new ID the display will flicker for approx. one minute while self-ID and group-IDs are transferred to the additional DU and stored in the local EEPROM.

Connection of Radiotelex Equipment

External radiotelex equipment is connected to the 25 pole D-sub connector marked **Aux** on the DU 9000. See table 6 at page 3-39 for pin assignments and fig.25 at page 3-38 for connector and cable specifications.

The radiotelex equipment is automatically switched to the transceiver, when this is not in use by the DSC equipment. The simplified diagram in fig 30 at page 3-44 illustrates the interconnections.


Connection of Navigation Equipment

Navigation equipment complying with the NMEA 0183 standard may be connected for automatic position updating. Connection is made either to the DU 9000 or to a DCU 9000 control unit but, only one navigation input can be used. The DSC 9000 automatically recognizes which input is used.

For connection to the DU 9000 use the 25 pole D-sub connector marked **Aux**. See table 6 at page 3-39 for pin assignments and fig.25 at page 3-38 for connector and cable specifications.

For connection to a DCU 9000 control unit, use the 15 pole D-sub connector marked **Aux**. See table 4 at page 3-35 for pin assignments and fig.23 at page 3-34 for connector and cable specifications. Where the mounting bracket is used, the cable is connected to the terminal strip of the bracket, see fig.22 at page 3-33.

The NMEA receive circuit consists of an optoisolator with a 3.3 kohms series resistor to insure current mode operation and a shunt diode to limit reverse bias as shown below. The circuit is isolated from earth.




The circuit operates with a minimum differential input voltage of 3 volts and takes less than 1 mA from the line at that voltage. The maximum voltage is 15 volts, compatible with RS-232 levels.

Interconnection between devices may be by means of two-conductor shielded twisted-pair wire. Multiple listeners may be connected to a single talker. The receivers are connected in parallel. The shield should be connected to the navigator chassis and should not be connected at any listener. However the shield should be continuous (unbroken) between all listeners.

Following sentences are recognized by the DSC 9000 for extraction of position information:

GGA:



GLL:

```
$--GLL, llll.ll, a, yyyy.yy, a, hhmmss.ss, A*hh<CR><LF>
```

_____ Status: A=Data valid
 _____ UTC of position fix
 _____ Longitude, E/W
 _____ Latitude, N/S

GXP:

```
$--GXP, hhmmss.ss, llll.ll, a, yyyy.yy, a, c--c, x*hh<CR><LF>
```

_____ Satellite number
 _____ Waypoint ID
 _____ Longitude, E/W
 _____ Latitude, N/S
 _____ UTC of position fix

GDP:

```
$--GDP, hhmmss.ss, llll.ll, a, yyyy.yy, a, c--c*hh<CR><LF>
```

_____ Waypoint ID
 _____ Longitude, E/W
 _____ Latitude, N/S
 _____ UTC of position fix

GLP:

```
$--GLP, hhmmss.ss, llll.ll, a, yyyy.yy, a, c--c*hh<CR><LF>
```

_____ Waypoint ID
 _____ Longitude, E/W
 _____ Latitude, N/S
 _____ UTC of position fix

GOP:

```
$--GOP, hhmmss.ss, llll.ll, a, yyyy.yy, a, c--c*hh<CR><LF>
```

_____ Waypoint ID
 _____ Longitude, E/W
 _____ Latitude, N/S
 _____ UTC of position fix

*hh: Optional checksum delimiter and optional checksum field.
 Not used by DSC 9000.

Connection of a Printer

A printer with serial interface may be connected to either the DU 9000 or a DCU 9000 control unit. Only one printer may be connected. The DSC 9000 must be configured for the connection selected. See the *Installation Configuration* section at page 3-48.

The printer interface is opto-isolated with driver power delivered from the printer (most printers deliver a +5 to +15 V signal on one of the connector pins when operational).

For connection to the DU 9000 use the 25 pole D-sub connector marked **Com**. See table 5 at page 3-37 for pin assignments and fig.24 at page 3-36 for connector and cable specifications.

For connection to a DCU 9000 control unit, use the 15 pole D-sub connector marked **Aux**. See table 4 at page 3-35 for pin assignments and fig.23 at page 3-34 for connector and cable specifications. Where the mounting bracket is used, the cable is connected to the terminal strip of the bracket, see fig.22 at page 3-33.

Connection of a Distress Alarm Box

A distress alarm box consisting of a Distress button and an associated Distress lamp may be connected to the DCU 9000 control unit or to the DU 9000 DSC unit for remote initiation and indication of distress calls.

Fig.29 at page 3-43 shows the control box and a simplified diagram of the interconnections.

The Distress button is operated in exactly the same way as the Distress key on DCU 9000: To initiate a distress call press the push-button for 6 sec (until the distress lamp stops quick-flashing and shows steady light) and release.

The equipment will send the Distress call as previously prepared. If position is automatically updated the latest values at the time of activation is used including time information.

The Distress lamp flashes when a distress or urgency call has been received.

For connection to a DCU 9000 control unit use the 15 pole D-sub connector marked **Aux**. See table 4 at page 3-35 for pin assignments and fig.23 at page 3-34 for connector and cable specifications. Where the mounting bracket is used, the cable is connected to the terminal strip of the bracket, see fig.22 at page 3-33.

Alternatively, connection may be made to the DU 9000 using the 25 pole D-sub connector marked **Aux**. See table 6 at page 3-39 for pin assignments and fig.25 at page 3-38 for connector and cable specifications. Either *Alarm 1 Out* or *Alarm 2 Out* may be used, but the one selected must be configured to follow the '*Distress Alarm + lamp*'. See the *Installation Configuration* section at page 3-48.

Connection of Remote Alarms

The *Alarm 1 Out* and *Alarm 2 Out* terminals of the DU 9000 Aux connector enables external lamps, buzzers, bells or other visual or audible indicators to be connected to the equipment. Each output may be configured separately to be active when

- the aural Distress alarm sounds, or
- the aural Call alarm sounds, or
- either alarm sounds *), or
- distress lamp is illuminated and distress alarm sounds


*) The on/off pattern resembles the alarm sound types, so it is possible to distinguish between distress alarm and call alarm.

For connection to the DU 9000 use the 25 pole D-sub connector marked **Aux**. See table 6 at page 3-39 for pin assignments and fig.25 at page 3-38 for connector and cable specifications. See the *Installation Configuration* section at page 3-48 for setting-up the alarm outputs.

FIGURES AND TABLES


DCU 9000 MOUNTING ON DU 9000

Fig.1




DCU 9000 - DU 9000 OUTLINE

Fig.2



- 1) Space for air flow: min. 100
- 2) Space for service access: min. 500
- 3) Space for cable entry and air flow: min. 200



Dimensions are in mm

Tolerance: ± 1 mm


● Centre of Gravity

Weight: DSC 9001 8.6 Kg


Weight: DSC 9006 8.7 Kg

DCU 9000 - DU 9000 INTERCONNECTING RIBBON CABLE

Folding the ribbon cable for table top mounting.
Fig.3a




Folding the ribbon cable for bulkhead mounting.
Fig.3b




CABLE CONNECTION FOR DCU 9000 MOUNTING ON DU 9000

Fig.4




DCU 9000 WITH MOUNTING BRACKET

Fig.5



DCU 9000 INSTALLATION WITH MOUNTING BRACKET

Fig.6



1) Space for cable entry min. 50


Dimensions are in mm

Tolerance: ± 1 mm


● Centre of Gravity

Weight: DCU 1.2 Kg


Weight: Mounting Bracket 0.7 Kg



DCU 9000 INSTALLATION WITH MOUNTING BRACKET "LOW PROFILE MOUNTING" Fig.7



- 1) Space for cable entry min. 50




Dimensions are in mm

Tolerance: +/- 1 mm


 Centre of Gravity

Weight: DCU 1.2 Kg

Weight: Mounting Bracket 0.7 Kg

DCU 9000 INSTALLATION WITH MOUNTING BRACKET**"FLUSH MOUNTING" Fig.8a**


Dimensions are in mm Weight: DCU 1.2 Kg
 Tolerance: +/- 1 mm Weight: Mounting Bracket 0.7 Kg
 ● Centre of Gravity

Construction drawing for Fixture. Fig.8b

1) Customize to Bulkhead thickness.
 Dimensions are in mm
 Tolerance: +/- 0.2 mm


DCU 9000 INSTALLATION WITH MOUNTING BRACKET

19 INCH PANEL MOUNTING Fig.9a



Dimensions are in mm Weight: DCU 1.2 Kg
 Tolerance: +/- 1 mm Weight: Mounting Bracket 0.7 Kg
 ● Centre of Gravity

Construction drawing for Fixture. Fig.9b




Dimensions are in mm
 Tolerance: +/- 0.2 mm

TERMINAL BOARD MOUNTING OPTIONS


NORMAL MOUNTING OF TERMINAL BOARD

Fig.10a




180 ° MOUNTING OF TERMINAL BOARD

Fig.10b



DCU 9000 WITHOUT MOUNTING BRACKET


Fig.11




1) Space for cable entry min. 100


Dimensions are in mm

Tolerance: +/- 1 mm

 Centre of Gravity

Weight: 1.2 Kg




DCU 9000 WITHOUT MOUNTING BRACKET**19 INCH PANEL MOUNTING Fig.12a**

Dimensions are in mm Weight: DCU 1.2 Kg

Tolerance: ± 1 mm

● Centre of Gravity


Construction drawing for Fixture. Fig.12b

Dimensions are in mm

Tolerance: ± 0.2 mm


CABLE CONNECTIONS FOR DCU WITHOUT MOUNTING BRACKET

Fig.13



DU 9000 OUTLINE

Fig.14



- 1) Space for air flow: min. 100
- 2) Space for service access: min. 500
- 3) Space for cable entry and air flow: min. 200


Dimensions are in mm

Tolerance: ± 1 mm

● Centre of Gravity


Weight: DU 9001 7.4 Kg

Weight: DU 9006 7.5 Kg



DU 9000 CABLE CONNECTIONS

Fig.15



CONNECTORS**DCU 9000 CONNECTORS**

Fig.16a




**DU 9000 CONNECTORS**

Fig.16b



SUPPLY TERMINAL STRIP, DU 9000

Fig.17



SUPPLY CABLE SPECIFICATIONS

Battery Voltage	Max. Cable Length to Battery	Recommended Cable	External fuses
12V	3.5m	Screened multiwire 2 X 2.5mmSq	20A
12V	8m	Screened multiwire 2 X 6mmSq	20A
24V	10m	Screened multiwire 2 X 1.5mmSq	10A
24V	16m	Screened multiwire 2 X 2.5mmSq	10A
24V	40m	Screened multiwire 2 X 6mmSq	10A
32V	15m	Screened multiwire 2 X 1.5mmSq	6.3A
32V	24m	Screened multiwire 2 X 2.5mmSq	6.3A
32V	60m	Screened multiwire 2 X 6mmSq	6.3A


Table 2

EARTH CONNECTIONS

Fig.18


DCU 9000, EARTH CONNECTION

Skanti part no. 772 000 17



DU 9000, EARTH CONNECTION

Skanti part no. 772 000 14




Wire specification

Recommended wire dimension: min. 2.5 mm Sq .
Wire length as short as possible.

ANTENNA CONNECTOR

Fig.19




Connector type: PL 259, SKANTI part no. 751 000 54


Cable specification: Coaxial cable type RG-213/U or RG 8A/U

INTERCONNECTION OF UNITS


Fig.20a



NET TERMINATION JUMPER LOCATION



DCU
Fig.20b




DU
Fig.20c

NET CONNECTOR, DCU 9000 AND DU 9000

Fig.21

SKANTI part no. 751 000 64.



Identify twisted pairs.

Before contacts of plug are soldered: slide the plastic cover over the cable .

After the contacts are soldered: latch the inner and outer shields into the connectors from the rear and snap in.

Finally slide the plastic cover over the shield and fix the two jack screws into the plastic cover.


Pin no.	Designation	Remarks
1	Supply On	For switching-on power supply
2	Data+	For data communication between units
3	Data-	For data communication between units
4	AF+	Balanced audio signals
5	AF-	Balanced audio signals
6	GND	Ground reference
7	+24V	Supply voltage to control units
8	RXAF+	Not used in DSC 9000
9	RXAF-	Not used in DSC 9000
Shield	Cable screen	

Table 3**Twisted pairs:**

1 and 6
2 and 3
4 and 5
6 and 7
8 and 9

MOUNTING BRACKET TERMINAL BOARD

Fig.22




995 509 91 A

AUX CONNECTOR, DCU 9000

Fig.23

SKANTI part no. 751 000 65.



Cable specification

Acommodate cable outer diameter from 4.4 to 11.0 mm

Pin no.	Designation	Direction	Remarks
1	PC DTR / V+	Input	+5V/+15V supply for opto-isolated serial data interface for printer (RS-232) *)
2	PC GND		Power supply reference for serial data interface for printer (RS-232) *)
3	Alarm Out	Output	Open collector (RS-410N) for external alarm. Max 50mA, 32V. Active Low
4	Alarm In	Input	For external distress alarm button. Internal pull-up to 15V through 2.5kohm.
5	NMEA Rx+	Input	Opto-isolated serial interface for navigation equipment (NMEA 0183)
6	n.c.		
7	n.c.		
8	n.c.		
9	PC Rx	Input	Serial data input or busy input for printer (RS-232) *)
10	PC Tx	Output	Serial data output for printer (RS-232) *)
11	+24 V	Output	+24V for use with 'Alarm Out'. Max 100 mA. Internally protected.
12	GND		
13	NMEA Rx-	Input	Opto-isolated serial interface for navigation equipment (NMEA 0183)
14	n.c.		
15	n.c.		

Table 4

*) The printer interface is opto-isolated with driver power delivered from the printer. Most printers deliver a High (+5V to +15V) signal on one of the connector pins when the printer is operational. Opto-isolation may be disabled by connecting the terminals PC GND and GND and connecting a 2.2 kohm resistor between the terminals +24V and PC DTR/V+.

The terminal 'PC RX' is used for handshake signal input:

If Xon/Xoff handshake is used, the terminal must be connected to the outgoing serial data pin of the printer.


If Busy (High/Low) handshake is used, the terminal must be connected to the printer Ready/Busy signal output.

See page 3-50 for configuration of printer interface.

COM CONNECTOR, DU 9000

Fig.24



SKANTI part no 751 000 66.




Before contacts of plug are soldered: slide the plastic cover over the cable .

After the contacts are soldered: latch the inner and outer shields into the connectors from the rear and snap in.

Finally slide the plastic cover over the shield and fix the two jack screws into the plastic cover.



Contact arrangement (viewed from solder side)



Cable specification

Acommodate cable outer diameter from 4.4 to 11.0 mm

Pin no.	Designation	Direction	Remarks
1	GND		
2	Print RX	Input	Serial interface for printer (RS-232) *)
3	Print Tx	Output	Serial interface for printer (RS-232) *)
4	On-Hook	Input	Internal pull-up to 12V through 1.8kohm (RS-410N). Low for handset off-hook = normal. (Configurable)
5	n.c.		
6	PCP Tx	Output	Serial interface for transceiver control (RS-232)
7	Print GND		Serial interface for printer (RS-232) *)
8	Rx Line-	Input	For external receiver AF 0 dBm -30/+10 dB 600 ohm, free of earth **)
9	+15V	Output	+15V, $R_i=470$ ohm
10	n.c.		
11	GND		
12	Key Out	Output	Open collector (RS-410N). Max 50mA, 32V Low for keying TX
13	GND		
14	S/S Out	Output	Open collector (RS-410N). Max 50mA, 32V Not used
15	Tx Line-	Output	AF for transmitter modulation Adjustable -10/+10 dBm 600 ohm, free of earth
16	Tx Line+	Output	AF for transmitter modulation Adjustable -10/+10 dBm 600 ohm, free of earth
17	GND		
18	n.c.		
19	PCP Rx	Input	Serial interface for transceiver control (RS-232)
20	Print V+	Input	+5V/+15V supply for opto-isolated serial interface for printer *)
21	Rx Line+	Input	For external receiver AFInput 0 dBm -30/+10 dB 600 ohm, free of earth **)
22	n.c.		
23	n.c.		
24	GND		
25	+24V	Output	+24V. Max 100 mA. Internal fuse. Not used
Shield	Cable screen		

Table 5

The printer interface is opto-isolated with power delivered from the printer. Most printers deliver a High (+5V to +15V) signal on one of the connector pins when the printer is operational. Opto-isolation may be disabled by inserting jumpers J10, J11 and J12 on PCB 717. See fig.31 on page 3-47.


The terminal 'Print RX' is used for handshake signal input:

If Xon/Xoff handshake is used, this terminal must be connected to the outgoing serial data pin of the printer. If Busy (High/Low) handshake is used, the terminal must be connected to the printer Ready/Busy signal output. See page 3-50 for configuration of printer interface

AUX CONNECTOR, DU 9000

Fig.25



SKANTI part no 751 000 66.




Before contacts of plug are soldered: slide the plastic cover over the cable .

After the contacts are soldered: latch the inner and outer shields into the connectors from the rear and snap in.

Finally slide the plastic cover over the shield and fix the two jack screws into the plastic cover.



Contact arrangement (viewed from solder side)



Cable specification

Acommodate cable outer diameter from 4.4 to 11.0 mm

Pin no.	Designation	Direction	Remarks
1	GND		
2	PC Rx	Input	Serial interface for PC or radiotelex equipment (RS-232) *)
3	PC Tx	Output	Serial interface for PC or radiotelex equipment (RS-232) *)
4	Alarm 1 out	Output	Open collector (RS-410N) for external alarm. Max 50mA, 32V. Active Low
5	NMEA Rx+	Input	Opto isolated serial interface for navigation equipment (NMEA 0183)
6	On-Hook	-	Connected to Com pin 4.
7	PC GND		Serial interface for PC or radiotelex equipment (RS-232) *)
8	Rx Line-	Output	AF for radiotelex equipment. Connected to Rx Line-input (Com connector)
9	n.c.		
10	Disable	Input	Disables +24V output to Net when connected to pin 24
11	GND		
12	Key In	Input	Internal pull-up to 12V through 1kohm (RS-410N). Low for keying TX from radiotelex equipment
13	GND		
14	n.c.		
15	Tx Line In-	Input	AF from radiotelex equipment. Connected to Tx Line- (Com connector)
16	Tx Line In+	Input	AF from radiotelex equipment. Connected to Tx Line+ (Com connector) when DSC is not transmitting
17	NMEA Rx-	Input	Opto isolated serial interface for navigation equipment (NMEA 0183)
18	Alarm In	Input	For external distress alarm button. Internal pull-up to 12V through 1.8kohm.
19	n.c.		
20	PC DTR	Input	+5V/+15V supply for opto-isolated serial interface for PC or radiotelex equipment (RS-232) *)
21	Rx Line+	Output	AF for radiotelex equipment. Connected to Rx Line-input (Com connector)
22	n.c.		
23	Alarm 2 Out	Output	Open collector (RS-410N) for external alarm. Max 50mA, 32V. Active Low
24	GND		
25	+24V	Output	+24V for use with 'Alarm 1 Out' and 'Alarm 2 Out'. Max 100 mA. Internal fuse.
Shield	Cable screen		

Table 6

*) Opto-isolated with driver power delivered from PC (DTR).
 (Non-isolated: Set Jumpers J8, J9, and J13 on PCB 717 ON)
 Note. If non-isolated. Pin 20 PC DTR must not be connected.

OPTIONAL HANDSET HOOK-SWITCH FOR TRP 8000

Fig.26a






Fig.26b




993 741 71 A

Fig.26c



HANDSET WITH BUILT-IN HOOK SWITCH


Fig.27



CONNECTOR FOR BUILT-IN HANDSET HOOK-SWITCH

Fig.28

SKANTI part no 751 001 72.



Before contacts of the plug are soldered:
slide plastic cover over the cable.


After the contacts are soldered: the two shields
are latched into the connector and snapped in.
Finally slide the plastic cover over the shield.

Pin No.	Designation	Remarks
1	HOOK-ON	Low when the handset is placed in the holder
2	NC	
3	NC	
4	NC	
5	NC	
6	GND	

Table 7

DISTRESS ALARM BOX

Fig.29
Diagram.




DISTRESS BUTTON: Press and hold in for 6 seconds.


DISTRESS LAMP:	<i>Flashing:</i>	Distress or Urgency call received
	<i>Quick flashing:</i>	Distress button activated
	<i>Steady light:</i>	Distress alert in progress

RADIOTELEX INTERCONNECTIONS

Fig.30.
Simplified diagram



DSC 9000 INSTALLATION WIRING DIAGRAM



Pos	Connector Types	
1	15-pole D-Sub male	751 000 65
3	9-pole D-Sub male	751 000 64
4	Tab Connector	772 000 17
5	Cable Lug	772 000 14
6	UHF Plug Type PL 259	751 000 54
7	25-pole D-Sub male	751 000 66

Pos	Cable Types	
8	Coaxial, RG-213/U or RG-8A/U	
9	5 x 2 x 0.25mmSq Screened	
10	4 x 0.25mmSq Screened	
11	2 x 0.25mmSq Screened	
12	5 x 2 x 0.25mmSq Screened	

DCU 9000	
Aux Connector Pin No.	
9	PC RX
10	PC TX
1	PC DTR
2	PC GND
3	Alarm Out
11	+24V
4	Alarm In
12	GND
5	NMEA RX+
13	NMEA RX -


DU 9000	
AUX Pin no.	
8	RX Audio
21	RX Audio
15	TX Audio
16	TX Audio
12	Key
13	GND
2	Data Out
3	(Data In)
20	(DTR)
7	Data GND

DU 9000	TRP 7000 w.PCB717	TRP 7000 w.PCB718	TRP 8000		Remarks
Com Pin No.	Com Pin No.	Com Pin No.	601 TS1 Term.No.	Hook Switch	
8	8	8	18		RX Audio
21	21	21	17		RX Audio
15	15	15	12		TX Audio
16	16	16	13		TX Audio
12	12	12	9		Key
13	13	13+7	2		GND
6	6	2	1		Data
19	19	3	3		Data
9		20			+15V
4	4	4		1	Hook
17				x	GND

- Note 1: Where more units are chain connected the termination jumper is removed from units not located at the end of the chain.
- Note 2: One additional receiver may be connected to the antenna output.
- Note 3: May alternatively be connected to DU 9000 Com connector.
- Note 4: May alternatively be connected to DU 9000 Aux connector.
- Note 5: Screen connected at navigator only.
- Note 6: Configuration plug. Connect pin 18 to pin 23 and pin 10 to pin 25.

PCB 717 JUMPER AND ADJUSTMENT LOCATIONS

Fig.31

**Trimpot R8***AF output level.*

For adjustment of signal level on Tx Line.
 Factory setting: 0 dBm.

Jumper J1*Input impedance.*

When On the input impedance of Rx Line is 600 ohms.
 When Off the input impedance is high.
 Factory setting: On.

Jumpers J2 and J4*Not used.***Jumper J3***Test mode.*

Enables Special Test mode when On.
 Factory setting: Off.

Jumper J5, J6 and J7*Not used.* Left open.**Jumpers J8, J9 and J13***PC interface (DU 9000).*

When all three jumpers are On the opto-isolation is suspended.
 Factory setting: Off.

Jumpers J10, J11 and J12*Printer interface (DU 9000) .*

When all three jumpers are On the opto-isolation is suspended.
 Factory setting: Off.

Red LED V23*Program activity.*

Normal operation is indicated by regular flashing.

Factory resetting

With the equipment on, disconnect Supply Voltage.
 Insert 'Factory Resetting Plug' in the COM connector on the DU 9000.
 Switch supply on for 30 seconds.
 Disconnect supply voltage.
 Remove 'Factory Resetting Plug'.
 Reconnect Supply Voltage.

Note: Factory Resetting must be made after exchange of software (EPROMs).

INSTALLATION CONFIGURATION

The DSC 9000 is factory configured to standard settings, stored in a non-volatile EEPROM. Change of these settings is possible from the front panel of the DCU 9000.

To view or change configuration settings, switch the equipment on, press [Main Menu], select CONFIGURATION and press [Enter]. Select VIEW or CHANGE and press [Enter].

To protect against unintentional changes a password must be entered if CHANGE is selected. The figures are not displayed while keyed-in.

Note: Following any change in configuration setting the supply must be switched off-on to implement the changes.

Configuration of Self-ID

The Maritime Mobile Service Identity assigned to the station must be stored in the DSC 9000 before it can be used.

Select SELF-ID in the CONFIGURATION menu and press [Enter]. Key-in the MMSI and press [Enter].

To prevent the operator from changing the self-ID, it must be protected by entering PROTECT. *Please note that once PROTECT has been entered, change of self-ID is not possible* (only after a factory resetting. See page 3-47). Therefore, check the numbers carefully for correctness before pressing [Enter].

Configuration of Group-ID

One or more group call identities may be assigned to the station. Group call identity numbers always contains a leading zero. The group call identities assigned to the station must be stored in the DSC 9000 before it is able to respond to group calls. Up to six group call identity numbers may be stored.

Select GROUP-ID in the CONFIGURATION menu and press [Enter]. Key-in the group call identities and press [Enter]. Check that the self-ID is correct after having switched the equipment off and on.

Configuration of Control Unit Priority

Where more control units are connected to a DU 9000 each control unit may be given a priority.

Only a control unit with higher priority can interrupt a control unit which is in any other state than MAIN-MENU or STATUS states.

To change the priority level select PRIORITY in the CONFIGURATION menu and press [Enter]. Select the desired priority level (1. priority is the highest level) and press [Enter].

Note: If an external distress alarm button is connected to a control unit, this control unit should be given priority

Configuration of Radio Interface

The DSC 9000 may be configured for different protocols for control of the associated radio equipment:

T+Bus (default)
T+Bus, one way
NMEA

Baudrate 2400 bps for T+Bus and 4800 bps for NMEA is implicitly selected.

Following NMEA sentences are used to set frequency, mode of operation and transmitter power level of the radio equipment.

RX frequency:

```
$CDFSI, ,xxxxxx,c,*hh<CR><LF>
      |           |
      |           |— Mode of operation1
      |           |— Receiving frequency2
```

TX frequency:

```
$CDFSI, ,xxxxxx,c,9*hh<CR><LF>
      |           |
      |           |— Power level (9=highest)1
      |           |— Mode of operation1
      |           |— Transmitting frequency2
```

Notes:

1) Mode of operation:

m = J3E, telephone
o = H3E, telephone
w = F1B/J2B, teleprinter/DSC
{ = A1A Morse, morse key/headset

2) Frequency in 100 Hz increments.

To change configuration select INTERFACES in the CONFIGURATION menu and press [Enter]. Select RADIO in the Interfaces menu and press [Enter]. Select CONTROL in the Radio interface menu and press [Enter]. Select the desired option and press [Enter].

Configuration of Handset Hook-Switch Interface

The handset hook interface may be configured for either polarity of the input signal or for ignoring the input, i.e. if no hook-switch is connected.

To change configuration select INTERFACES in the CONFIGURATION menu and press [Enter]. Select RADIO in the Interfaces menu and press [Enter]. Select HANDSET-HOOK in the Radio interface menu and press [Enter]. Select the correct option Normal, Reverse or Ignore. 'Normal' corresponds to off-hook = low input signal. Press [Enter].

TRP 7000: Normal

TRP 8000 handset with built-in hook switch: Reverse

The handset hook signal is utilized as follows:

When the receiver of the radiotelephone is used for scanning controlled from the DSC 9000 or radiotelex equipment, scanning is interrupted while the handset is off-hook. At the same time automatic DSC acknowledgement transmissions are disabled. Scanning is automatically resumed when the handset is placed on-hook.

When a Selective or Direct-dial telephony call is received, lifting the handset off-hook will stop the acoustic alarm, start transmission of an acknowledgement, and set the radiotelephone to the appropriate working frequencies.

Configuration of DSC-watch

The DSC 9000 enables two DSC watch receivers to be used simultaneously. The status display contains a line for each receiver/demodulator, indicating the DSC watch frequencies.

It is possible by configuration to select between different DSC watch lay-outs in the status display:

Distress watch MF

Distress watch MF/HF

Calling watch

None

One of the lay-outs may be selected for each watch receiver.

To change the configuration, select WATCH in the CONFIGURATION menu and press [Enter]. Select the desired configuration for each watch receiver and press [Enter].

Note: When the TRP 7000 or TRP 8000 is intended to be used for automated radiotelex and no additional DU configured as a DSC watch receiver is connected (see page 3-7 'Connection of an additional DU'), 'None' should be selected for 'watch receiver 2'.

Configuration of Telex Interface

Select INTERFACES in the CONFIGURATION menu and press [Enter]. Select TELEX in the Interfaces menu and press [Enter]. Select 'External modem' if an external radiotelex modem is used and press [Enter].

Configuration of Printer Interface

Select INTERFACES in the CONFIGURATION menu and press [Enter]. Select PRINTER in the Interfaces menu and press [Enter]. Select between connection to

This DCU, None/other DCU, or DU*

and press [Enter]. Select between Baud rates of

300, 600, 1200, 2400, 4800*, or 9600

and press [Enter]. Select between Parity/data bits

None/7, None/8*, Even/7, Even/8, Odd/7, or Odd/8

and press [Enter]. Select between handshake types

Xon/xoff, Busy High, Busy Low, None*

and press [Enter]. Select between paper feed

Up* or Down

and press [Enter].

*) Default

Configuration of External Alarms

Select INTERFACES in the CONFIGURATION menu and press [Enter]. Select ALARMS in the Interfaces menu and press [Enter]. Select for each output in turn the desired activation conditions:

Distress alarm only

Call alarm only

Distress + Call alarm

Distress alarm + lamp

Configuration of Formats

Certain call formats may be omitted. This enables the DSC 9000 to be adapted to specific applications where it is desirable to avoid unintended use of these formats.

The formats that can be disabled are:

Distress

Group + Area

Direct-dial

To change the configuration, select FORMAT in the CONFIGURATION menu and press [Enter]. Select 'Yes' to include a format, or 'No' to disable a format, and press [Enter].

All formats can be received and displayed in RX-calls irrespective of the configuration settings.

Configuration of Messages

It is possible to select between the full set of telecommands or a reduced set. The reduced set may be selected where it is desirable to avoid unintended use of the telecommands.

Full set of telecommands:

- Polling
- Unable to comply
- Congestion
- Busy
- Queue
- Station barred
- No operator
- Temporarily no opr
- Equipment disabled
- Cannot use channel
- Cannot use mode
- Data V.21
- Data V.22
- Data V.22 bis
- Data V.23
- Data V.26 bis
- Data V.26 ter
- Data V.27 ter
- Data V.32
- USB telephony
- AM telephony
- Distress relay
- FEC telex
- ARQ telex
- RTTY receive
- RTTY
- A1A/CW tape
- Ship position
- A1A/CW Morse
- Facsimile
- No information

Reduced set of telecommands:

- USB telephony
- Distress relay
- FEC telex
- ARQ telex

Only messages enabled by configuration are selectable in TX-calls. All messages may be displayed in RX-calls and TX-acknowledgements, irrespective of the configuration.

ACCESSORIES INCLUDED

DCU 9000:

<u>DESIGNATION</u>	<u>QUANTITY</u>	<u>SKANTI PART NUMBER</u>
Mounting bracket for DCU 9000	1	107 810 40
D-sub connector, 9 pole, male	2	751 000 64
D-sub connector, 15 pole, male	1	751 000 65
Tab connector, female	1	772 000 17

DU 9000:

<u>DESIGNATION</u>	<u>QUANTITY</u>	<u>SKANTI PART NUMBER</u>
Technical manual	1	910 000 63
D-sub connector, 25 pole, male	2	751 000 66
Set of labels for 25 pole connectors	1	345 507 91
UHF plug, type PL 259	1	751 000 54
Cable lug	1	772 000 14
Ribbon cable assembly, DCU-DU	1	106 810 80
Fuse 5x20mm, 200 mA Slow	1	720 220 02

OPTIONAL ACCESSORIESDESIGNATIONSKANTI PART NUMBER

Hook-switch assembly for TRP 8000 old handset		107 609 00
DIN connector, 6 pole, for TRP 8000 new handset		751 001 72
Cable 2x0.25mmSq screened, length: 100 metres		702 000 33
Cable 4x0.25mmSq screened, length: 100 metres		702 000 34
Cable 5x2x0.25mmSq screened, length: 100 metres		702 000 35
Cable assembly 5x2x0.25mmSq screened with 9 pole D-sub connectors, length:	3 metres	106 803 61
	10 metres	106 803 51

4. TECHNICAL DESCRIPTION Table of Contents

DSC Control Unit, DCU 9000	4-3	Synthesizer Board 711	4-7
Control Board 901	4-3	Master Oscillator 713	4-7
Front Panel Board 902	4-3	Receiver Signal Path 915	4-7
Terminal Board 903	4-4	SMPS/Interconnection 930	4-7
 DSC Unit, DU 9001	4-5	Diagrams	
Programmable Communication Processor 717	4-5	Block Diagram DCU 9000	4-9
Master Oscillator 913	4-5	Interconnection Diagram DCU 9000	4-10
Single Channel Receiver 914	4-6	Block Diagram DU 9001	4-11
SMPS/Interconnection 930	4-6	Interconnection Diagram DU 9001	4-12
 DSC Unit, DU 9006	4-7	Block Diagram DU 9006	4-13
Programmable Communication Processor 717	4-7	Interconnection Diagram DU 9006	4-14

DSC CONTROL UNIT, DCU 9000

Block diagram: page 4-9.

Interconnection diagram: page 4-10.

The primary function of the control unit is to support the man/machine interface via keyboard, display, and visual and audible indicators. It contains following PCB's:

Control Board 901:

Contains a micro-controller unit which performs keyboard scanning, display and indicator LED driving, control of display contrast, control of display and keyboard backlight, control of loudspeaker volume, sensing of Alarm Button, and control of Alarm Out interface.

Via an asynchronous communication interface adaptor and an opto-isolated RS-232 receiver/driver a serial interface printer may be controlled if connected to the PC terminals. The opto-isolated driver is supplied from the printer. Input from navigational equipment with NMEA 183 interface are received via another opto-isolated receiver and asynchronous communication interface adaptor.

The micro-controller communicates with the microprocessor of the DU 9000 via a serial bus using the CAN (Controller Area Network) communication protocol. The baud rate on the bus is 76.8 kbits/sec and the interface to the micro-controller is made by a dedicated CAN controller chip.

A temperature sensor monitors the internal air temperature of the control unit near the LCD display to automatically adjust for the temperature dependent contrast setting variation of the display and at the same time adjust the maximum level of the display backlight intensity to highest permissible at the given temperature.

The audio amplifier feeding the built-in loudspeaker of the control unit amplifies audible alarm signals and illegal key beep signals generated by the micro-controller or may be switched to monitor RX Audio signals on the Net AF lines.

A switched mode voltage converter transforms the DCU supply voltage (nominally 24V) to the 5V needed by the digital circuitry and the LCD display and its LED backlight. The audio amplifier and keyboard backlight are supplied directly by the input voltage which may vary between 19V and 28V dependent on interconnecting cable length. A current controlled backlight driver insures that the backlight intensity is independent of the input voltage.

Front Panel Board 902:

Carries keyboard switches, LCD display and backlight, 14 keyboard backlight LEDs connected in two chains, and a relay connecting the Supply On/Off key switch to the Supply On wire to DU 9000 in the off condition and to the micro-controller of the control unit in the on condition.

Also carries a 15-pole D-sub connector for connecting auxiliary equipment and two 9-pole D-sub Net connectors for connecting the DU 9000 and possibly one or more additional units. A jumper connects a 120 ohm resistor between terminals 2 and 3 of the Net connectors, providing the necessary termination impedance of the serial data bus of the net. The jumper must be removed if the unit is not located at the end of a chain.

The optional Mounting Bracket for DCU 9000 contains following PCB:

Terminal Board 903:

Contains terminal blocks for connecting auxiliary equipment and for the Net cable to the DU 9000. Ribbon cable connectors provides for connection to the control unit.

DSC UNIT, DU 9001

Block diagram: page 4-11.

Interconnection diagram: page 4-12.

The primary functions of the DU 9001 are the DSC controller function with two independent demodulators and single channel watch reception on the MF distress and safety DSC frequency 2187.5 kHz. It contains following PCB's:

Programmable Communication Processor 717:

Contains a 80C186 16 bit microprocessor with its peripherals, a real time clock, interface circuits for alarm, handset hook, and key input signals, interface circuits for alarm and key output signals, four asynchronous communication interface adaptors for serial communication with radiotelex equipment (PC), radio equipment (PCP), printer, and navigational equipment (NMEA). The driver/receivers for PC, printer and NMEA are opto-isolated with driver power delivered from the equipment connected. Opto isolation may be disabled by inserting appropriate jumpers.

The microprocessor communicates with the micro-controller of the DCU 9000 control unit via a serial bus using the CAN (Controller Area Network) communication protocol. The baud rate on the bus is 76.8 kbits/sec and the interface to the microprocessor is made by a dedicated CAN controller chip.

Timer circuits for the modulator generates the continuous phase frequency shift keyed signal as a square wave at eight times the modulation frequency. Subsequent filtering in a transversal filter followed by a low pass analog filter leaves an FSK modulated sine wave at the desired frequency. The signal is routed through audio switches to an adjustable output amplifier. The modulator signal may also be routed to each of the demodulators for test purposes.

The input signals for the two demodulators coming from the built-in receiver via RSP AF and from an external receiver via LINE IN and connected to Demodulator 1 and 2 respectively are each filtered in an analog band-pass filter before being applied to the demodulators. The demodulators controls two timers, which forms the interface to the microprocessor.

Master Oscillator 913:

The master oscillator includes a stable oven controlled crystal oscillator (OCXO) which generates an accurate 17.325 MHz for the first mixer of the Single Channel Receiver 914.

Single Channel Receiver 914:

The single channel receiver is fixed tuned to 2187.5 kHz. It includes antenna input protection, pre-selector, 1. mixer where the input signal is mixed with a 1.7325 MHz signal originating from the master oscillator signal divided by 10, followed by a narrow-band crystal filter with a centre frequency of 455 kHz, IF amplifier, and 2. mixer. The local oscillator signal for this is generated by a 7.2528 MHz crystal oscillator the output of which is divided by 16 to produce a frequency of 453.3 kHz. The output from the mixer is low-pass filtered and the AF signal centred around 1.7 kHz is finally amplified in an AF amplifier. A self-test facility is included comprising injection of a test signal at the input of the receiver and signal check at the AF output.

SMPS/Interconnection 930:

The Switched Mode Power Supply part includes control and protection circuit. The SMPS generates all the voltages needed in the DSC 9000 galvanically isolated from the battery. The SMPS is protected against wrong input voltage level and polarity.

The interconnection part includes a splitter for the antenna signal allowing an additional receiver to be connected to the same antenna, and a relay which in standby directs modulation output from an external modem to the transmitter.

DSC UNIT, DU 9006

Block diagram: page 4-13.

Interconnection diagram: page 4-14.

The primary functions of the DU 9006 are the DSC controller function with two independent demodulators and scanning watch reception on up to six MF/HF DSC frequencies. It contains following PCB's:

Programmable Communication Processor 717:

See description above.

Synthesizer Board 711:

The synthesizer board includes synthesizers, dividing/multiplication circuits and check detectors. The 1st, 2nd and 3rd local oscillator receive their reference signal from the master oscillator PCB 713. The 1. local oscillator covers the frequency range from 45 MHz to 75 MHz and generates the injection signal for the 1. mixer on Receiver Signal Path 915. The 2. local oscillator generates by division and multiplication a 44.544 MHz signal for the 2. mixer. The 3. local oscillator generates a 456.5 kHz signal for the modulation/demodulation process.

Master Oscillator 713:

The master oscillator includes a highly stable oven controlled crystal oscillator (OCXO) which generates an accurate 17.8176 MHz reference signal for Synthesizer Board 711.

Receiver Signal Path 915:


The receiver signal path includes antenna input protection, pre-selector, 1. mixer where the input signal is mixed with the 1. local oscillator of the synthesizer, followed by a 45 MHz crystal filter, 1. IF amplifier, and 2. mixer. The local oscillator frequency for this is 44.544 MHz corresponding to a 2. IF frequency of 455 kHz. The 2. IF filter is a narrow-band crystal filter. In the 3. mixer the IF signal is mixed with 456.7 kHz producing an AF signal centred around 1.7 kHz. A self-test facility is included comprising injection of test signals at the 1. mixer from the synthesizer and signal check at the AF output.

SMPS/Interconnection 930:

See description above.


BLOCK DIAGRAM DCU 9000

DSC CONTROL UNIT




INTERCONNECTION DIAGRAM DCU 9000

DSC CONTROL UNIT




BLOCK DIAGRAM DU 9001




INTERCONNECTION DIAGRAM DU 9001

DSC UNIT



BLOCK DIAGRAM DU 9006

DSC UNIT



DSC UNIT



5. SERVICE Table of Contents

Preventive Maintenance	5-3	DSC 9000 spare-parts	5-15
Realignment of Master Oscillator		DSC Control Unit Spare-parts	5-16
713 (DSC 9006 only)	5-3	DSC Unit 9001 Spare-parts	5-18
Replacement of back-up battery	5-4	DSC Unit 9006 Spare-parts	5-20
Self-test	5-5	SKANTI Service Agents	5-22
DSC 9001 test-step description and error			
code explanation	5-6		
DSC 9006 test-step description and error			
code explanation	5-8		

PREVENTIVE MAINTENANCE

Realignment of Master Oscillator 713 (DSC 9006 only)

The Master Oscillator frequency should be checked at least once a year. The Master Oscillator determines the exact receive frequency of the equipment. The oscillator tends to age very slowly with time, typically with the highest drift rate the first year. The check should be performed by a qualified technician with the necessary test equipment at his disposal.

1. Measuring equipment:

Frequency counter: Frequency range 100 MHz
 Input impedance 50 ohms
 Sensitivity at least 0.2 VRMS
 Accuracy better than 0.01 ppm

2. Preparations:

- 2.1 Switch on the power at least 30 minutes before adjustment.
- 2.2 Remove the front cover of the DU 9006.
- 2.3 Locate and disconnect 711X10 carrying the 2. Local Oscillator signal from the Synthesizer Board 711 to Receiver Signal Path 915. Connect the frequency counter to the X10 socket on the synthesizer.
- 2.4 The ambient temperature should be between 10 and 30 deg. Celsius. Be sure that thermal equilibrium has taken place before adjustment.

3. Realignment of Master Oscillator:

- 3.1 Locate the Master Oscillator adjustment hole in the metal shield of the Synthesizer Board 711. Use a small screwdriver to gently adjust the frequency.
- 3.2 Adjust the frequency as close as possible to 44.544 000 MHz.
 Adjustment tolerance +/- 1 Hz.
- 3.3 Re-connect X10 and refit the front cover.

Replacement of back-up battery

The DSC 9000 uses a lithium battery to back-up the memory when power supply is switched off. The expected battery life time is minimum 6 years.

The manufacturing date is marked on the battery.

When servicing the equipment, always check the date on the battery and replace if the minimum battery life time has expired or expires in the near future.


1. Turn on the DSC 9000. This will prevent loss of memory content.
2. Remove the front cover of the DU 9001/6.
3. Disconnect the battery plug.
4. Remove the battery container from its compartment by pulling the nylon string.
5. Read the manufacturing date on the battery. If life time is due to expire, replace the complete battery container.
Skanti part number 107 811 60.
6. Push the battery container back into its compartment and connect the battery plug.
7. The DSC 9000 may now be turned off without losing memory content.

Warning:

The battery contains lithium. Do not recharge, disassemble, heat above 100 deg.C, incinerate, or expose contents to water.

SELF-TEST

The Self-test menu is selected by pressing:



Automatic self-test is performed to check all test-steps in the self-test. It will stop if a test-step fails or all tests are completed. If a test-step fails the test will stop and display the failing test-step number, the failing part of the DSC, the possible cause of failure and an error code. A description of each test-step along with the error code explanation is listed in this chapter.

Self-test example:
completed without fail.

```

TEST    Automatic Self-test
Completed    19 steps ok
              0 bypassed
              0 failed          >END<
  
```

Fig. 1

Self-test example:
completed with 2 fails.

```

TEST    Automatic Self-test
03 Synthesizer test:          Failed
Error code: 0301          >CONTINUE< END
  
```

Fig. 2

```

TEST    Automatic Self-test
04 Synthesizer test:          Failed
Error code: 0411          >CONTINUE< END
  
```

Fig. 3

```

TEST    Automatic Self-test
Completed    19 steps ok
              0 bypassed
              2 failed          >END<
  
```

Fig. 4

The error code consists of step number (2 digits), indication of previous faults (1 digit: 0=no, 1=yes) and failure type (1 digit).

If an additional DU is connected a Self-test on that is included in the sequence. The display will indicate that DU 2 is tested.

Test-step description and error code explanation**DSC 9001:**

Step no. 01 Receiver test.

Tests Single Channel Receiver PCB 914.

The receiver is muted. The AF Detector at the output checks that no signal is present.

The test is OK if $\overline{\text{AF CHECK}}=1$

<u>Error code</u>	<u>Possible error source</u>
0101	PCB 914 or cable
0102	RSP AF cable or PCB 717

Step no. 02 Receiver test.

Tests Single Channel Receiver PCB 914.

A 2187.5 kHz test signal is generated locally and injected at the pre-selector input of the receiver. The signal passes the receiver where it is mixed to a 1.7 kHz tone. The AF Detector at the output checks that signal is present.

The test is OK if $\overline{\text{AF CHECK}}=0$

<u>Error code</u>	<u>Possible error source</u>
0201	PCB 914 or cable
0202	RSP AF cable or PCB 717

Step no. 03 EEPROM test

Tests Programmable Communication Processor PCB 717.
Checks and re-writes the EEPROM.

The test is OK if the checksum is correct.

<u>Error code</u>	<u>Possible error source</u>
1801	PCB 717

Step no. 04 DCU test

Tests the DCU 9000.

<u>Error code</u>	<u>Test</u>	<u>Possible error source</u>
1901	Audio/Speaker	PCB 901, cable, PCB 902, speaker
1902	Display backlight	Display, PCB 901
1903	Keyboard backlight	PCB 902, cable, PCB 901
1904	Contrast circuit	PCB 901, display
1905	Distress LED	PCB 902, cable, PCB 901
1906	Call LED	PCB 902, cable, PCB 901
1907	Supply LED	PCB 902, cable, PCB 901

DSC 9006:

Step no. 01 Master Osc. test.

Tests if Master Oscillator is oscillating, using MO check.

<u>Error code</u>	<u>Possible error source</u>
0101	PCB 713, PCB 711, cable

Step no. 02 Synthesizer test.

Tests Synthesizer PCB 711 all local oscillators.
Tests that synthesizer is able to lock in mid-range.

Band: 45 - 52.5 MHz
1. LO: 50.00000 Hz
3. LO: 456.7 kHz

The test is OK if SYNCHECK=1

<u>Error code</u>	<u>Possible error source</u>
0201	PCB 711 or cable

Step no. 03 Synthesizer test.

Tests Synthesizer PCB 711 1. LO.
Tests if 1. LO is able to get out of lock to check that microprocessor can control synthesizer.

Band: 45 - 52.5 MHz
1. LO: 75.00000 MHz
3. LO: 456.7 kHz

The test is OK if SYNCHECK=0

<u>Error code</u>	<u>Possible error source</u>
0301	PCB 711 or cable

Step no. 04 Synthesizer test.

Tests Synthesizer PCB 711 1. LO.

Tests if 1. LO is able to lock in band 0 low border.

Band: 45 - 52.5 MHz

1. LO: 45.00000 MHz

3. LO: 456.7 kHz

The test is OK if SYNCHECK=1

<u>Error code</u>	<u>Possible error source</u>
0401	PCB 711 or cable

Step no. 05 Synthesizer test.

Tests Synthesizer PCB 711 1. LO.

Tests if 1. LO is able to lock in band 0 high border.

Band: 45 - 52.5 MHz

1. LO: 52.50000 MHz

3. LO: 456.7 kHz

The test is OK if SYNCHECK=1

<u>Error code</u>	<u>Possible error source</u>
0501	PCB 711 or cable

Step no. 06 Synthesizer test.

Tests Synthesizer PCB 711 1. LO.

Tests if 1. LO is able to lock in band 1 low border.

Band: 52.5 - 60 MHz

1. LO: 52.50000 MHz

3. LO: 456.7 kHz

The test is OK if SYNCHECK=1

<u>Error code</u>	<u>Possible error source</u>
0601	PCB 711 or cable

Step no. 07 Synthesizer test.

Tests Synthesizer PCB 711 1. LO.

Tests if 1. LO is able to lock in band 1 high border.

Band: 52.5 - 60 MHz

1. LO: 60.00000 MHz

3. LO: 456.7 kHz

The test is OK if SYNCHECK=1

<u>Error code</u>	<u>Possible error source</u>
0701	PCB 711 or cable

Step no. 08 Synthesizer test.

Tests Synthesizer PCB 711 1. LO.

Tests if 1. LO is able to lock in band 2 low border.

Band: 60 - 67.5 MHz

1. LO: 60.00000 MHz

3. LO: 456.7 kHz

The test is OK if SYNCHECK=1

<u>Error code</u>	<u>Possible error source</u>
0801	PCB 711 or cable

Step no. 09 Synthesizer test.

Tests Synthesizer PCB 711 1. LO.

Tests if 1. LO is able to lock in band 2 high border.

Band: 60 - 67.5 MHz

1. LO: 67.50000 MHz

3. LO: 456.7 kHz

The test is OK if SYNCHECK=1

<u>Error code</u>	<u>Possible error source</u>
0901	PCB 711 or cable

Step no. 10 Synthesizer test.

Tests Synthesizer PCB 711 1. LO.

Tests if 1. LO is able to lock in band 3 low border.

Band: 67.5 - 75 MHz

1. LO: 67.50000 MHz

3. LO: 456.7 kHz

The test is OK if SYNCHECK=1

<u>Error code</u>	<u>Possible error source</u>
1001	PCB 711 or cable

Step no. 11 Synthesizer test.

Tests Synthesizer PCB 711 1. LO.

Tests if 1. LO is able to lock in band 3 high border.

Band: 67.5 - 75 MHz

1. LO: 75.00000 MHz

3. LO: 456.7 kHz

The test is OK if SYNCHECK=1

<u>Error code</u>	<u>Possible error source</u>
1101	PCB 711 or cable

Step no. 12 Synthesizer test.

Tests Synthesizer PCB 711 3. LO.

Tests if 3. LO is able to get out of lock to check that microprocessor can control synthesizer.

Band: 67.5 - 75 MHz

1. LO: 75.00000 MHz

3. LO: 400.00 kHz

The test is OK if SYNCHECK=0

<u>Error code</u>	<u>Possible error source</u>
1201	PCB 711 or cable

Step no. 13 Synthesizer test.

Tests Synthesizer PCB 711 3. LO.

Tests if 3. LO is able to lock at low border.

Band: 67.5 - 75 MHz

1. LO: 70.0000 MHz

3. LO: 452.57 kHz

The test is OK if SYNCHECK=1

<u>Error code</u>	<u>Possible error source</u>
1301	PCB 711 or cable

Step no. 14 Synthesizer test.

Tests Synthesizer PCB 711 3. LO.

Tests if 3. LO is able to lock at high border.

Band: 67.5 - 75 MHz

1. LO: 70.0000 MHz

3. LO: 460.50 kHz

The test is OK if SYNCHECK=1

<u>Error code</u>	<u>Possible error source</u>
1401	PCB 711 or cable

Step no. 15 Rx signal path test.

Tests Rx Signal Path PCB 915 I/O register addressing.

Reads the OPTION INST signal.

The test is OK if VERSION-0=1

<u>Error code</u>	<u>Possible error source</u>
1501	PCB 915 jumper or cable

Step no. 16 Rx signal path test.

Tests Rx Signal Path PCB 915.

The pre-selector and the synthesizer is set-up so no signal passes the receiver. The AF Detector at the output checks that no signal is present.

Pre-selector: PRE 0

Band: 67.5 - 75 MHz

1. LO: 75.0000 MHz

3. LO: 456.7 kHz

The test is OK if $\overline{\text{AF CHECK}}=1$

<u>Error code</u>	<u>Possible error source</u>
1601	PCB 915 or cable
1602	RSP AF cable or PCB 717

Step no. 17 Rx signal path test.

Tests Rx Signal Path PCB 915.

By choosing the right synthesizer frequency the signal passes the 45 MHz filter and is mixed to a 1.7 kHz tone in the audio part of the receiver. The AF Detector at the output checks that signal is present.

Band: 45 - 52.5 MHz

1. LO: 44.99900 MHz

3. LO: 456.7 kHz

The test is OK if $\overline{\text{AF CHECK}}=0$

<u>Error code</u>	<u>Possible error source</u>
1701	PCB 915 or cable
1702	RSP AF cable or PCB 717

Step no. 18 EEPROM test

Tests Programmable Communication Processor PCB 717.
Checks and re-writes the EEPROM.

The test is OK if the checksum is correct.

<u>Error code</u>	<u>Possible error source</u>
1801	PCB 717

Step no. 19 DCU test


Tests the DCU 9000.

<u>Error code</u>	<u>Test</u>	<u>Possible error source</u>
1901	Audio/Speaker	PCB 901, cable, PCB 902, speaker
1902	Display backlight	Display, PCB 901
1903	Keyboard backlight	PCB 902, cable, PCB 901
1904	Contrast circuit	PCB 901, display
1905	Distress LED	PCB 902, cable, PCB 901
1906	Call LED	PCB 902, cable, PCB 901
1907	Supply LED	PCB 902, cable, PCB 901

DSC 9000 SPARE-PARTS


DSC CONTROL UNIT SPARE-PARTS

<u>Position</u>	<u>Designation</u>	<u>SKANTI part no.</u>
1	Control Board 901	107 890 11
2	Front Panel Board 902	107 890 21
3	Loudspeaker 50 ohms 1W	860 000 10




DSC UNIT 9001 SPARE-PARTS

<u>Position</u>	<u>Designation</u>	<u>SKANTI part no.</u>
1	Programmable Communication Processor 717 incl. screen covers.	107 805 60
2	Master Oscillator 913 (located on Single Ch. Receiver 914)	107 891 31
3	Single Channel Receiver 914 incl. Master Oscillator 913 and screen covers.	107 812 10
4	SMPS / Interconnection Assembly 930	107 809 80
5	W1 Ribboncable	106 811 10
6	W2 Ribboncable	106 811 00
7	W3 Ribboncable	106 811 10
8	W4 Ribboncable	106 811 00
9	W5 Ribboncable	106 811 50
10	Battery Container incl. batteries	107 811 60



DSC UNIT 9006 SPARE-PARTS

<u>Position</u>	<u>Designation</u>	<u>SKANTI part no.</u>
1	Programmable Communication Processor 717 incl. screen covers.	107 805 60
2	Synthesizer Board 711 incl Master Oscillator 713 and screen covers.	107 805 90
3	Master Oscillator 713 (located on Synthesizer Board 711)	107 871 31
4	Receiver Signal Path 915 incl. screen covers	107 812 00
5	SMPS / Interconnection Assembly 930	107 809 80
6	W1 Ribboncable	106 811 30
7	W2 Ribboncable	106 811 00
8	W3 Ribboncable	106 811 10
9	W4 Ribboncable	106 811 00
10	W5 Ribboncable	106 811 20
11	Battery Container incl. batteries	107 811 60



SKANTI SERVICE AGENTS

Argentina

J.M. Staffa Morris y Cia. S.A.
Domingo Savio 2881
1642 San Isidro
Tel: +54 1 732 1083
Fax: +54 1 732 1082

Australia

Electrotech Marine Pty. Ltd.
39/9 Powells Road
P.O. Box 1054
Brookvale, NSW 2100
Tel: +61 2 9905 6313
Fax: +61 2 9905 6318 - Tlx: 20175 elemar

Belgium

SAIT MARINE N.V.
Herentalsebaan, 55
B-2100 Deurne (Antwerp)
Tel: +32 33 201 711 - Tlx: 31547 sait a b
Fax: +32 33 662 470

Brazil

NAVALTRADE LTDA
Av. Rio Branco, 14-3 . Andar
20090-000 Rio de Janeiro
Tel: +55 21 253 5170
Fax: +55 21 233 2664

Canada

Canadian Marconi Company
600 Dr. Frederik Philips Blvd.
Ville Saint-Laurent, Quebec H4M 2S9
Tel: +1 514 748 3148 - Tlx: 5827822
Fax: +1 514 748 3100

Chile

ELECTRONICA HOLANDA LTDA.
Bulnes 136 Of. 306
Talcahuano
Tel: +56 41 544 915
Fax: +56 41 541 944

Mera Vennik Ltda.
Marine Electronics
Colon 1148
Talcahuano
Tel: +56 41 541 752
Fax: +56 41 543 489

I SYSTEMS LTDA.
Avda. Italia 2004
P.O. Box 463-11
Santiago
Tel: +56 2 205 2132
Fax: +56 2 209 9400

China

Racal-Decca Electronics (H.K.) Ltd.
6C, Sun House
181 Des Voeux Road, Central,
Hong Kong
Tel: +852 28532351
Fax: +852 28519967

Racal Decca Electronics Ltd.
Shanghai Office
Rm. 612, 555 east Zhonghahan Rd (2nd)
Shanghai, China
Tel: +86 21 3550 890
Fax: +86 21 6355 1000

Cyprus

Galaxy Communications Ltd.
89, Omonia Ave.
P.O. Box 1449
3505 Limassol
Tel: +357 5 373063/369529
Fax: +357 5 367033

Denmark

FURUNO DANMARK A/S
Hammerholmen 44-48, DK-2650 Hvidovre
Tel: +45 36 77 45 00 - Tlx: 27289
Fax: +45 36 77 45 01

Egypt

Eastern Electronics
48, El-Nahda St.
P.O. Box 120, Port Said R.C. 14085
Tel: +20 66 224393 / 221950 / 225431 - Tlx:
63000
Fax: +20 66 236159

England

Nera Ltd.
20, Imperial Way
Croydon - Surrey CR0 4RR
Tel: +44 181 68 65 701 - Tlx: 946384
Fax: +44 181 68 66 811

Finland

Furuno Suomi OY
Laivanrakentajantie 2
SF-00980 Helsinki
Tel: +358 0 317 277
Fax: +358 0 341 29 30

France

MARTEC
5, rue Carle-Vernet
F-92310 Sèvres
Tel: +33 1 46 23 79 09
Fax: +33 1 46 26 55 55

Germany

HDW-HAGENUK Schiffstechnik GmbH
Albert-Einstein-Ring 6
D-22761 Hamburg
Tel: +49 40 89 97 20 - Tlx: 212091 hsv d
Fax: +49 40 89 97 21 99

Greece

NAVICOM Electronics
10 Kolokotroni Str.
18531 Piraeus
Greece
Tel: +30 1 41 26 050 - Tlx: 213154
Fax: +30 1 41 28 660

RADIO MARINE Electronics
150 Kolokotroni Str.
18536 Piraeus
Greece
Tel: +30 1 45 14 307 - Tlx: 213106
Fax: +30 1 41 80 639

Holland

Internationale Navigatie Apparaten B.V.
P.O. Box 1590, Wijnhaven 42
NL-3000 BN Rotterdam
Tel: +31 10 403 8711 - Tlx: 22079
Fax: +31 10 433 0831

Hong Kong

Racal-Decca Electronics (H.K.) Ltd.
6C, Sun House
181 Des Voeux Road, Central,
Hong Kong
Tel: +852 28532351
Fax: +852 28519967

Iceland

BRIMRUN H.F.
Holmaslod 4
101 Reykjavik
Tel: +354 1 610160
Fax: +354 1 610163

India

Bombay Region:
ELEKTRONIK LAB
R/13 Navrozbaug
Lalbaug
Bombay 400012
Tel: +91 22 4137444 / 3780787 - Tlx:
1176333 elab in
Fax: +91 22 4137444

Calcutta Region:
Maricom Marine Services
27, Nakuleswar Bhatta Charya Lane
Kalighat
Calcutta 26
Telegram: maricom - Tlx: 7252 to 7255 user
code it-59 a/b - inl tgmca

Indonesia

Jason Electronics Pte. Ltd.
Bik 194 Pandan Loop
0605 Pantech Industrial Complex
Singapore 128383
Republic of Singapore
Tel: +65 872 0211 - Tlx: 35290 jepi
Fax: +65 872 1800

Ireland

Barry Electronics Ltd.
St. Catherine's Road
Killybegs, Donegal
Tel: +353 73 31215
Fax: +353 73 31739

Israel

Alhout-yam Ltd.
P.O. Box 1963
Hiram Street 22/24
Haifa 31019
Tel: +972 4620804/5 - Tlx: 46432 alh il
Fax: +972 4627404

Italy

Telecom Italia S.p.A. - Div. Clienti Privati
SIRM Servizi Radiomarittimi
I-00143 Roma - Piazzale Giulio Douhet, 25
Tel: +39 65 961 41 - Tlx: 610293
Fax: +39 65 920 771

Japan

KGK Kaigai Gijyutsu K.K.
25, Yamashita-cho,
Naka-ku, Yokohama
Tel: +81 45 664 7318
Fax: +81 45 664 7320
Telex: +72 - 47920 SIKGKY

Tokimec Inc.
Control Systems Div.
2-16, Minami-Kamata, Ohta-ku
Tokyo 144
Tel: +81 3 3737 8651
Fax: +81 3 3737 8663

Korea

JAEUN CORPORATION
642-8, Moonhyun-2Dong
Nam-Ku
Pusan 608-042
South Korea
Tel: +82 51 631 7398
Fax: +82 51 647 7515

Kuwait

Commercial Co-Ordination Centre w.l.l.
1 st Floor Al Thuwalny Building
All Al Salem Street
P.O.Box 25208
13113 Safat, Kuwait
Tel: +965 2462347
Fax: +965 2458070

Lebanon

Please contact Galaxy Communication Ltd.
Cyprus for further information.

Malaysia

Jason Electronics Pte. Ltd.
Bik 194 Pandan Loop
0605 Pantech Industrial Complex
Singapore 128383
Republic of Singapore
Tel: +65 872 0211 - Tlx: 35290 jepl
Fax: +65 872 1800

Malta

Medcomms Ltd.
4, Msida Road
Gzira
Tel: +356 335521 - Tlx: 331
Fax: +356 310820

Morocco

General Electronic Service S.A.
174, Bd. My Youssef - Casablanca 01
Tel: +212 2 264110 - Tlx: 24001
Fax: +212 2 264110

New Zealand

CSL Cetronics Systems Ltd.
4A King Street - P.O. Box 3562
Wellington
Tel: +64 43 828 868
Fax: +64 43 856 760

Norway

SKANTI RADIO A/S
Stanseveien 25
P.O. Box 104, Kalbakken
N-0902 Oslo
Tel: +47 22250660 - Tlx: 19971
Fax: +47 22250690

Peru

Tradex International Corp.
Mlc. 28 de Julio 511 piso 8
Miraflores, Lima 18
Tel: +51 144 74672 - Tlx: 25202
Fax: +51 144 74672

Portugal

SEMA ELECTRONICAS
Av. 24 de Julho, 60, 1^o
1200 Lisbon
Tel: +351 1 67 60 87/8/9 - Tlx: 12195
Fax: +351 1 60 37 39

Singapore

JASON ELECTRONICS PTE LTD
Bik 194 Pandan Loop
0605 Pantech Industrial Complex
Singapore 128383
Republic of Singapore
Tel: +65 872 0211 - Tlx: 35290 jepl
Fax: +65 872 1800

South Africa

PERTEC (PTY) LIMITED
304 Broadway Centre, Heerengracht
Foreshore 8001
Cape Town 8000
South Africa
Tel: +27 21 21 44 50
Fax: +27 21 25 31 62

Spain

CRAME S.A.
C/ La Rioja, s/n
Barajas Park, Barajas
28042 Madrid
Tel: +34 132 91 862 - Tlx: 23686 crame e
Fax: +34 132 93 045

RADIO MARITIMA INTERNACIONAL S.A.
C/ De La Granja, 3
28100 Alcobendas Madrid
Tel: +34 1 661 2568
Fax: + 34 1 661 7025

Sweden

FURUNO SWEDEN AB
Gruvgatan 23
S-42130 Västra Frölunda
Tel: +46 31 49 02 20 - Tlx: 21452
Fax: +46 31 49 70 93

RING MARINE COMMUNICATION AB
Ekonomivägen 2
S-43633 Askim / Göteborg
Tel: +46 31 68 29 62 - Tlx: 2293
Fax: +46 31 68 36 60

Taiwan

PEI SAY ENTERPRISE CO. LTD.
60-2, Pei Ning Road
Taipei
Tel: +886 2 579 8199 - Tlx: 28978
Fax: +886 2 579 6698

Tunisia

Mediterranee Service
Port de Peche de la Goulette
La Goulette
Tunisia
Tel: +216 1 736 824/736 816
Fax: +216 1 861 023

Turkey

ÖZSAY Deniz Nakliyatı Ltd.
Iskele Sokak no.44 Kadıköy
81320 Istanbul
Tel: +90 216 346 76 16 - Tlx: 29303
Fax: +90 216 418 41 74

SAIT ELECTRONICS
Yemeniciler Cad. No. 60
Omer Han K. 5
Karaköy - Istanbul
Tel: +90 212 255 54 34 - Tlx: 24156 sait tr
Fax: +90 212 250 45 24

U.A.E.

Radio Holland Middle East
P.O. Box 4592
Sharjah - U.A.E.
Tel: +971 6 543002 - Tlx: 68302
Fax: +971 6 356083

U.S.A.

MACKAY COMMUNICATIONS INC.
Raritan Center
P.O. Box 7819
Edison
New Jersey 08818-7819
Tel: +1 908 225 0909 - Tlx: 4754132
Fax: +1 908 225 2848/+1 908 225 4959

Radio Holland Group
8943 Gulf Freeway
Houston
Texas 77017
Tel: +1 713 943 3325
Fax: +1 713 943 3802
Tlx: 795438

Uruguay

Aeromarine Ltda.
Cerro Largo 1497
11200 Montevideo
Tel: +598 2 41 86 04 / 40 39 62 - Tlx: 22142
aeromar uy
Fax: +598 2 41 85 97

Venezuela

RADIO HOLLAND de Venezuela
Apartado 61210
Caracas 1060A
Tel: +58 2 752 74 80 - Tlx: 28566 rhol vc
Fax: +58 2 751 83 24

Service in the following countries:

- Russia,
- Ukraine,

- Estonia,
- Lithuania,
- Latvia,
- Poland,
- Bulgaria,
- Romania,
- Croatia

is to be requested from:

SAIT MARINE N.V.
Herentalsebaan, 55
B-2100 Deurne (Antwerp)
Belgium

HM 11.06.96